## GENERAL INFORMATION:

| | |
|---|---|
| **SIMPLWINDOWS NAME:** | Qsys Generic String Named Control |
| **CATEGORY:** | Qsys |
| **VERSION:** | 5.0.0 |
| **SUMMARY:** | Controls and monitors a single text Q-SYS Named Control (e.g. a text box, or any control set by its string value). |
| **GENERAL NOTES:** | SetStringValue accepts up to 255 characters. An empty string clears the control.<br><br>StringValue reports the control's string as Q-SYS reports it. For numeric controls this is Q-SYS's formatted text (e.g. "-10.0dB"); for a combo box it is the selected choice's text. |
| **CRESTRON HARDWARE REQUIRED:** | 3 Series Processor or 4 Series Processor |
| **SETUP OF CRESTRON HARDWARE:** | Requires a Qsys Core module in the same program with a matching CoreID. |
| **VENDOR FIRMWARE:** | N/A |
| **VENDOR SETUP:** | Uses a Q-SYS Named Control. |
| **GENERATION:** | Generated by Claude Code from SIMPL+ and SIMPL# source files |

## CONTROL:

| | | |
|---|---|---|
| **[SetStringValue]** | S | Sets the control's string value to the text received. |

## FEEDBACK:

| | | |
|---|---|---|
| **[StringValue]** | S | The control's current string value. |

## PARAMETERS:

| | | |
|---|---|---|
| **CoreID** | S | Used to address this module to the Qsys Core module with the same CoreID.<br>Default: 1 |
| **NamedControlName** | S | Name of the control as entered in Q-SYS Designer's Named Controls. |

## TESTING:

| | |
|---|---|
| **SAMPLE PROGRAM:** | 3-Series: 3 Series Test.smw<br>4-Series: 4 Series Test.smw |
| **REVISION HISTORY:** | |