GENERAL INFORMATION:

SIMPLWINDOWS NAME:	Qsys Room Combiner
CATEGORY:	Qsys
VERSION:	5.0.0
SUMMARY:	Opens and closes the walls of a Q-SYS Room Combiner component and reports wall state and which rooms are combined. Supports up to 3 walls and 4 rooms.
GENERAL NOTES:	Only walls 1 to TotalWalls and rooms 1 to TotalRooms are controlled and reported; signals above these counts do nothing.
CRESTRON HARDWARE REQUIRED:	3 Series Processor or 4 Series Processor
SETUP OF CRESTRON HARDWARE:	Requires a Qsys Core module in the same program with a matching CoreID.
VENDOR FIRMWARE:	N/A
VENDOR SETUP:	Works with a Q-SYS Room Combiner; Script Access must be External or All. It must have at least TotalWalls walls and TotalRooms rooms.
GENERATION:	Generated by Claude Code from SIMPL+ and SIMPL# source files

CONTROL:

WallOpen[1]–WallOpen[3]	D	Pulse to open the corresponding wall.
WallClose[1]–WallClose[3]	D	Pulse to close the corresponding wall.

FEEDBACK:

[WallOpenState[1]]–[WallOpenState[3]]	D	High when the corresponding wall is open.
[RoomCombined[1]]–[RoomCombined[4]]	D	High when the corresponding room (room combiner output) is combined with another room.

PARAMETERS:

CoreID	S	Used to address this module to a Qsys Core module. Must match the CoreID of the Qsys Core module. Default: 1
ComponentName	S	Code Name of the Room Combiner component in the Q-SYS design.
TotalWalls	Dec	Number of walls to control and monitor (1–3). Should match the number of walls in the Q-SYS Room Combiner.
TotalRooms	Dec	Number of rooms to monitor (1–4). Should match the number of rooms in the Q-SYS Room Combiner.

TESTING:

SAMPLE PROGRAM:	3-Series: 3 Series Test.smw 4-Series: 4 Series Test.smw
REVISION HISTORY:	