GENERAL INFORMATION:

SIMPLWINDOWS NAME:	Qsys Generic Integer Component Control
CATEGORY:	Qsys
VERSION:	5.0.0
SUMMARY:	Controls and monitors a single numeric control of any Q-SYS component (e.g. a gain fader, knob or integer value). The control is identified by the component's Code Name and the control's name within that component.
GENERAL NOTES:	Use either SetUnsignedIntegerValue or SetSignedIntegerValue depending on whether the control is to be driven by position (0-100% of travel) or by its actual value. IntegerValueScaled pairs with SetUnsignedIntegerValue when ScaleUnsigned is set to Yes; IntegerValueUnscaled pairs with SetSignedIntegerValue. Q-SYS position is the control's position within its range, which for gain controls is not linear in dB. IntegerValueUnscaled is the control's value truncated to a whole number (e.g. -12.7 dB reports as -12).
CRESTRON HARDWARE REQUIRED:	3 Series Processor or 4 Series Processor
SETUP OF CRESTRON HARDWARE:	Requires a Qsys Core module in the same program with a matching CoreID.
VENDOR FIRMWARE:	N/A
VENDOR SETUP:	The Q-SYS component that owns the control must have a Code Name set in its Properties, and Script Access set to External (or All). Enter that Code Name in the ComponentName parameter. ComponentControlName is the control's name inside that component as Q-SYS exposes it to external control (the name shown in the control's tooltip / Control Info in Q-SYS Designer, e.g. "gain", "mute"). It is case sensitive.
GENERATION:	Generated by Claude Code from SIMPL+ and SIMPL# source files

CONTROL:

[SetUnsignedIntegerValue]	A	Sets the control. With ScaleUnsigned = Yes, 0-65535 is sent as the control's position (0-100% of its range). With ScaleUnsigned = No, the number is sent unchanged as the control's value (0-65535).
[SetSignedIntegerValue]	A	Sets the control's value directly, in the control's own units (e.g. dB for a gain control). Not affected by ScaleUnsigned.

FEEDBACK:

[IntegerValueScaled]	A	The control's position in Q-SYS scaled to 0-65535 (0-100% of its range).
[IntegerValueUnscaled]	A	The control's value in its own units (e.g. dB), as a signed whole number.

PARAMETERS:

CoreID	S	Used to address this module to the Qsys Core module with the same CoreID. Default: 1
ComponentName	S	Code Name of the Q-SYS component that contains the control.
ComponentControlName	S	Name of the control within the component to be controlled.
ScaleUnsigned	Dec	Selects how SetUnsignedIntegerValue is sent: No = raw value, Yes = scaled 0-65535 to 0-100% position. Default: No

TESTING:

SAMPLE PROGRAM:	3-Series: 3 Series Test.smw 4-Series: 4 Series Test.smw
REVISION HISTORY:	