GENERAL INFORMATION:

SIMPLWINDOWS NAME:	Qsys Generic String Component Control
CATEGORY:	Qsys
VERSION:	5.0.0
SUMMARY:	Controls and monitors a single text control of any Q-SYS component (e.g. a text box, or any control set by its string value). The control is identified by the component's Code Name and the control's name within that component.
GENERAL NOTES:	SetStringValue accepts up to 255 characters. An empty string clears the control. StringValue reports the control's string as Q-SYS reports it. For numeric controls this is Q-SYS's formatted text (e.g. "-10.0dB").
CRESTRON HARDWARE REQUIRED:	3 Series Processor or 4 Series Processor
SETUP OF CRESTRON HARDWARE:	Requires a Qsys Core module in the same program with a matching CoreID.
VENDOR FIRMWARE:	N/A
VENDOR SETUP:	The Q-SYS component that owns the control must have a Code Name set in its Properties, and Script Access set to External (or All). Enter that Code Name in the ComponentName parameter. ComponentControlName is the control's name inside that component as Q-SYS exposes it to external control (the name shown in the control's tooltip / Control Info in Q-SYS Designer, e.g. "gain", "mute"). It is case sensitive.
GENERATION:	Generated by Claude Code from SIMPL+ and SIMPL# source files

CONTROL:

[SetStringValue]	S	Sets the control's string value to the text received.

FEEDBACK:

[StringValue]	S	The control's current string value.

PARAMETERS:

CoreID	S	Used to address this module to the Qsys Core module with the same CoreID. Default: 1
ComponentName	S	Code Name of the Q-SYS component that contains the control.
ComponentControlName	S	Name of the control within the component to be controlled.

TESTING:

SAMPLE PROGRAM:	3-Series: 3 Series Test.smw 4-Series: 4 Series Test.smw
REVISION HISTORY:	