GENERAL INFORMATION:

SIMPLWINDOWS NAME:	Qsys Meter
CATEGORY:	Qsys
VERSION:	5.0.0
SUMMARY:	Reports the level of one meter on a Q-SYS component. The component is addressed as a Named Component by its Code Name (ComponentName parameter). The module follows the component's meter_N control, where N is the Index parameter.
GENERAL NOTES:	MeterValue is the meter's position (0 to 1 across the meter's range in Q-SYS) scaled to 0–65535. It is not a dB value. Use one instance of this module per meter channel.
CRESTRON HARDWARE REQUIRED:	3 Series Processor or 4 Series Processor
SETUP OF CRESTRON HARDWARE:	Requires a Qsys Core module in the same program with a matching CoreID.
VENDOR FIRMWARE:	N/A
VENDOR SETUP:	In Q-SYS Designer, set the meter component's Code Name to match the ComponentName parameter and set its Script Access to External (or All). The component must have a control named meter_N for the chosen Index.
GENERATION:	Generated by Claude Code from SIMPL+ and SIMPL# source files

CONTROL:

N/A		

FEEDBACK:

MeterValue	A	Meter level, 0–65535, scaled from the meter's position in Q-SYS.

PARAMETERS:

CoreID	S	Used to address this module to a Qsys Core module. Must match the CoreID of the Qsys Core module. Default: 1
ComponentName	S	Code Name of the meter component in the Q-SYS design.
Index	Dec	Meter channel to follow. Selects which meter_N control is used.

TESTING:

SAMPLE PROGRAM:	3-Series: 3 Series Test.smw 4-Series: 4 Series Test.smw
REVISION HISTORY:	