## GENERAL INFORMATION:

| | |
|---|---|
| **SIMPLWINDOWS NAME:** | Qsys Nv Decoder |
| **CATEGORY:** | Qsys |
| **VERSION:** | 5.0.0 |
| **SUMMARY:** | Selects the source for one HDMI output of a Q-SYS NV Series decoder (e.g. NV-32-H) and reports the currently selected source.<br><br>The decoder is addressed as a Named Component by its Code Name (ComponentName parameter). The module controls the component's hdmi_out_N_select_index control, where N is the OutputNumber parameter. |
| **GENERAL NOTES:** | Source values are passed straight through to the Q-SYS select index control; no scaling is applied. Use the index numbering shown on the decoder's output select control in Q-SYS Designer.<br><br>CurrentSource follows the Q-SYS control, so it also updates when the source is changed from Q-SYS or another control system.<br><br>Use one instance of this module per HDMI output to be controlled. |
| **CRESTRON HARDWARE REQUIRED:** | 3 Series Processor or 4 Series Processor |
| **SETUP OF CRESTRON HARDWARE:** | Requires a Qsys Core module in the same program with a matching CoreID. |
| **VENDOR FIRMWARE:** | N/A |
| **VENDOR SETUP:** | In Q-SYS Designer, set the NV decoder component's Code Name to match the ComponentName parameter and set its Script Access to External (or All). |
| **GENERATION:** | Generated by Claude Code from SIMPL+ and SIMPL# source files |

## CONTROL:

| | | |
|---|---|---|
| **Source** | A | Source index to route to the selected HDMI output. Sent to the hdmi_out_N_select_index control each time the value changes. |

## FEEDBACK:

| | | |
|---|---|---|
| **[CurrentSource]** | A | Source index currently selected on the HDMI output, as reported by Q-SYS. |

## PARAMETERS:

| | | |
|---|---|---|
| **CoreID** | S | Used to address this module to a Qsys Core module. Must match the CoreID of the Qsys Core module.<br>Default: 1 |
| **ComponentName** | S | Code Name of the NV decoder component in the Q-SYS design. |
| **OutputNumber** | Dec | HDMI output to control (0–2). Selects which hdmi_out_N_select_index control is used.<br>Default: 1 |

## TESTING:

| | |
|---|---|
| **SAMPLE PROGRAM:** | 3-Series: 3 Series Test.smw<br>4-Series: 4 Series Test.smw |
| **REVISION HISTORY:** | |