GENERAL INFORMATION:

SIMPLWINDOWS NAME:	Qsys Signal Presence
CATEGORY:	Qsys
VERSION:	5.0.0
SUMMARY:	Monitors up to 4 channels of a Q-SYS Signal Presence component and adjusts its threshold, hold time and infinite hold settings. The component is addressed as a Named Component by its Code Name (ComponentName parameter). The module uses the component's signal_presence (or signal_presence_N), threshold, hold_time and infinite_hold controls.
GENERAL NOTES:	When Count is 1, the module uses the component's single signal_presence control. When Count is greater than 1, it uses signal_presence_1, signal_presence_2, and so on. PeakThresholdUp/Down and HoldTimeUp/Down each move the Q-SYS control by 10% of its full range per pulse, clamped at the ends of the range. PeakThreshold and HoldTime are the Q-SYS control's display strings (as shown in Q-SYS, including units). Feedback follows the Q-SYS controls, so it also updates when changes are made from Q-SYS or another control system.
CRESTRON HARDWARE REQUIRED:	3 Series Processor or 4 Series Processor
SETUP OF CRESTRON HARDWARE:	Requires a Qsys Core module in the same program with a matching CoreID.
VENDOR FIRMWARE:	N/A
VENDOR SETUP:	In Q-SYS Designer, set the Signal Presence component's Code Name to match the ComponentName parameter and set its Script Access to External (or All).
GENERATION:	Generated by Claude Code from SIMPL+ and SIMPL# source files

CONTROL:

[InfiniteHold]	D	Pulse to toggle infinite hold on/off, based on InfiniteHoldIsOn.
[PeakThresholdUp]	D	Pulse to raise the signal presence threshold by one step (10% of range).
[PeakThresholdDown]	D	Pulse to lower the signal presence threshold by one step (10% of range).
[HoldTimeUp]	D	Pulse to raise the hold time by one step (10% of range).
[HoldTimeDown]	D	Pulse to lower the hold time by one step (10% of range).

FEEDBACK:

SignalPresence1–SignalPresence4	D	High while signal is present on the corresponding channel. Only channels up to Count are reported.
[InfiniteHoldIsOn]	D	High when infinite hold is on.
[PeakThreshold]	S	Current threshold value as displayed in Q-SYS.
[HoldTime]	S	Current hold time value as displayed in Q-SYS.

PARAMETERS:

CoreID	S	Used to address this module to a Qsys Core module. Must match the CoreID of the Qsys Core module. Default: 1
ComponentName	S	Code Name of the Signal Presence component in the Q-SYS design.
Count	Dec	Number of channels on the Q-SYS Signal Presence component (1–4).

TESTING:

SAMPLE PROGRAM:	3-Series: 3 Series Test.smw 4-Series: 4 Series Test.smw
REVISION HISTORY:	