GENERAL INFORMATION:

SIMPLWINDOWS NAME:	Qsys Snapshot Controller
CATEGORY:	Qsys
VERSION:	5.0.0
SUMMARY:	Recalls and saves snapshots in a Q-SYS Snapshot Controller (snapshot bank) component and reports which snapshot is active. Supports up to 32 snapshots. The snapshot bank is addressed as a Named Component by its Code Name (ComponentName parameter). Recall and save trigger the component's load_N and save_N controls.
GENERAL NOTES:	In LatchRecallSave mode (Mode = 1), hold Load (or Save) high and change Number: each new Number value recalls (or saves) that snapshot. Pulsing Load or Save alone does nothing in this mode, and setting Number to 0 is ignored. In PulseRecallSave mode (Mode = 2), set Number first, then pulse Load to recall or Save to save that snapshot. Changing Number alone does nothing in this mode. SnapshotActive follows the state of each snapshot's load_N control in Q-SYS, so it reflects recalls made from Q-SYS or another control system as well.
CRESTRON HARDWARE REQUIRED:	3 Series Processor or 4 Series Processor
SETUP OF CRESTRON HARDWARE:	Requires a Qsys Core module in the same program with a matching CoreID.
VENDOR FIRMWARE:	N/A
VENDOR SETUP:	In Q-SYS Designer, set the Snapshot Controller component's Code Name to match the ComponentName parameter and set its Script Access to External (or All).
GENERATION:	Generated by Claude Code from SIMPL+ and SIMPL# source files

CONTROL:

Load	D	Mode 2: Pulse to recall the snapshot set on Number. Mode 1: Hold high to recall snapshots as Number changes.
[Save]	D	Mode 2: Pulse to save the current state to the snapshot set on Number. Mode 1: Hold high to save snapshots as Number changes.
Number	A	Snapshot number to recall or save (1 = first snapshot).

FEEDBACK:

[SnapshotActive[1]]–[SnapshotActive[32]]	D	High when the corresponding snapshot is active in Q-SYS. Only snapshots up to NumberOfSnapshots are reported.

PARAMETERS:

CoreID	S	Used to address this module to a Qsys Core module. Must match the CoreID of the Qsys Core module. Default: 1
ComponentName	S	Code Name of the Snapshot Controller component in the Q-SYS design.
Mode	Dec	Selects how Load and Save are used. 1 = LatchRecallSave: hold Load/Save high and change Number. 2 = PulseRecallSave: set Number, then pulse Load/Save.
NumberOfSnapshots	Dec	Number of snapshots in the Q-SYS Snapshot Controller to monitor for SnapshotActive feedback (maximum 32). Default: 8

TESTING:

SAMPLE PROGRAM:	3-Series: 3 Series Test.smw 4-Series: 4 Series Test.smw
REVISION HISTORY:	