

GENERAL INFORMATION:

SIMPLWINDOWS NAME:	Qsys Core
CATEGORY:	Qsys
VERSION:	4.3.0
SUMMARY:	Multiple core modules can be used in the same program slot. This module has a built in reconnect feature.
GENERAL NOTES:	N/A
CRESTRON HARDWARE REQUIRED:	3 Series Processor or 4 Series Processor
SETUP OF CRESTRON HARDWARE:	TCP managed inside the module.
VENDOR FIRMWARE:	N/A
VENDOR SETUP:	N/A

CONTROL:

Initialize	D	Pulse to Initialize connection to the Q-SYS Core. Pulse this after PrimaryCoreIpAddress, BackupCoreIpAddress, Port, and UseExternalConnection have been set to their desired states.
[PrimaryCoreIpAddress]	S	Optional. IP Address or Hostname of the Q-SYS Core to connect to for Deployment.
[BackupCoreIpAddress]	S	Optional. IP Address or Hostname of the redundant/backup Q-SYS Core in your design.
[Port]	A	Optional. TCP Port to use for connection if different from the default: 1710.
[Debug]	A	Specifies the Debug level for the program 0: Disabled 1: Logging Enabled 2: Debug Enabled 3: All Enabled Debug prints to Console Output.
[UseExternalConnection]	D	Raise to handle TCP connection outside of this module.
[ExternalConnectionRx]	S	Rx from the external TCP socket.

FEEDBACK:

[IsInitialized]	D	Signal used to show if the Q-SYS Core has been initialized.
[PrimaryCoreIsConnected]	D	Signal used to show if the Primary Q-SYS Core is connected.
[BackupCoreIsConnected]	D	Signal used to show if the Backup Q-SYS Core is connected.
[PrimaryCoreIsActive]	D	Signal used to show if the Primary Q-SYS Core is the one currently running.
[BackupCoreIsActive]	D	Signal used to show if the Backup Q-SYS Core is the one currently running.
[IsLoggedIn]	D	Signal used to show if this module is logged in with the Q-SYS Core.
[IsRedundant]	D	Signal used to show if the Q-SYS Core is redundant.
[IsEmulator]	D	Signal used to show if the Q-SYS Core is connected to an emulated file.
[DesignName]	S	Signal used to show the current running design on the Q-SYS Core.
[ExternalConnectionTx]	S	Tx to the external TCP socket.

PARAMETERS:

CoreID	S	Used to Address Core Module to Control Modules
Default Primary Core IP Address	S	IP Address of your Primary Q-SYS Core
Default Backup Core IP Address	S	IP Address of your Backup Q-SYS Core
Username	S	Username for the Core (if required)
Password	S	Password for the Core (if required)
Port	Dec	Default: 1710 Can be changed if doing port forwarding to get to a Q-SYS Core

TESTING:

SAMPLE PROGRAM:	3-Series: 3 Series Test.smw 4-Series: 4 Series Test.smw
REVISION HISTORY:	