



Air Impact Wrench


Models 1712B2 and 1712P2

Parts Information





Model 1712B2 Air Impact Wrench - Exploded View



03531753_ed14

2

Model 1712B2 Air Impact Wrench - Parts List

Item	Part Description	Part Number	Item	Part Description	Part Number
ntem 1	Inside Trigger Handle Assembly	1712-A92	item *	Dead Handle	834-48
2	Grease Fitting	130SR-188	43	Side Spade Handle	T15-41
5	Inside Trigger	834-93A	44	Side Spade Handle Stud	534-148
•6	Inside Trigger Pin	534-265	45	Side Spade Handle Stud Nut	107-73A
7	Throttle Valve Plunger	2934-302	45A	Side Spade Handle Bracket	2934-364
8	Throttle Valve Assembly	2934-302 2934-A50	45A 45B	Side Spade Handle Bracket Spacer (2)	2934-364
†•9	Throttle Valve Face	2934-A30 2934-159	436	1" Square Drive Anvil	2934-140
†•10	Throttle Valve Spring	834-51	40	Standard Length	1712-726
11		845-565		6" Extended Length	280-726-6
	Straight Inlet		47	, ,	-
† 12	Air Strainer Screen	434-61	• 47	Retainer Ring (for 1" Square Drive Anvil)	RR10015S
†•13	Reverse Valve Seal	R00BR-210	49	Spline Drive Anvil	T
†•15	Handle Gasket	2934-283		Standard Length	1712-A526
16	Motor Clamp Washer	2934-207		6" Extended Length	280-A514-6
17	Rear End Plate	2934-12	50	Retaining Plunger Spring	2940-231
† 18	Rear Rotor Bearing	508-97	51	Socket Retaining Ball	D04-280
19	Rotor	2934-53	52	Retaining Ball Plunger	845-230
†•20	Vane Packet (set of 6 Vanes)	2934-42-6	53	Plunger Retaining Pin	845-128
21	Cylinder	2934-3	54	Exhaust Deflector	280-167
22	Front End Plate	2934-11	55	Exhaust Deflector Screw (2)	W54-376
† 23	Front Rotor Bearing	810-97	56	Nameplate	1712-301
24	Cylinder Dowel	2934-98	57	Nameplate Screw (4)	C32-302
25	Motor Housing Asssembly	1712-A40	*	Exhaust Deflector Kit	2934-K23
26	Reverse Valve Bushing	2934-330S	*	Exhaust Baffle	2934-124
†•27	Air Port Gasket (2)	R44H-210A	*	Gasket	2934-223
†•27A	Air Port Gasket Retainer (2)	2940-200	*	Silencer	2940P-311
28	Reverse Lever	2934-658A	*	Screw (2)	R43F-104
†•29	Reverse Lock Plunger	4U-663B	*	Piped-Away Exhaust Kit	
†•30	Reverse Lock Plunger Spring	4U-664		without Muffler	2940-K184
31	Reverse Valve Assembly	2934-A329	*	Exhaust Adapter	294-167
†•32	Valve Seal	85H-167	*	Exhaust Adapter Gasket	2940-30
33	Hammer Case Assembly	1712B-A727	*	Adapter Cap Screw (2)	AL-638
34	Hammer Case Bushing	2934-641	*	Exhaust Hose	R21-230
34A	Warning Label	WARNING-2-99	*	Hose Clamp	R21-31
† 35	Hammer Case Gasket	2934-36	*	Horizontal Hanger	2934-366
36	Hammer Case Cap Screw (4)	834-638	*	Tune-up Kit (includes illustrated parts 3,	
	Hammer Case Cap Screw			9, 10, 12, 13, 15, 18, 20, 23, 27 (2),	1712B/1712P-TK3
37	Lock Washer (4)	34U-58		27A (2), 29, 30, 32 and 35)	
38	Handle Cap Screw (4)	510-638		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1
39	Cap Screw Lock Washer (4)	8U-58			
40	Hammer Frame Assembly	2934-A703			
.5		233.703	1		

⁴² * Not Illustrated.

41

Hammer

Hammer Pin (2)

2934-704


1712-724

03531753_ed14 3

[†] Indicates Tune-up Kit Part.

[•] To keep downtime to a minimum it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each Part indicated by a bullet (•) for every four tools in service.

Model 1712P2 Air Impact Wrench - Exploded View



(Dwg. TPA873-3)

4 03531753_ed14

Model 1712P2 Air Impact Wrench - Parts List

Item	Part Description	Part Number	Item	Part Description	Part Number	
1	Motor Housing Assembly	1712P-A40	† 40	Front Rotor Bearing	810-97	
2	Trigger	2934P-93	†•41	Hammer Case Gasket	2934-36	
3	Trigger Spring	2934P-51	*	Dead Handle	834-48	
5	Trigger Bushing	2905-915	42	Side Spade Handle	T15-41	
†•6	Air Port Gasket (2)	R44H-210A	43	Side Spade Handle Stud	534-448	
†•7	Gasket Retainer (2)	2940-200	44	Side Spade Handle Nut	107-73A	
8	Throttle Valve	2934P-A50	44A	Side Spade Handle Bracket	2934-364	
†•9	Throttle Valve Face	2934-159	44B	Side Spade Handle Bracket Spacer (2)	2934-140	
10	Throttle Valve Plunger	2934P-302	45	Hammer Frame Assembly	2934-A703	
†•11	Throttle Valve Spring	834-51	46	Hammer Pin (2)	2934-704	
† 12	Air Strainer Screen	434-61	47	Hammer	1712-724	
13	Straight Inlet	845-565	48	1" Square Drive Anvil		
14	Reverse Valve Bushing	2934P-330S		Standard Length	1712-726	
15	Reverse Valve Assembly	2934P-A329		6" Extended Length	280-726-6	
†•16	Reverse Valve Seal	85H-167	• 49	Retainer Ring (for 1" Square Drive Anvil)	RR10015S	
17	Reverse Lever	2934-658A	51	Hammer Case Assembly	1712-A727	
†•18	Reverse Lock Plunger	4U-663B	52	Hammer Case Bushing	2934-641	
† 19	Reverse Lock Spring	4U-664	52A	Warning Label	WARNING-2-99	
20	Power Regulator Assembly	2934P-A249	53	Cap Screw Lock Washer (4)	34U-58	
† 21	Power Regulator Seal	R1A-159	54	Hammer Case Cap Screw (4)	834-638	
22	Power Regulator Retaining Ball	AV1-255	*	Muffler	2910-674	
23	Housing Cover Lock Washer (4)	8U-58	56	Spline Drive Anvil		
24	Housing Cover Cap Screw (4)	510-638		Standard Length	1712-A526	
25	Housing Cover Assembly	1712P-A102		6" Extended Length	280-A514-6	
28	Grease Fitting	130SR-188	57	Retaining Plunger Spring	2940-231	
30A	Nameplate	1712P-301	58	Socket Retaining Ball	D04-280	
† 30B	Nameplate Screws (3)	C32-302	59	Retaining Ball Plunger	845-230	
† 31	Housing Cover Gasket	2934-283	60	Plunger Retaining Pin	845-128	
32	Motor Clamp Washer	2934-207	*	Horizontal Hanger	2934-366	
33	Cylinder	2934-3	*	Tune-up Kit (includes illustrated parts	1712B/1712P-TK3	
34	Cylinder Dowel	2934-98		3, 6 [2], 7 [2], 9, 11, 12, 16, 18, 19, 21, 27,		
† 35	Rear Rotor Bearing	508-97		30, 31, 35, 38, 40 and 41)		
36	Rear End Plate	2934-12				
37	Rotor	2934-53				
			1			
†•38	Vane Packet (set of 6 Vanes)	2934-42-6				

^{*} Not Illustrated.

Parts and Maintenance

When the life of the tool has expired, it is recommended that the tool be disassembled, degreased and parts be separated by material so that they can be recycled.

Tool repair and maintenance should only be carried out by an authorized Service Center.

Refer all communications to the nearest Ingersoll Rand Office or Distributor.

Related Documentation

For additional information refer to:

Air Impact Wrench Product Safety Information Manual 04580916.

Air Impact Wrench Product Information Manual 16581977.

Manuals can be downloaded from www.ingersollrandproducts.com.

03531753_ed14 5

[†] Indicates Tune-up Kit Part.

[•] To keep downtime to a minimum it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each Part indicated by a bullet (-)for every four tools in service.

Notes:			

Notes:			



© 2012 Ingersoll-Rand, plc

