Bluewater Spirit

Light Code Reference

Three indicator lights on the control panel:

ON (top) · FILTER (middle) · SERVICE (bottom)

#	Light pattern	Symptom	What to do
1		No power to purifier	Connect the purifier to power.
2		Filter replacement due soon	Replace filter. See manual p. 26.
3		Filter overdue — replace immediately	Replace filter now. See manual p. 26.
4		RO water quality decreased (safe to drink within 30 s)	Let water run up to 120 s. If SERVICE stays on, contact dealer to replace RO membrane.
5		**DO NOT DRINK — quality not OK** **Purifier may have stopped**	Wait up to 120 s. If stopped: disconnect & reconnect power — let it auto-flush. Contact dealer if SERVICE light stays on.
6		Water quality sensor malfunction	Wait up to 120 s for SERVICE light to clear. Contact dealer if fast flash continues.
7a		Low inlet pressure — auto-restart active	Ensure inlet supply valve is fully open. Min inlet pressure: 1.5 bar (22 psi). Purifier retries up to 10 times.
7b		7a + noise from purifier (Inlet Grid Filter or filter blocked)	Clean the Inlet Grid Filter (p. 31). If noise persists, replace the filter (p. 26).
8		**Faucet not fully closed** **or small leak detected**	Close faucet fully. If it persists, disconnect power and check all connections for leaks.
9		**Overflow protection activated**	Disconnect from power. Wipe base plate dry. Reconnect. If protection activates again, contact dealer.

© Bluewater Group 2025