
Rocketronics Connection diagram: JMC iHSV/iHSS -> Netbob CNC Control







Use an adapter or a straight ethernet Patchcable (CAT5-CAT7) to connect the motor to the CNC control! Below you find the pinout of the ethernet patchcable standard.

Motorsignal	ENA+	ENA-	PUL-	DIR+	DIR-	PUL-	Bridge!	
Color	white-orange	orange	white-green	ənjq	white-blue	green	white-brown	brown
RJ45-PIN-Nr.		2	3	4	5	9	2	8

RJ45 Pinout T-568B





- White Orange
- Orange
 White Green
 Blue
 - Blue

- White Blue 2
- 6. Green 7. White Brown 8. Brown