Aether Router - User Manual

Official Technical Specification, Operating Instructions & Support Policy

Category:	Electronics	**Retail Price:**	$120.25
Model Number:	AR-7000-TRI	**Warranty Term:**	1 Month Limited

1. Product Overview & Technical Specifications

The Aether Router is an ultra-fast, tri-band Wi-Fi 7 wireless networking hub engineered to satisfy high-density connected home and small office environments. Powered by a 2.0 GHz quad-core 64-bit processing unit and 1GB of DDR4 memory, it delivers aggregate theoretical wireless speeds of up to 9.6 Gbps across simultaneous 2.4 GHz, 5 GHz, and 6 GHz spectrum channels. The router features six external beamforming antennas with high-gain power amplifiers, one 10GbE WAN port for multigigabit fiber uplinks, four 2.5GbE LAN ports for low-latency wired connections, and full support for WPA3 Enterprise encryption. Its intelligent traffic orchestration engine automatically optimizes quality of service (QoS) for cloud gaming, 8K video streaming, and latency-critical VoIP calls.

2. Setup & Operating Instructions

Setting up your Aether Router requires just a few straightforward steps. First, position the router in a central, elevated location away from metal structures and thick concrete walls. Connect your broadband fiber terminal or modem to the yellow 10GbE WAN port using the provided Cat6a Ethernet cable. Plug in the 12V DC power adapter and push the power toggle; allow two minutes for the status indicator to turn solid sky blue. Connect your PC or mobile device to the default Wi-Fi network printed on the bottom label, or open a browser to '192.168.1.1'. The interactive QuickSetup Wizard will guide you through establishing a custom SSID, setting a strong WPA3 passphrase, and creating an isolated guest network for IoT devices.

3. Troubleshooting & Diagnostics Guide

Should network connectivity issues arise, carry out the following troubleshooting protocols. Issue 1: WAN LED remains solid amber with no internet access. Resolution: Power cycle your fiber modem and the Aether Router in sequence, verify that the Ethernet cable is securely clicked into the WAN port, and confirm with your ISP whether MAC address cloning is required. Issue 2: Wireless dropouts or high interference on the 5GHz/6GHz bands. Resolution: Access the web admin portal, navigate to Wireless Settings, and enable Automatic Channel Selection (ACS) or change DFS channels to bypass local radar interference. Issue 3: Admin password lost or portal unreachable. Resolution: Use a paperclip to depress the recessed reset pinhole on the back panel for 10 seconds to restore factory default parameters.

4. Warranty Terms & Customer Support Information

Warranty Summary: 1 Month (30 Days) Limited Manufacturer Protection

The Aether Router includes a 1-month (30-day) manufacturer limited warranty starting on the date of original customer shipment. The warranty covers defects in router hardware components, integrated transceiver failure, Ethernet port solder defects, and bundled AC power adapter malfunctions. It explicitly excludes damage resulting from unauthorized third-party firmware flashing (e.g., non-certified OpenWrt builds), electrical surges caused by lightning, or physical antenna breakage due to impact. To submit a warranty claim within the 1-month term, email support@agentichelpdesk.com including your router serial number, MAC address, and a diagnostic system log snapshot for RMA evaluation.