# Sonic Screwdriver V2 - User Manual

Official Technical Specification, Operating Instructions & Support Policy

| | | | |
|---|---|---|---|
| **Category:** | Electronics | **Retail Price:** | $340.00 |
| **Model Number:** | SS-V2-SONIC | **Warranty Term:** | 1 Month Limited |

## 1. Product Overview & Technical Specifications

The Sonic Screwdriver V2 is a versatile multi-frequency acoustic resonance diagnostic tool and non-contact mechanical fastener manipulator designed for electronics engineers, hardware technicians, and advanced hobbyists. Featuring a wide-spectrum piezoelectric ultrasonic transducer capable of generating precise sound wave resonance between 20 Hz and 400 kHz, the device loosens, fastens, or analyzes micro-mechanical components without physical torque. Constructed from aerospace-grade brushed titanium with knurled ergonomic grips, it features a dual-stage activator button, a tactile haptic rotary frequency selector, an integrated high-lumen multi-spectrum LED targeting emitter, and a magnetic induction charging dock that replenishes the internal cell in under 40 minutes.

## 2. Setup & Operating Instructions

Using the Sonic Screwdriver V2 requires selecting the appropriate acoustic resonance mode for your workpiece. Lift the tool from its magnetic charging dock; the emitter ring will illuminate steady emerald. Rotate the knurled collar to choose your desired operating profile: Mode 1 for micro-fastener harmonic release, Mode 2 for acoustic density scanning, or Mode 3 for non-contact electromagnetic field detection. Aim the focused targeting LED at the target fastener or component from a distance of 2 to 5 centimeters. Depress the activator button halfway to focus the frequency lock; once the haptic feedback pulses twice, depress the button fully to emit the resonant wave burst until the fastener disengages or the diagnostic reading registers.

## 3. Troubleshooting & Diagnostics Guide

If the tool fails to operate as expected, use these troubleshooting steps to diagnose the issue. Issue 1: Acoustic emitter does not vibrate or loosen fasteners. Resolution: Clean the emitter tip aperture using compressed air to remove microscopic debris, ensure the battery is charged above 30%, and adjust the rotary dial fine-tuning trim to match fastener resonance frequency. Issue 2: Targeting LED flashes amber with an audible warning tone. Resolution: The device has entered thermal safety lockout following excessive continuous firing; allow the tool to rest for 3 minutes to disperse internal transducer heat. Issue 3: Tool does not charge on magnetic dock. Resolution: Wipe the base gold pogo-pins with isopropyl alcohol to clear oxidation and ensure the dock is plugged into a 5V/2A power supply.

## 4. Warranty Terms & Customer Support Information

**Warranty Summary:** 1 Month (30 Days) Limited Manufacturer Protection

The Sonic Screwdriver V2 is covered by an official 1-month (30-day) limited warranty against defects in materials and manufacturing from the date of initial delivery. This warranty covers the ultrasonic transducer array, internal logic board, rotary selector mechanism, and magnetic charging base. It specifically excludes damage caused by using the tool as a physical pry bar, exposing the emitter tip to liquids, dropping the tool from heights exceeding one meter, or unauthorized casing disassembly. To file a warranty claim within the 1-month period, contact Helpdesk Support at support@agentichelpdesk.com with your order number and a brief video demonstrating the transducer failure to obtain replacement processing. For technical assistance scheduled firmware.