6328 RE-BOT OPERATOR CONTROLS

DISABLE VACUUM

ENABLE VACUUM

LOWER INTAKE

FORCE HATCH

RAISE INTAKE

FLOOR SET POINT

FORCE CARGO

CARGO EJECT

SHIP SET POINT

CARGO INTAKE

ROCKET L2
SET POINT

HATCH EJECT

ROCKET L1
SET POINT

HATCH INTAKE

ELEVATOR DRIVE

CLIMBER DRIVE