Untrust Components

In Hypervisor TCB (First TCB Layer)

VU mode

Untrusted App

EasyAda Hypervisor VMM

Host App

U mode

VS mode

Non-Confidential VM

vSBI

HS mode

EasyAda Hypervisor Driver

EasyAda Microkernel

S mode

Hardware Abstract Layer

M mode

SBI Firmware

M mode

CPU Side

hart

PMP/ePMP

IOPMP

RoT

I/O Devices Side

Accelaretor

Other peripheral devices

Hardware

Hardware