Untrust Components

In Hypervisor TCB (First TCB Layer)

VU Mode

Untrusted App

EasyAda Hypervisor VMM

Host App

U Mode

VS Mode

Non-Confidential VM

vSBI

HS Mode

EasyAda Hypervisor Driver

EasyAda Microkernel

Hardware Abstract Layer

HS Mode

M Mode

SBI Firmware

M Mode

Hardware

CPU Side

hart

PMP/ePMP

IOPMP

RoT

I/O Devices Side

Accelaretor

Other peripheral devices