9. Memory Location Mappings

The following locations in memory are utilized. All other locations are unused.

Coils

Coil	Description
00017	Compressor On/Off
00062	Debug Bit (see section 10)

Inputs

None

Holding Registers

Holding Register	Description
40010	Temperature Setpoint

Input Registers

Input Register	Description
30010	Current Fanspeed
30011	Current Temperature
30031	System Messages (1+2)
30032	System Messages (3+4)
30033	System Messages (5+6)
30034	System Messages (7+8)
30035	System Messages (9+10)
30036	System Messages (11+12)
30037	System Messages (13+14)
30038	System Messages (15+16)
30039	System Messages (17+18)
30040	System Messages (19+20)
30041	System Messages (21+22)
30042	System Messages (23+24)
30043	System Messages (25+26)
30044	System Messages (27+28)
30045	System Messages (29+30)
30046	System Messages (31+32)

30047	System Messages (33+34)
30048	System Messages (35+36)
30049	System Messages (37+38)
30050	System Messages (39+40)

10. Debug Bit

When the debug bit is set to 1, the memory reserved for system messages in normal operation will be filled with system debugging information. By default, the debug bit is set to 0. This is not to be used in normal operation and is reserved for service technicians.

NOTE: The end user web panel and api.php endpoints do not have the ability to toggle this bit.