


# 防火墙透明模式下做双向 NAT 典型配置

#### 一、组网需求

如下图所示:某市银行通过外联路由器连接国税,地税等外联单位,通过骨干路由器连接银行骨干网。为了保证内网的安全,在外联单位和内网之间部署了一台 USG 防火墙,通过严格的规则限制内网和外联单位之间的互相访问。



## 具体需求如下:

- 防火墙采用透明模式接入,不影响原有的网络结构和地址规划。G0/0/0 连接内网核心交换, TRUST 区域, G0/0/1 连接外联路由器, UNTRUST 区域。
- 业务访问需求:外联单位只能够访问内网的业务前置机的特定端口。内网的业务前置机和某些终端可以访问外联单位的业务主机。
- 对外联单位发布一个业务前置机的虚地址,对内网用户发布一个外联单位业务主机的虚地址。
- ◆ 外联单位业务主机只允许固定的某个地址可以访问。
- 为了保证内网安全,不能在内网的核心三层交换机上配置到到外联单位的路由。
- 为了保证路由器性能,外联路由器只做路由转发,通过防火墙做 NAT 策略。

### 二、IP 地址, NAT 地址规划:



数据	备注
接口编号: G/0/0/0	防火墙透明模式下可以使用
接口编号: G/0/0/1	额外的接口配置地址进行管
接口加入 VLAN10	理。也可以配置 VLAN 地址,
Ip 地址;无	来进行管理
Trust: GigabitEthernet 0/0/0	
Untrust: GigabitEthernet 0/0/1	
真实地址: 10.112.0.1/24	外联国税服务器只允许源地
对外发布地址: 9.108.101.10/24	址为 9.108.101.10 的地址访
	问
真实地址: 9.108.100.1/24	内部用户通过访问
对内发布地址: 10.112.100.1/24	10.112.100.1 来访问外联单
	位国税服务器
	接口编号: G/0/0/0 接口编号: G/0/0/1 接口加入 VLAN10 Ip 地址;无  Trust: GigabitEthernet 0/0/0 Untrust: GigabitEthernet 0/0/1 真实地址: 10.112.0.1/24 对外发布地址: 9.108.101.10/24

## 三、配置思路

配置 USG 的工作模式,并将接口加入相应安全区域。

配置域间防火墙策略。

配置 Trust 到 Untrust 的 NAT Outbound.

配置 Untrust 到 Trust 的 NAT Inbound.

配置 NAT Server

## 四、操作步骤

1. 配置 USG5310 的工作模式并将接口加入对应安全区域。 <USG5310>system-view [USG5310]firewall mode transparent

## 2. 将接口加入安全区域

[USG5310]firewall zone trust

[USG5310-zone-trust]add interface GigabitEthernet 0/0/0

[USG5310-zone-trust]quit

[USG5310]firewall zone untrust

[USG5310-zone-untrust]add interface GigabitEthernet 0/0/1

[USG5310-zone-untrust]quit



3. 配置域间防火墙策略

4. 配置 NAT 地址池

[USG5310]nat address-group 1 9.108.101.10 9.108.101.10 此 nat 地址池用于内网终端和业务前置机访问外联服务器时的 nat outbound 规则

### 配置 trust 到 untrust 的 NAT Outbound 规则

[USG5310]nat-policy interzone trust untrust outbound

[USG5310-nat-policy-interzone-trust-untrust-outbound]policy 1

[USG5310-nat-policy-interzone-trust-untrust-outbound-1]policy source 10.112.0.

#### 0 0.0.0.255

[USG5310-nat-policy-interzone-trust-untrust-outbound-1]action source-nat

 $[USG5310-nat-policy-interzone-trust-untrust-outbound-1] address-group\ 1$ 

[USG5310-nat-policy-interzone-trust-untrust-outbound-1quit

### 配置 trust 到 untrust 的 NAT Inbound 规则

[USG5310]nat-policy interzone trust untrust inbound

[USG5310-nat-policy-interzone-trust-untrust-inbound]policy 1

[USG5310-nat-policy-interzone-trust-untrust-inbound-1]policy source 9.108.100.10

0

[USG5310-nat-policy-interzone-trust-untrust-inbound-1]action source-nat

[USG5310-nat-policy-interzone-trust-untrust-inbound-1]address-group 2

[USG5310-nat-policy-interzone-trust-untrust-inbound-1]quit

### 配置 NAT Server 规则

[USG5310]nat server global 9.108.101.10 inside 10.112.0.1

[USG5310]nat server global 10.112.100.1 inside 9.108.100.10

### 从外联单位服务器(9.108.100.10)上 ping 9.108.101.10,在防火墙上看到会话表如下:

[USG5310]disp firewall session table

17:49:38 2011/02/22

Current Total Sessions: 2

icmp VPN: public -> public

9.108.101.10:768[10.112.0.1:12838] < --9.108.100.10:768[10.112.100.1:12838]

## 从内网业务服务器(10.112.0.1)ping 10.112.100.1,在防火墙看到会话表如下:

10.112.0.1:44000 [9.108.101.10:44000] --> 10.112.100.1:44000 [9.108.100.10:44000]

## 配置脚本:



```
<USG5310>disp cu
18:08:23 2011/02/22
acl number 2000
 rule 0 permit
 sysname USG5310
 ftp server enable
 web-manager enable
 web-manager security enable
 firewall packet-filter default permit interzone local t
 firewall packet-filter default permit interzone local t
 firewall packet-filter default permit interzone local u
 firewall packet-filter default permit interzone local u
d
 firewall packet-filter default permit interzone local d
 firewall packet-filter default permit interzone local d
 firewall packet-filter default permit interzone trust u
 firewall packet-filter default permit interzone trust u
 firewall packet-filter default permit interzone trust d
 firewall packet-filter default permit interzone trust d
 firewall packet-filter default permit interzone dmz unt
 firewall packet-filter default permit interzone dmz unt
 nat address-group 1 9.108.101.10 9.108.101.10
 nat address-group 2 10.112.100.1 10.112.100.1
 nat server 0 global 9.108.101.10 inside 10.112.0.1
 nat server 1 global 10.112.100.1 inside 9.108.100.10
 firewall statistic system enable
interface Vlanif10 (如果核心交换机和路由器之间互联地址为30为掩码,可以不用配
置 VLAN 地址,采用额外的一个防火墙接口进行管理)
 ip address 9.107.1.3 255.255.255.0
interface GigabitEthernet0/0/0
 port default vlan 10
interface GigabitEthernet0/0/1
```





```
port default vlan 10
interface GigabitEthernet0/0/2
interface GigabitEthernet0/0/3
interface NULL0
firewall zone local
 set priority 100
firewall zone trust
 set priority 85
 add interface GigabitEthernet0/0/0
firewall zone untrust
 set priority 5
 add interface GigabitEthernet0/0/1
firewall zone dmz
 set priority 50
firewall interzone local untrust
 detect ftp
policy interzone local untrust inbound
 policy 1
 action permit
 policy source 192.168.1.2 0
nat-policy interzone trust untrust inbound
 policy 1
 action source-nat
 policy source 9.108.100.0 0.0.0.255
 address-group 2
#
 local-user admin password cipher ]MQ;4\]B+4Z,YWX*NZ55OA
 local-user admin service-type web telnet
 local-user admin level 3
 local-user ftp password simple Admin@123
 local-user ftp service-type ftp
 local-user ftp ftp-directory flash:/
```



```
authentication-scheme default

#
authorization-scheme default

#
accounting-scheme default

#
domain default

#
right-manager server-group

#
rip

#
ip route-static 10.112.0.0 255.255.255.0 9.107.1.1

#
user-interface con 0
user-interface vty 0 4
authentication-mode aaa
user privilege level 3
protocol inbound telnet

#
Return
```

外联路由器,核心交换机配置略。