

```

*****
*
*          STAAD.Pro V8i SELECTseries3          *
*          Version  20.07.08.22                  *
*          Proprietary Program of                 *
*          Bentley Systems, Inc.                  *
*          Date=    NOV 12, 2012                  *
*          Time=    0:53:35                      *
*
*          USER ID: JCUBE ENGINEERING SERVICES PTE L  *
*****

```

```

1. STAAD SPACE
INPUT FILE: 172-PF-01.STD
2. START JOB INFORMATION
3. ENGINEER DATE 06-NOV-12
4. END JOB INFORMATION
5. INPUT WIDTH 79
6. UNIT METER KN
7. JOINT COORDINATES
8. 2 0 2.6 0; 3 1.725 2.6 0; 6 0 2.6 1.85; 7 1.725 0 1.85
9. 8 1.725 2.6 1.85; 9 0 2.6 0.85; 11 -2.6 0 1.85; 12 -2.6 0 0.85; 28 0 2.6 3.698
10. 29 0 2.6 -0.3; 30 1.725 2.6 0.925; 32 0 2.6 0.925
11. MEMBER INCIDENCES
12. 2 3 4; 4 7 8; 5 2 4; 6 6 8; 7 4 30; 8 2 9; 9 9 32; 10 12 9; 11 11 6; 31 6 32
13. 35 6 28; 36 29 2; 37 30 8; 40 32 30
14. DEFINE MATERIAL START
15. ISOTROPIC STEEL
16. E 2.05E+008
17. POISSON 0.3
18. DENSITY 76.8195
19. ALPHA 1.2E-005
20. DAMP 0.03
21. TYPE STEEL
22. STRENGTH FY 253200 FU 407800 RY 1.5 RT 1.2
23. END DEFINE MATERIAL
24. MEMBER PROPERTY BRITISH
25. 2 4 TO 9 31 35 TO 37 40 TABLE ST UC152X152X23
26. 10 11 TABLE ST CH200X75X23
27. CONSTANTS
28. MATERIAL STEEL ALL
29. SUPPORTS
30. 3 7 11 12 28 29 PINNED
31. MEMBER RELEASE
32. 10 11 END MPY 0.99 MPZ 0.99
33. LOAD 1 LOADTYPE DEAD TITLE LOAD CASE 1 SELF WEIGHT
34. SELFWEIGHT Y -1 LIST ALL
35. LOAD 2 LOADTYPE DEAD TITLE LOAD CASE 2 SDL
36. ONEWAY LOAD
37. YRANGE 0 3 ONE -0.75 GY

```

****WARNING** about Floor/OneWay Loads/Weights.**

Please note that depending on the shape of the floor you may have to break up the FLOOR/ONEWAY LOAD into multiple commands. For details please refer to Technical Reference Manual Section 5.32.4 Note 6.

```

38. MEMBER LOAD
39. 10 11 UNI GY -0.375
40. LOAD 3 LOADTYPE LIVE TITLE LOAD CASE 3 LL
41. ONEWAY LOAD
42. YRANGE 0 3 ONE -5 GY
43. MEMBER LOAD
44. 10 11 UNI GY -2
45. LOAD 4 LOADTYPE LIVE TITLE LOAD CASE 4 WL(X)
46. JOINT LOAD
47. 4 8 FX -0.81
48. LOAD 5 LOADTYPE LIVE TITLE LOAD CASE 5 WL(Z)
49. JOINT LOAD
50. 2 4 FZ 0.81
51. LOAD COMB 6 COMBINATION LOAD CASE 6 1.0DL+1.0LL
52. 1 1.0 2 1.0 3 1.0
53. LOAD COMB 7 COMBINATION LOAD CASE 7 1.4DL+1.6LL+WL(X)
54. 1 1.4 2 1.4 3 1.6 4 1.0
55. LOAD COMB 8 COMBINATION LOAD CASE 8 1.0DL+1.4WL(X)
56. 1 1.0 2 1.0 4 1.4
57. LOAD COMB 9 COMBINATION LOAD CASE 9 1.2DL+1.2LL+1.2WL(X)
58. 1 1.2 2 1.2 3 1.2 4 1.2
59. LOAD COMB 10 COMBINATION LOAD CASE 10 1.4DL+1.6LL+WL(Z)
60. 1 1.4 2 1.4 3 1.6 5 1.0
61. LOAD COMB 11 COMBINATION LOAD CASE 11 1.0DL+1.4WL(Z)
62. 1 1.0 2 1.0 5 1.4
63. LOAD COMB 12 COMBINATION LOAD CASE 12 1.2DL+1.2LL+1.2WL(Z)
64. 1 1.2 2 1.2 3 1.2 5 1.2
65. PERFORM ANALYSIS

```

P R O B L E M S T A T I S T I C S

NUMBER OF JOINTS/MEMBER+ELEMENTS/SUPPORTS = 13/ 14/ 6

SOLVER USED IS THE OUT-OF-CORE BASIC SOLVER

ORIGINAL/FINAL BAND-WIDTH= 10/ 4/ 27 DOF
TOTAL PRIMARY LOAD CASES = 5, TOTAL DEGREES OF FREEDOM = 60
SIZE OF STIFFNESS MATRIX = 2 DOUBLE KILO-WORDS
REQRD/AVAIL. DISK SPACE = 12.0/ 271247.9 MB

STAAD SPACE

-- PAGE NO. 3

66. PARAMETER 1
67. CODE BS5950
68. KY 1.5 MEMB 2 4
69. KZ 1.5 MEMB 2 4
70. UNL 1.85 MEMB 7 37
71. UNL 4 MEMB 8 9 31 35 36
72. CHECK CODE ALL

STAAD.Pro CODE CHECKING - (BSI)

PROGRAM CODE REVISION V2.13_5950-1_2000