

HW_ADHERENT_LANECTRL_R1 — Block Diagram

7-lane conveyor motor controller (CAN / USB) · signal flow: right → left · inputs on the right, lane outputs on the left

