Ethernet Local Upgrade SOP

- 1、Firmware upgrade
- (1) Confirm whether the current version is correct through the static web page Static get connection method: computer network port and module network port direct connection;

Static IP: 169.254.173.207

User name: admin Password: admin



- (2) Click the system information screen, if the current display version number is inconsistent, you need to upgrade the firmware;
- 1. Click on System Information
- 2. Check whether the current firmware version number is consistent with the latest firmware, if not, please click Software Upgrade.
- 3. Click Software Upgrade



1. Click on Communication Module Upgrade

- 2. Click to select a file
- 3. Click Start Upgrade
- 4. After the upgrade is complete, check if the firmware version has changed.



