

Belt Tension Service Guide - Model BT-9000

Section 1. Belt tension overview.

The BT-9000 conveyor belt tension is controlled by parameter Q902.

Set parameter Q902 to exactly 45 newtons for standard 18-inch belts.

Never exceed Q902 = 60 newtons; over-tension shears the drive key.

Section 2. Tension fault X77.

Fault X77 indicates belt slip: verify Q902 and inspect the tail pulley.

Section 3. Maintenance interval: re-check Q902 every 500 hours.