

Fault Descriptions

No.	Fault	Description	Action
F004	UnderVoltage 1	DC bus voltage fell below the min value.	Monitor the incoming AC line for low voltage or line power interruption.
F015(3)	Load Loss 2	The output torque current is below the threshold.	Verify connections between motor and load.
F013	Ground Fault 1(2)	A current path to earth ground has been detected.	Check the motor and external wiring.
F000	No Fault —	No fault present.	—
F038	Phase U to Gnd	A phase to ground fault has been detected between the drive and motor in this phase.	Check the wiring between the drive and motor for grounded phase.
F039	Phase V to Gnd		
F040	Phase W to Gnd		Replace drive if fault cannot be cleared.
F081	DSI Comm Loss 2	Communications between the drive and Modbus master have been interrupted.	Modify using C125 [Comm Loss Action].

Basic Program Group Parameters

No.	Parameter	Min/Max	Display/Options	Default
P042	[Decel Time 1] Sets the time for the drive to decel from 0 Hz. (1) When P042 [Decel Time 1] A535[Motor Fdbk Type] is used, this is scaled.	0.00/600.00 s	0.01 s	10.00 s
P031	[Motor NP Volts] Sets the motor nameplate rated volts.	10V (for 200V Drives), 20V (for 400V Drives), 25V (for 600V Drives)/Drive Rated V Volts		Based on Drive Rating

Communications Group

C124 [RS485 Node Addr]

Sets the Modbus drive node number (address) for the RS-485 port.

Default: 100

Values Min/Max: 1/247

Display: 1

C125 [Comm Loss Action] Related Parameters: P045

Sets the drive's response to a loss of connection or excessive communication errors on the RS-485 port.

0 "Fault" (Default)

1 "Coast Stop" Stops drive using "Coast to stop".

Options

2 "Stop" Stops drive using P045 [Stop Mode] setting.

3 "Continu Last" Drive continues at the last commanded speed.

PF40 Fault Descriptions

No.	Fault		Description	Action
F2	Input Fault	①	The remote input interlock is open.	Check remote wiring.
F3	Bus Warning	②	Excessive DC bus voltage ripple.	Check the input line for imbalance.
F5	Phase A Short	②	A short has been detected between two output phases.	Check the motor and drive output wiring for a short.
F6	Phase B Short			
F7	Config Reset		Parameters were reset to defaults.	Clear the fault or cycle power.
F8	Heatsink OverTemp	①	Heatsink temperature exceeds a predefined value.	Check for blocked or dirty fins.
F9	Net Fault	②	The network connection was lost.	1. Check the network wiring. 2. Turn off using A205 [Comm Loss Action].

PF40 Advanced Program Group

A200 [Comm Loss Action] Related Parameters: A201

Selects the drive's response to a loss of the connection.

Options 0 "Fault" (Default) Drive will fault and coast to stop.

1 "Coast Stop" Stops drive via coast to stop.

2 "Stop" Stops drive using A201 setting.

A201 [Comm Loss Time] Related Parameters: A200

Sets the time the drive remains in communication loss.

Values Default: 5.0 Secs

Min/Max: 0.1/60.0 Secs

Display: 0.1 Secs

A299 [Phantom Freq]

Frequency reference curve callout — not a real parameter.