





Lot 3 - Développements

MNGT to LTE-CM Interface

Version 1

Baris DEMIRAY

Baris.Demiray@eurecom.fr / 04 93 00 82 74

Michelle WETTERWALD

Michelle.Wetterwald@eurecom.fr / 04 93 00 81 31



Generic Information

- For all the packets defined herein,
 - Byte-order is Big Endian
 - Packet exchange is done through a UDP socket
 - Unless stated otherwise there is padding for variable-size fields to make entire packet's size multiples of DWORD
 - Reserved fields should be zeroed

Socket Interface

- MGMT listens to the port number 1402 (by default) for incoming UDP data
- This port number may be altered through the configuration file of MGMT (see SCOREF-MGMT_Configuration.pdf)
- LTE-CM shall bind() to a certain port throughout the data exchange, i.e. all the packets should be sent from the same port number

Message Header

- Bit 0: vendor specific or extended message flag (E)
 - Used to indicate that a custom message format is used
 - For vendor specific extension capabilities
- Bit 1: Validity flag (used to indicate of non-existent data)
- Version information (4 bits)
- Priority (Optional, 3 bits)
- Event Type (8 bits)
- Event Subtype (8 bits)

0									1									2									3								
0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7				
E	V	R	R	Version				Priority R R R R R							Eve	ent	Тур	e					Eve	ent	Sub	type	2								

Message type & subtype

Event Type (ET)	Event Sub-type (EST)	Direction	Encoding	Description
ANY			0	Unspecified
	UNSPECIFIED	Unspecified	0	Unspecified
STATE			4	State Event
	WIRELESS_STATE_REQ	GN-CM←MGMT	2	Wireless State Event Request
	WIRELESS_STATE_RES	GN-CM→MGMT	23	Wireless State Event Response

State

Wireless State Request

• It contains only the Header.

0	0								1									2									3								
0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7				
E	V	R	R		Ver	sion	1	Pri	iori	ty	R	R	R	R	R	Event Type							Event Subtype												

Wireless State Response

- The response contains all the Wireless Interfaces
- The message can be unsolicited if major change
- Abbreviations

RSRP: Reference Signal Received Power

RSRQ: Reference Signal Received Quality

QCI: Channel Quality Indication

			()							-	L				2									3							
0	1	2	3	4	5	6 7 0 1 2 3 4 5 6 7										0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	
Е	E V R R Version Priority R R R R												R	Eve	Event Type Event Subtype																	
						lı	nterf	ace II	D							Reserved Reserved																
				Re	fere	nce S	ignal	Rece	eived	Pow	er									Re	ferer	nce S	ignal	Rece	ived	Qua	lity					
Channel Quality Indication Status													Reserved Reserved																			
								•						Pac	ket L	oss R	ate							•								