P_GND

P_+3V

A tactile switch blue

B tactile switch red

P_0

P_3

P_1

P_2

rev 2.0

Assembly Top rev 1.4

USB2

IC4

IC6

MIC1

SPK1

U1

IC1

IC3

LED1

JP1

26

1

2

EXP1

I2C

SERIAL

TAST-A

TAST-B

BAT

TAST_RESET