

First Arduino

- 1. Connect a Servo motor on pin D9.
- 2. Use pushbutton in internal pull-up configuration on pin D5.
- 3. Initiate UART communication between to two Arduinos on pins D2, D3.
- Receive the potentiometer's value on A0 from the second Arduino using the serial communication and use it to position the servo.
- 5. Send the pushbutton's state to the second Arduino to toggle the LED on D12.