

ROS Master

ROS control

Arm Control

arm_joint_state | arm_publish_joints

convert_joint_msg

arm_real_to_sim

Hands Control

get_angle_hands

set_angle_hands

Base Control

base_status

teleop_real_base

send_velocity

Sensors Control

wait_data

read_sensor



