

RoboLift X100 User Manual

Introduction

The RoboLift X100 is an autonomous warehouse robot designed for indoor logistics.

Specifications

Item	Value
Payload	120 kg
Weight	84 kg
Battery	48V Lithium
Runtime	14 Hours
Charging Time	2 Hours

Startup Procedure

1. Press Power button.
 2. Wait until LED turns Green.
 3. Connect to Wi-Fi.
 4. Login to Fleet Manager.
 5. Start navigation.
-

Safety Guidelines

Do not:

- Stand in robot path
 - Remove battery during operation
 - Operate on wet floors
 - Block LiDAR sensor
-

Troubleshooting

Error E101

Battery voltage low.

Solution:
Recharge battery.

Error E205

LiDAR sensor blocked.

Solution:
Clean sensor.

Error E410

Navigation timeout.

Solution:
Restart navigation service.

Maintenance Schedule

Frequency	Task
Daily	Clean sensors
Weekly	Check wheels
Monthly	Battery inspection
Yearly	Full service

Frequently Asked Questions

Q: Maximum payload?

120 kg.

Q: Can it work offline?

Yes.

Q: Does it support OTA updates?

Yes.

Q: Battery replacement interval?

Every 3 years.

Contact

ACME Robotics Support

support@acmerobotics.com

+91-80-1234-5678