

AM-400 Air Grease Gun

Instruction Manual

WARNING

Thank you very much for purchasing this product. Be sure to read this instruction manual before use. Read the items below carefully, understand them, and always observe them. Use the AM-400 air grease gun only in the correct manner. To avoid injury while using the grease gun, follow the safety precautions and rules below.

- Do not use the product for any purpose other than its intended use.
- Do not use it with excessive force, and do not modify it in ways such as extending the handle.
- Wear clothing appropriate for the work. Do not wear loose clothing or jewellery. When using the air grease gun, protective gloves and non-slip footwear are recommended. For operator protection, always use impact-resistant safety glasses, safety goggles and chemical-protection goggles, a face-shield mask, safety shoes, arm protectors, an apron and other protective equipment. If you have long hair, wear a cap.
- Work only in well-lit locations with secure footing.
- Wear a mask — an appropriate mask to avoid inhaling hazardous gases, fumes or vapours.
- Work with full concentration. Refrain from using the grease gun when you are tired or experiencing side-effects of any medication (cold medicine, etc.). Even if you have operated this product hundreds of times, be careful — particularly during monotonous work, over-confidence is extremely dangerous. Used carelessly, or not according to the instructions, it can become a dangerous tool.
- Do not let children or bystanders operate it.
- Before use, confirm that the work site is suitable and that the gun operates properly. Check thoroughly that the connections from the air supply to the grease gun are tight and that there is no damage; if there is nothing abnormal, the grease gun will operate properly. If any part is damaged or could affect its function, repair it or replace the part before use.
- To use the grease gun well and safely, maintain it: inspect and service it regularly, oil it and replace parts. Never repair or disassemble it while it is under pressure.
- Store it out of the reach of children in a dry place.
- Do not modify it. Repairs must be performed only by qualified technicians.
- Regarding grease handling, spraying and disposal, always check the laws and regulations of your region. Dispose of sprayed grease properly — never into street drains, household sewers or backyards. Ask your local waste-management authority about correct disposal. If you have any doubt that the grease gun is in a safe condition, do not use it.

Operating method

This product is designed to operate in the working-pressure range 0.41–1.03 MPa. Lower air pressure reduces the gun's performance; exceeding 1.03 MPa risks damage to parts and personal injury.

Use clean, dry air. Moisture and dust significantly shorten the life of the body. Supply clean, dry air, and add oil.

Drain the moisture that collects in the compressor tank. We recommend fitting a filter / regulator / lubricator, connected close to the grease gun.

Preparation before use

1. Remove the barrel from the gun head (turn it counter-clockwise).
2. Pull the ring and draw the barrel chain all the way out toward you, then hook the chain into the notch in the bottom cap.
3. Unscrew the cap of the bellows grease cartridge and attach the cartridge to the threaded section inside the gun head.
4. Screw the barrel back onto the gun head and release the chain from the notch.
5. Turn the wing lock 1–2 turns counter-clockwise.

OILKEY CORPORATION

Head Office: 4-4-18 Makitsukadai, Minami-ku, Sakai, Osaka 590-0114, Japan Sakai Sales Office: 617 Taiheiji (2F), Nishi-ku, Sakai, Osaka 593-8314, Japan
TEL +81-72-284-1711 FAX +81-72-298-7790 <http://www.oilkey.co.jp> English edition, translated from the original Japanese document.

6. Rotate the grip body to set a comfortable working angle.
7. Tighten the wing lock fully.
8. Before connecting air, add a few drops of oil through the air vent.
9. After connecting air, pull the trigger to start greasing.



Using the air-bleed valve (when an air pocket forms and grease stops discharging):

1. Pull the trigger, then stop.
2. Pressing the top of the valve easily eliminates the air pocket.
3. Repeat this procedure until grease comes out.
4. Pull the trigger (greasing restarts).

Caution

- Air entrainment in the lubricant can stop lever-type grease guns and similar tools from working. Press the air-bleed valve and purge the air thoroughly.
- Always use this product's specified genuine cartridge grease.
- Wipe dirt off the body constantly and take care not to let it slip out of your hands.
- After finishing work, when the product will not be used for a long time, or when carrying it, always disconnect the air supply port and stop the air supply to prevent unintended operation.
- The body cannot be removed unless the air is purged.
- Never run the gun empty — without a cartridge fitted, or after the grease has run out — as this causes piston and other failures.