

that could be encountered by the flight crew. A figure and block number reference for each code tells where to go in the fault isolation diagram to start the actual troubleshooting. All assigned fault code numbers between 3310000 and 3310999 and between 3315000 and 3315099 represent flight station lighting failures, and are subdivided as follows:

SYSTEM/FAILURE	ASSIGNED FAULT CODE RANGE
Dome and thunderstorm lights	3310000 - 3310049, 3310A01, 3310A02
Pilot's instrument panel lights	3310050 - 3310099, 3310B01, 3310B02
Copilot's instrument panel lights	3310100 - 3310149, 3310C01, 3310C02
Engine instrument panel lights	3310150 - 3310199, 3310D01, 3310D02
Overhead panel lights	3310200 - 3310249, 3310E01, 3310E02
Utility and sextant lights	3310250 - 3310299, 3310F01
Dimmer control	3310300 - 3310399, 3310G01, 3310G02
Pilot's side and pedestal lights	3310400 - 3310499, 3310H01, 3310H02
Pilot's circuit breaker panel lights	3310500 - 3310599, 3310J01, 3310J02
Copilot's side and circuit breaker panel lights	3310600 - 3310699, 3310K01, 3310K02
Navigator's lights	3310700 - 3310799, 3310L01, 3310L02
Radio Operator's Station Lights	3310800 - 3310899, 3310M01
MACAWS	3315000 - 3315049, 3315M01
Advance Lighting Control System	3315051 - 3315099, 3315A01

d. Preparation Procedures. Each procedure is contained in a separate figure which uses pictures and words to simplify preparation. When required, preparation procedures must be performed to condition the airplane before starting the actual troubleshooting. Each malfunction and fault code index entry specifies the preparation (if required) to be performed.

e. Fault Isolation Procedures. In order to be brief and concise, fault isolation procedures do not include detailed instructions necessary to gain access to components, to disconnect or connect electrical connectors, or to close panels/covers following troubleshooting. Always back-track through the fault isolation diagram and remove any jumpers, reconnect plugs and hydraulic lines, and reinstall relays, access panels, and other removed components. All maintenance procedures must be properly performed (refer to the applicable Job Guide manual when a problem or question about maintenance procedures arises). The Job Guide manuals also contain replacement procedures to be used when troubleshooting determines the bad component or LRU. Always bring the airplane to a safe condition before replacing specified components. Wiring problems will require the use of TO 1C-130B-2-13, TO 1C-130H-2-13, TO 1C-130(H)H-2-13, TO 1C-130(M)E-2-13, TO 1C-130(M)H-2-13 or TO 1C-130H-2-14.

f. Fault Isolation Diagrams. The fault isolation diagrams follow the preparation procedures (within a section). The fault isolation diagrams are entered at a point designated by the