Engine Oil

Engine oil is the lifeblood of a passenger vehicle. For most gasoline engines manufactured after 2010, the manufacturer recommends changing the oil and filter every 10,000 km or every six months, whichever comes first. Use only the viscosity grade specified in the owner manual, typically 5W-30 or 0W-20 synthetic for modern engines. After draining the old oil and replacing the filter, refill with the exact quantity specified by the manufacturer, usually between 3.5 and 4.5 liters for a four-cylinder engine.

Brake Inspection

Brake pad inspection should be performed at every routine service interval and any time the driver notices unusual noises, vibration, or longer pedal travel. Most modern passenger cars use disc brakes on the front axle. New pads start at approximately 10 to 12 millimeters of friction material; the manufacturer wear limit is typically 3 millimeters. Below 3 millimeters the pads should be replaced as a complete axle set.