

SECTION 1: ULTRABOOK PRO 15 & AIR 13 — USER GUIDE

1.1 KEYBOARD SHORTCUTS (WINDOWS 11)

Win + D → Show/hide desktop
Win + L → Lock screen
Win + E → Open File Explorer
Win + I → Open Settings
Fn + F1 → Mute/unmute audio
Fn + F2/F3 → Volume down/up
Fn + F4 → Mute microphone
Fn + F5 → Toggle keyboard backlight
Fn + F6/F7 → Screen brightness down/up
Fn + F8 → Toggle display output (internal/external/mirror)
Fn + F10 → Toggle touchpad on/off
Fn + F12 → Toggle TechMart AI Assistant
Ctrl + Shift + Esc → Task Manager

1.2 BATTERY CARE & MAINTENANCE

- Best practice: Keep battery between 20% and 80% for daily use to maximize long-term capacity.
- TechMart Battery Health Mode (TechMart PC Toolkit → Battery → Health Mode): Limits charging to 80%.
- Full charge (100%) is fine for travel days when you need maximum runtime.
- Avoid storing the laptop at 0% or 100% for extended periods.
- Expected battery lifespan: 80% capacity after 1,000 charge cycles.
- Battery replacement service available through TechMart Warranty (see warranty policy).

1.3 DISPLAY CARE

- Use a soft, lint-free microfiber cloth to clean the screen. Lightly dampen with water if needed.
- Never use paper towels, abrasive materials, or household cleaners — these can scratch the anti-ref.
- Avoid pressing hard on the screen.

1.4 PORTS & CONNECTIVITY

UltraBook Pro 15:

- USB-A 3.2 Gen 2 (10Gbps, up to 900mA): peripherals, USB drives
- USB-C Thunderbolt 4 (40Gbps, up to 100W PD charging, 8K display output)
- HDMI 2.1 (4K@120Hz or 8K@30Hz external displays)
- SD Card Reader (UHS-II)
- 3.5mm combo headphone/microphone jack

UltraBook Air 13:

- 2× USB-C (USB 3.2 Gen 2, 10Gbps, up to 65W PD charging)
- No built-in HDMI or USB-A: use TechMart USB-C Multiport Adapter (sold separately)
- 3.5mm combo jack

1.5 STORAGE MANAGEMENT

- Check disk usage: Settings → System → Storage
- Free up space: Storage Sense (Settings → System → Storage → Storage Sense)
- External SSD recommended for large media libraries (TechMart-compatible USB-C SSDs available)

- TechMart PC Toolkit → Disk Cleaner for safe junk file removal

1.6 FACTORY RESET (WINDOWS 11)

- Go to Settings → System → Recovery → Reset this PC
- Choose "Keep my files" (reinstalls Windows, removes apps) or "Remove everything" (full reset)
- Full reset takes 1–2 hours. Ensure power is connected.
- All personal data is removed. Backup first via OneDrive, Google Drive, or external drive.

SECTION 2: SMARTPHONE X14 / X14 PRO — USER GUIDE

2.1 CAMERA FEATURES

X14 Camera System:

- Main lens (50MP): Best for everyday shots; tap to focus, swipe to zoom
- Ultrawide (12MP): Switch to 0.6x in camera app; great for landscapes and group shots
- Telephoto (10MP, 3x): Switch to 3x; up to 10x digital zoom

X14 Pro Camera System:

- Main (108MP): full resolution mode via "108MP" toggle in Pro mode
- Periscope telephoto (10x optical): up to 100x Space Zoom
- LiDAR scanner: improves low-light autofocus and AR apps
- Night Mode: auto-activates in low light; increase or decrease exposure using the moon slider
- Pro Video: 4K@60fps main camera, 4K@30fps front camera; LOG video mode for color grading

2.2 GESTURES (ANDROID 14)

- Go home: swipe up from bottom
- Go back: swipe in from left or right edge
- Recents: swipe up from bottom, hold
- Quick Settings: swipe down from top-right corner
- Notification shade: swipe down from top-left corner
- Split screen: hold Recent button → select "Split screen" → choose second app
- One-Hand Mode: swipe down on bottom of screen (enable in Settings → Advanced Features)

2.3 S-PEN (X14 PRO ONLY)

- Remove S-Pen from bottom slot; screen auto-opens Air Command menu
- Air Actions: hold S-Pen button and gesture to control camera, media, presentation slides
- Samsung Notes integration for handwritten notes
- Bluetooth enabled; charge by inserting into device (30 seconds = 30 minutes use)

2.4 DEX DESKTOP MODE (X14 PRO ONLY)

- Connect phone to monitor via USB-C or wirelessly to a TechMart HomeHub or compatible TV
- DeX mode transforms the phone into a desktop-like interface
- Use Bluetooth keyboard and mouse for full desktop experience
- Access all Android apps in resizable windows

2.5 DIGITAL WELLBEING

- Settings → Digital Wellbeing & Parental Controls
- App timers: set daily limits per app
- Focus Mode: pause distracting apps during work/sleep
- Bedtime Mode: grayscale display and DND during set sleep hours
- Screen Time dashboard: see daily and weekly usage reports

2.6 FACTORY RESET (ANDROID)

- Backup data first (Settings → Google → Backup)
- Settings → General Management → Reset → Factory Data Reset
- Confirm with PIN. Process takes 5–10 minutes.
- Remove Google account before factory reset if selling/giving away device to prevent FRP lock.

SECTION 3: TABPRO 11 — USER GUIDE

3.1 PRODUCTIVITY FEATURES

- Split screen: open an app, hold Recent button, choose "Open in Split Screen View," select second
- Pop-up view: hover an app in Recents, select "Open in Pop-up View" for floating window
- TechMart Notes (pre-installed): handwriting with Stylus Pro 2, convert handwriting to text
- Samsung DeX available via USB-C (same as X14 Pro)

3.2 STYLUS PRO 2 PRESSURE & TILT

- 4,096 pressure levels: adjust brush size in drawing apps by pressing harder or lighter
- Tilt support: tilt stylus at an angle to shade like a pencil in art apps
- Latency: 2.8ms panel response (TechMart proprietary low-latency screen)

3.3 PARENTAL CONTROLS (FOR KIDS)

- Settings → Digital Wellbeing → Parental Controls → Set Up
- Use Family Link to monitor and control apps, screen time, and location (Android)

SECTION 4: SMARTWATCH SERIES 3 — FEATURES

4.1 HEALTH TRACKING FEATURES

- Heart Rate: continuous 24/7 monitoring; alerts for abnormally high (>120 bpm at rest) or low (<5
- SpO2: automatic overnight; manual reading anytime from Health tile
- ECG: 30-second single-lead ECG; store results in TechMart Health app; share PDF with doctor
- Stress: measured every hour via heart rate variability (HRV); breathing exercises if high stress
- Sleep: automatic detection; tracks light, deep, REM sleep; sleep score in morning
- Temperature: continuous skin temp monitoring; deviation alerts

4.2 WORKOUT MODES (90+ SUPPORTED)

- Auto-detect: watch detects walk, run, swim, cycling automatically after 10 minutes
- Manual: press Crown, scroll to Workout, choose from 90+ modes
- Route tracking: GPS for outdoor runs, walks, hikes, cycling
- Swim: waterproof to 5ATM; tracks laps, strokes, SWOLF score

4.3 SAFETY FEATURES

- Fall Detection: detects hard falls; starts 60-second countdown; auto-calls emergency contact if
- Crash Detection: similar to fall detection but tuned for vehicle impacts
- Emergency SOS: press and hold Crown for 3 seconds → calls emergency services and notifies contact
- Location sharing: share real-time GPS location with emergency contacts via TechMart Watch app

4.4 WATCH FACE & CUSTOMIZATION

- Press and hold watch face → Customize → choose from TechMart Gallery or design custom face
- Change band: press both band release buttons (sides of case) and slide out; slide in new 22mm band

- Compatible bands: TechMart official bands and standard 22mm third-party bands

SECTION 5: EARBUDS PRO — CARE & MAINTENANCE

5.1 CLEANING

- Earbuds: use dry cotton swab to clean speaker mesh and sensors. Never use liquid directly on ear
- Case: wipe with dry microfiber cloth. For charging contacts, use dry cotton swab.
- Ear tips: remove and wash with mild soapy water; dry fully before reattaching.
- Frequency: clean weekly for heavy users.

5.2 EAR TIP FIT

- Proper fit is essential for optimal ANC and bass response.
- The right ear tip creates a light seal in the ear canal — not a deep insert.
- Test: put earbuds in, play music; hold hand over right earbud — if bass noticeably increases, th
- Sizes included: XS, S, M (pre-installed), L, XL.

5.3 FIRMWARE UPDATES

- Updates via TechMart Audio app (Android/iOS) → Earbuds → Check for Updates
- Keep earbuds in case during update; ensure case is at least 30% charged.

SECTION 6: GENERAL SAFETY INFORMATION

6.1 BATTERY SAFETY

- Do not disassemble, crush, puncture, or expose any TechMart device to fire or extreme heat.
- If a battery swells (visible bulge), stop using immediately, do not charge, and contact TechMart
- Do not use third-party chargers with unapproved wattage — risk of overheating or battery damage.
- Charge in well-ventilated areas; do not charge under pillows or blankets.

6.2 ELECTROMAGNETIC INTERFERENCE

- Keep TechMart devices at least 15cm from pacemakers. Consult a physician if you have a pacemaker
- Power off devices on aircraft unless airline explicitly permits Airplane Mode use.
- SmartWatch: not suitable for use near MRI machines; remove before any MRI examination.

6.3 ERGONOMICS

- Laptops: use at eye level on a desk. Use an external keyboard and mouse if laptop is raised.
- Smartphones and tablets: take breaks every 30 minutes to reduce eye strain and repetitive strain
- Earbuds: keep volume below 85dB for prolonged use. The TechMart Audio app shows volume level in
- TechMart devices support EU Volume Limitation at 85dB for European users.

6.4 OPERATING ENVIRONMENT

- Storage temperature: -20°C to 45°C (-4°F to 113°F)
- Operating temperature: 0°C to 35°C (32°F to 95°F)
- Humidity: 5%–95% non-condensing
- Altitude: Up to 5,000m (16,400 ft)

SECTION 7: CONTACTING SUPPORT

All TechMart product documentation is available at: www.techmartelectronics.com/support
Download TechMart PC Toolkit: www.techmartelectronics.com/downloads

TechMart Audio App: Search "TechMart Audio" on Google Play or App Store
TechMart Watch App: Search "TechMart Watch" on Google Play or App Store
TechMart Home App: Search "TechMart Home" on Google Play or App Store

Support: 1-800-TECHMART | support@techmartelectronics.com
Hours: Mon–Fri 8AM–9PM EST; Sat–Sun 9AM–6PM EST