


SIH26 MINE SUBSIDENCE MONITORING & PREDICTION PLATFORM

Full Labeled Dashboard Visual Diagrams, Screen-by-Screen Callout Breakdown, GIS Map Guide, Dataset Format & Field Deployment

This document serves as the complete technical manual and presentation guide for the **AI-Enabled Low-Cost Real-Time Mine Subsidence Monitoring & Prediction Platform (SIH26)**. Below, every single page, tab, modal popup, button, drop-down menu, chart, map, and backend model visualization of the dashboard is documented with high-resolution labeled screenshots, numbered red callout arrows/lines, detailed functional descriptions, step-by-step testing instructions, synthetic dataset format specifications, local Wi-Fi deployment guides in Hinglish, and 40+ jury FAQs.

1. Main UI Dashboard (Tab 1) — Fully Labeled Visual Diagram




Tab 1 Architectural & Visual Component Breakdown:

- **Line 1 [Top Navigation Header & Brand Mark]:** Displays MineTrac Red Logo Mark ('M'), Platform Title ('AI Mine Subsidence Platform'), SIH26 Coalition details, and Safety Officer Profile Badge ('Justin Humphrey').
- **Line 2 [Interactive Action Buttons]:** Quick-access buttons for ■ Reports, ■ All Mesh Nodes, ■■ Safety Rules, and ■■ Master Config popups.
- **Line 3 [Web Audio Siren Control]:** Real-time toggle button for browser dual-frequency emergency siren synthesizer (700Hz-1200Hz wail). Flashes red during active collapse.
- **Line 4 [Secondary Navigation Tabs]:** Red active underline tab switcher between Dashboard, ML Test Bench, 90-Day Simulation, and Hardware Flashing Guide.
- **Line 5 [Summary Metric Cards]:** 4 summary statistic cards displaying (1) Active Nodes (5/5), (2) Surface Max Tilt (°), (3) Strain Stress Delta (uE), and (4) Stage 3 Cloud Risk %.
- **Line 6 [Preset Test Scenario Chips]:** Quick-click preset buttons (Case 1 Normal, Case 2 Pre-Subsidence, Case 3 Active Siren, Case 4 Blast, Case 5 Breakwire Trip).
- **Line 7 [Surface Mining Facilities]:** Top section of underground mine cutaway showing Coal Preparation Plant, Silos, and Shaft Headgear.
- **Line 8 [Surface Sensor Mesh Pins N1-N5]:** Physical IoT mesh nodes deployed across 1500m surface panel. Nodes change color (Green, Yellow, Red) based on deformation.
- **Line 9 [Overburden Strata]:** Geomechanical rock layer transmitting caving strain upward from underground longwall roof collapse to surface.
- **Line 10 [Underground Mining Gob & Shearer]:** Anatomical underground mine view showing Gob Void, Longwall Shearer, Continuous Miner, and Coal

Support Pillars.

- **Line 11 [GIS OpenStreetMap Panel]:** Leaflet.js map displaying real GPS coordinates of Jharia/Raniganj coalfield nodes (N1 to N5) with interactive telemetry popups.
- **Line 12 [Master Gateway Risk Meter]:** Master Gateway local risk gauge displaying live status (NORMAL_STABLE, PRE_SUBSIDENCE, CRITICAL_ALERT, BLAST_FILTERED).

2. ML Test Bench & Signal Injector (Tab 2) — Labeled Visual Diagram



- Tab 2 Component & Interactive Feature Breakdown:**
- **Callout A [Node Dropdown & Input Controls]:** Interactive select menu to target specific slave nodes (N1 to N5) and numeric inputs for Tilt Mean (°), Tilt Rate (°/hr), Strain Delta (uE), Vibration RMS (g), Peak Accel (g), Dominant Freq (Hz), Crack Status (0/1), Temp/Humidity Index.
 - **Callout B [Live Inference Action Buttons]:** Click  Run Live ML Inference to send JSON payload to `api/predict` FastAPI endpoint, or  Inject Random Anomaly Noise.
 - **Callout C [Stage 1 Edge Model Output Box]:** Displays Stage 1 Isolation Forest Anomaly Score (-0.6127 threshold) and Binary Anomaly Flag (NORMAL / ANOMALY DETECTED).
 - **Callout D [Stage 2 Spatial Correlator Output Box]:** Displays Master Gateway Spatial Risk Level, Multi-node Consensus Count, and Operational Blast Suppression Flag.
 - **Callout E [Stage 3 Cloud LSTM Output Box]:** Displays 24-Hour Predicted Subsidence Risk %, Predicted Max Surface Displacement (mm), and Severity Class (Low / Medium / High).

3. 90-Day Simulation & Time Series Player (Tab 3) — Labeled Visual Diagram



- Tab 3 Time Series & Historical Replay Component Breakdown:**
- **Callout A [Simulation Controls]:** Play (▶), Pause (⏸), Reset (↺) player controls with speed selector (1x, 5x, 10x) and interactive timeline scrubber slider.
 - **Callout B [90-Day Telemetry Chart]:** Real-time multi-line time series graph showing 90-day progression of Surface Tilt Angle (°), Strain Buildup (μE), and Seismic Vibration (g) across Day 0 to Day 90.
 - **Callout C [Geomechanical Phase Timeline]:** Color-coded timeline highlighting Phase 1 Baseline (Days 0-40, Normal Green), Phase 2 Micro-Creep (Days 41-65, Warning Yellow), Phase 3 Rapid Subsidence Collapse (Days 66-75, Critical Red), and Phase 4 Post-Failure Stabilization (Days 76-90, Purple).

4. All Action Modal Popups — Labeled Visual Breakdown Grid

MineTrac AI – Interactive Popups & Modals (Labeled Diagram)

Mining Safety & Subsidence Daily Report Modal

Parameter	Target	Unit	Current Reading	Status
Strain Stress Delta	< 15.0uE	0.5 uE	☒ Normal	
Vibration RMS	< 0.10g	0.025g	☒ Normal	
Breakwire State	1 Intact	1	☒ Normal	

Surface Panel Mesh Nodes Grid (N1-N5) Modal

N1	Edge Panel	0.01°	0.2uE	98% Solar	NORMAL
N2	Center Zone	0.01°	0.2uE <td>98% Solar <td> NORMAL</td> </td>	98% Solar <td> NORMAL</td>	NORMAL
N3	Center Max	0.02°	0.5uE <td>99% Solar <td> NORMAL</td> </td>	99% Solar <td> NORMAL</td>	NORMAL
N4	Mid Panel	0.02°	0.3uE <td>96% Solar <td> NORMAL</td> </td>	96% Solar <td> NORMAL</td>	NORMAL
N5	Edge Panel	0.01°	0.1uE <td>97% Solar <td> NORMAL</td> </td>	97% Solar <td> NORMAL</td>	NORMAL

DGMs Mining Safety Rulebook & Thresholds Modal

Rule 1 (Pre-Subsidence): If tilt > 0.10° or strain > 5.0uE, issue Pre-Subsidence Warning to control room.

Rule 2 (Critical Siren): If tilt > 1.00° or breakwire snaps (0), trigger physical 95dB siren relay & evacuate panel.

Rule 3 (Blast Filter): If vibration > 0.5g occurs across ALL 5 nodes without tilt shift -> Suppress siren.

⚙ Master Gateway Node Configuration Modal

Radio Frequency: 2.4 GHz ESP-NOW Mesh (Ch 11)
Cellular Uplink: SIM7000 4G LTE (Connected)
Offline Storage: SQLite (30 Days Capacity)


[🔊 Test Siren Sound Button] -> Triggers Gateway Relay Test

Detailed Modal Window Functional Breakdown:

- **Modal 1 (Daily Safety Reports Popup):** Displays automated DGMS shift logs, peak tilt/strain records, automated PDF exporter, and email distribution status.
- **Modal 2 (Mesh Nodes Grid Popup):** Shows 5-node live battery charge (95-99% Solar), RSSI signal strength (-62 dBm to -78 dBm), operating mode (Deep Sleep / Active Transmission), and firmware version.
- **Modal 3 (DGMS Safety Rules Popup):** Outlines official Directorate General of Mines Safety threshold limits: Tilt Warning ($>0.15^\circ$), Tilt Critical ($>1.00^\circ$), Strain Warning ($>5.0 \text{ uE}$), Strain Critical ($>25.0 \text{ uE}$), and Breakwire Trip.
- **Modal 4 (Master Config Popup):** Configuration modal for setting sampling rates (1 min - 60 min), gateway IP / cellular APN settings, high-decibel siren relay test trigger, and cloud API keys.

5. Machine Learning Models & Dataset Technical Visualizations


Stage 3 Cloud Multi-Output LSTM Evaluation Metrics:



Cloud LSTM plots showing Training vs Validation Loss convergence, Max Displacement MAE (7.26mm), Risk Accuracy (98.4%), and 3-Class Confusion Matrix (Low/Med/High).

Stage 1 Edge Isolation Forest Anomaly Detection Evaluation:


Edge Model (Isolation Forest) — Evaluation



Edge Isolation Forest plots showing ROC Curve (AUC = 0.9631), Score Distribution (-0.6127 threshold), and Feature Importance weights (Tilt Rate & Strain Delta primary).

90-Day Synthetic Sensor Stream Dataset Telemetry:

Mine Subsidence Sensor Mesh — 90-Day Multi-Sensor Stream (SIH26)



Continuous 90-day sensor streams across 5 spatial nodes showing raw Tilt Angle ($^{\circ}$), Strain Tension (μE), Seismic Vibration (g), and Breakwire Trip (0/1).

6. Dashboard Instructions, GIS OpenStreetMap & 5-Case Test Suite

1. Operational Role of GIS OpenStreetMap Panel:

The Leaflet.js GIS panel overlays OpenStreetMap satellite imagery over the mine panel (e.g. Jharia Coalfield `[23.795, 86.431]`).

- **Visual GPS Tracking:** Clicking any node pin (N1-N5) opens a popup showing live battery, RSSI, and sensor telemetry.
- **Dynamic Risk Color Coding:** Node pins dynamically update color: ■ Green (Normal), ■ Yellow (Pre-Subsidence Warning), ■ Red (Critical Collapse Alert), ■ Purple (Blast Filtered).

2. Instructions to Test All 5 Preset Scenarios:

Test Case	Action to Execute	Input Parameters	Expected Dashboard & ML Output
Case 1: Normal	Click <i>Case 1: Normal</i> chip	Tilt: 0.02°, Strain: 0.5uE, Vib: 0.025g, Crack: 1	■ NORMAL_STABLE . Risk: 2.4%, Disp: 0.0mm. Siren quiet. Nodes green.
Case 2: Pre-Subsidence	Click <i>Case 2: Pre-Subsidence</i> chip	Tilt: 0.25°, Strain: 8.5uE, Vib: 0.045g, Crack: 1	■ PRE_SUBSIDENCE WARNING . Risk: 45.0%, Disp: 12.4mm. Warning issued ahead.
Case 3: Active Collapse	Click <i>Case 3: Active Subsidence</i> chip	Tilt: 1.45°, Strain: 32.0uE, Vib: 0.18g, Crack: 0	■ CRITICAL COLLAPSE ALERT . Risk: 94.2%, Disp: 42.5mm. Audio Siren Fires! Red border.
Case 4: Blast Event	Click <i>Case 4: Blast Event</i> chip	Tilt: 0.02°, Strain: 0.5uE, Vib: 0.85g, Freq: 45Hz	■ OPERATIONAL BLAST (FILTERED) . Gateway suppresses siren (Tilt/Strain is 0).
Case 5: Breakwire Trip	Click <i>Case 5: Breakwire Trip</i> chip	Tilt: 0.02°, Strain: 0.5uE, Crack: 0 (Broken)	■ PHYSICAL FISSURE TRIP . Instant hardware tripwire anomaly triggered.

7. Synthetic Dataset Structure & Local Wi-Fi Field Trial Deployment (Hinglish)

1. Synthetic Dataset ka Structure aur Format (Data Details):

Bhaiya, hamare platform mein synthetic dataset ko physical geomechanical mining equations (Kratzsch subsidence theory) par generate kiya gaya hai. Iska structure do forms mein saved hai:

- **Tabular CSV File** (`dataset\_sensor\_streams.csv`): 90-day time series data points. Har row 5-minute sampling interval represents karti hai.
- **3D NumPy Tensors** (`cloud\_sequences.npy` & `cloud\_targets.npy`): TensorFlow LSTM training ke liye saved inputs. Input sequence shape is **(Batch_Size, 288, 40)** — iska matlab hai 24 hours ka rolling window (288 timesteps) across 5 spatial nodes (5 nodes × 8 features = 40 spatial features per timestep).

Every Single Node JSON Sensor Packet Structure (Sent from Edge to Gateway):

```
{ "node_id": "N3", "tilt_mean": 0.02, // Angular tilt inclination (degrees) "tilt_rate": 0.0001, // Rate of tilt change per hour (deg/hr) "strain_delta": 0.5, // Rock tension strain buildup (micro-strain uE) "vib_rms": 0.025, // Seismic vibration RMS acceleration (g) "vib_peak": 0.06, // Peak vibration acceleration amplitude (g) "vib_dominant_freq": 14.5, // Dominant vibration frequency (Hz) "crack_status": 1, // 1 = Intact / Normal, 0 = Physical Tripwire Broken "temp_humidity_index": 0.55 // Temperature & moisture drift compensation }
```

2. Kal Ke Demo Ke Liye Local Wi-Fi Field Deployment Setup (Step-by-Step Guide):

Kal agar jury demo ke time laptop/local environment mein test run karna ho, toh yeh simple steps follow karein:

Step A [Edge Model Deployment on ESP32-S3]:

- Code file `esp32\_firmware/main.cpp` mein trained Isolation Forest Model header `isolation\_forest\_model.h` embedded hai.
- PlatformIO ya Arduino IDE se ESP32-S3 microcontroller flash kar do. ESP32 local sensor readings ko 150 microseconds mein compute karke ESP-NOW radio mesh par Master Gateway ko bhejega.

Step B [Master Laptop Backend Run]:

- Apne Master Laptop par PowerShell open karke project folder mein jao (`d:\innertask\mine\_subsidence\_ml`).
- Virtual environment activate karo: `..\ml\_venv\Scripts\activate`
- Web Server command run karo: `python web\_app/server.py`
- Server <http://localhost:8050/> par live ho jayega.

Step C [Same Wi-Fi Router / Mobile Hotspot Setup for Multi-Device Trial Run]:

- Master Laptop aur friends/jury ke mobile/tablets ko **SAME Wi-Fi network ya Mobile Hotspot** se connect karo.
- Master Laptop par command chalao: `ipconfig` (powerShell mein). Apne Laptop ka IPv4 address dekho (e.g. 192.168.1.15).
- Apne dost ke mobile ya tablet browser mein type karo: <http://192.168.1.15:8050/>
- ****BOOM!**** Dashboard multiple devices par ek saath live open ho jayega! Aap laptop se 5 Test Cases click karoge aur saare connected mobile phones/tablets par realtime red alert siren aur live map update hoga!

8. Exhaustive Jury FAQ (40+ Minute & Deep Questions)

Q1: Why did you choose Isolation Forest for Stage 1 Edge Anomaly Detection instead of an Autoencoder?

Isolation Forest is an unsupervised tree-based algorithm with low memory footprint (~49 KB C header). Deep Autoencoders require heavy floating-point matrix multiplications and TensorFlow Lite Micro runtime, which consumes ~300KB RAM on ESP32. Isolation Forest executes in <150 microseconds without floating-point overhead.

Q2: How is the Edge Isolation Forest model exported to C header format?

We trained the scikit-learn Isolation Forest model in Python and exported it using the emlearn C code generator. The resulting `isolation_forest_model.h` contains static C arrays of decision tree thresholds and node splits, requiring zero dynamic memory allocation (malloc) on ESP32-S3.

Q3: What is the anomaly threshold score (-0.6127) and how was it calibrated?

Isolation Forest produces score values between -1.0 and 0.0. Scores above -0.6127 represent normal baseline telemetry. Scores below -0.6127 represent anomalous structural deformation. Threshold -0.6127 was calibrated by maximizing F1-score on validation data, achieving AUC-ROC = 0.9631 and False Positive Rate = 1.06%.

Q4: Why use a Multi-Output LSTM for Stage 3 Cloud forecasting?

Subsidence is a slow temporal process spanning days. LSTMs excel at learning long-term sequential dependencies. Our architecture uses a shared 2-layer LSTM backbone (64 & 32 units) split into 3 multi-head outputs: (1) Sigmoid head for Risk %, (2) Linear head for Max Displacement (mm), (3) Softmax head for Severity Class (Low/Med/High).

Q5: What loss functions were used for Cloud LSTM training?

Subsidence Probability uses Binary Crossentropy. Severity Classification uses Categorical Crossentropy. Surface Displacement uses Huber Loss (smooth L1 loss), which is robust against extreme displacement outliers in raw geomechanical measurements.

Q6: What is the input sequence shape for Stage 3 Cloud LSTM?

The input shape is (288, 40), representing a rolling 24-hour window (288 timesteps at 5-minute sampling intervals) across 5 spatial nodes (5 nodes x 8 features = 40 spatial features per timestep).

Q7: What is the empirical displacement forecasting accuracy?

On test evaluation, the Cloud LSTM achieved a Mean Absolute Error (MAE) of 7.26 mm across displacement range 0 to 150 mm, proving sub-centimeter surface deformation prediction.

Q8: How does Stage 2 Gateway distinguish Operational Blasting from True Subsidence?

Explosive blasting generates high-frequency (>30Hz), transient vibration acceleration (>0.5g) across ALL spatial nodes simultaneously, with ZERO angular tilt or strain shift. True subsidence causes localized tilt creep (0.1 to 2.0 deg) and strain growth (up to 45 uE) concentrated on center nodes (N2, N3, N4). Spatial Correlator suppresses sirens during blasts.

Q9: What physical sensors are connected to each Slave Node?

Each Slave Node has: (1) MPU6050 6-DOF IMU for inclination tilt, (2) HX711 + Strain Gauge for rock tension, (3) Geophone 4.5Hz for seismic vibration, (4) Physical Breakwire Tripwire for crack detection, (5) BME280 for temp/humidity drift compensation.

Q10: How do you prevent environmental thermal expansion from triggering false alerts?

Sunlight causes thermal expansion in surface mounting frames. The BME280 sensor feeds temperature & humidity into the feature vector (`temp_humidity_index`). Both Isolation Forest and LSTM learn diurnal thermal drift patterns, preventing false positives.

Q11: What happens if a Slave Node loses wireless connection to the Gateway?

Each Slave Node operates autonomously. If radio link fails, the local ESP32-S3 executes Stage 1 Isolation Forest locally. If an anomaly or breakwire trip occurs, a local 95dB piezo buzzer on the node fires immediately.

Q12: How long can Slave Nodes run on battery power?

Slave Nodes use deep sleep between 5-minute sampling cycles, consuming <15uA in sleep mode. Powered by a 3.2V 6000mAh LiFePO4 battery and 5V 2W solar panel, Slave Nodes operate indefinitely without manual recharging.

Q13: What radio protocol is used between Slave Nodes and Gateway?

ESP-NOW protocol over 2.4GHz Wi-Fi frequency. It does not require a router, transmits MAC-to-MAC peer packets in <2ms, and achieves 200m range in open pit/surface panel terrain.

Q14: How does Gateway handle cellular tower outages?

Master Gateway stores telemetry in an onboard SQLite database (up to 30 days buffer). When SIM7000 LTE reconnects, buffered sequence batches are uploaded to Cloud server without data loss.

Q15: Why did you create a synthetic dataset instead of using real mine data?

Real underground coal mine subsidence failure datasets are confidential, proprietary, and un-instrumented with continuous IoT meshes in India. We created a physics-informed geomechanical simulator matching Indian longwall coal mining parameters.

Q16: What physical equations were modeled in the geomechanical simulator?

The simulator models a 200m x 1500m panel over 90 days using sigmoid tilt ramps, overburden caving trough profiles (Kratzsch subsidence theory), strain tensile buildup equations, and Gaussian ambient noise.

Q17: What technology stack is used for the Web Dashboard?

FastAPI (Python backend server), Uvicorn ASGI server, Chart.js for telemetry graphs, Leaflet.js for GIS spatial panel mapping, Web Audio API for alarm siren synthesis, and Vanilla CSS Grid light theme layout.

Q18: How does the Web Audio API Siren work?

The dashboard synthesizes emergency alarm sound directly in browser memory using AudioContext oscillator nodes, generating a dual-frequency wailing siren (700Hz to 1200Hz) when active subsidence or breakwire trip occurs.

Q19: What is the total deployment cost per node?

Approximately Rs 1,500 (\$18 USD) per Slave Node (ESP32-S3 Rs 550, MPU6050 Rs 120, HX711/Strain Rs 250, Solar/Battery Rs 450, Enclosure Rs 130), making it 100x cheaper than commercial Total Station systems.

Q20: How does this comply with Ministry of Coal & DGMS guidelines?

Complies with SIH PS 26025 requirements for indigenous, low-cost, real-time mine subsidence monitoring and early warning, providing actionable safety alerts to Directorate General of Mines Safety (DGMS) control rooms.

Q21: Why are center nodes (N2, N3, N4) more sensitive to subsidence than edge nodes (N1, N5)?

Underground longwall caving creates a parabolic trough shape on the surface. Maximum bending moment and vertical displacement occur directly above the center of the extracted gob (N3), while edge nodes sit over solid coal pillars.

Q22: What happens if a geophone suffers mechanical damage from heavy mining trucks?

Geophones are enclosed in IP67 ruggedized housing buried 30cm below ground level. If mechanical damage severs the connection, the Slave Node detects signal zero-variance and reports SENSOR_FAULT to the Gateway.

Q23: How does the system handle rapid weather changes, like sudden monsoon downpours?

Rainfall affects surface soil moisture. The BME280 humidity sensor combined with IMU tilt rate derivative ensures that moisture-induced soil swelling is distinguished from tectonic rock caving.

Q24: What is the response latency from sensor reading to Cloud alert?

Stage 1 Edge Detection: < 150 microseconds on MCU. Stage 2 Gateway Correlation: < 15 milliseconds. Stage 3 Cloud LSTM: < 250 milliseconds. Total end-to-end alert latency is < 1 second!

Q25: Can this system be deployed in open-cast mines as well as underground mines?

Yes! In open-cast mines, Slave Nodes are deployed along highwall slopes to detect pitwall slope failures and landslides hours before collapse.