Left

LS1
SPH18R1LM4H-1-8
MIC_DATA
DATA
SELECT
VDD
CLOCK
GROUND
MIC_CLOCK
C9
0.1uF
VDD
GND

J1
USB_C_Receptacle_USB2.0_16P
VBUS
CC1
CC2
R2
R3
5K1R
GND
D-
D+
SBU1
SBU2
SHIELD
S1

NRF5340-QKAA-R
U3C
P1.15
P1.14
P1.13
P1.12
P1.11
P1.10
P1.09
P1.08
P1.07
P1.06
P1.05
P1.04
P1.03/TWI
P1.02/TWI
P1.01
P1.00
SDOUT
LRCLK
SCK

+BATT
+3.3V
BT1
Battery_Cell

U4
NPM1100-CAAA-R
VBAT
VBUS
VSYS
VOUTB
SW
DEC
ERR
CHG
ICHG
NTC
MODE
ISET
VTERMSET
VOUTBSET0
VOUTBSET1
SHPHLD
SHPACT
AVSS
PVSS
C21
4.7uF
C26
10uF
C27
10uF
C28
10uF
L5
2.2uH
D1
D2
LED
R11
R12
1K5R
R5
R6
10K
5K1R

U3A
NRF5340-QKAA-R
VDD
DCCR
DECR
DECRF
DCCD
DECD
DCCH
VDDH
VSS
C12
C13
C15
C17
C19
L3
L4
10uH
1uF
2.2nF
C30
C33
C35
C37
C31
C34
C36
C38
100nF

J3
UART
TX
RX

J4
Prog
SWDIO
SWDCLK
nRESET

U3D
NRF5340-QKAA-R
XC2
XC1
ANT
nRESET
SWDCLK
SWDIO
D-
D+
C7
C8
12pF
Y1
32MHz
L2
2.2nH
C3
N.M.
C6
0.7pF
Antenna_Shield
AE1
C4
C5
L1
N.M.

U1
BMA400
SDO
SDX
VDDIO
NC
INT1
INT2
SCX
NC
CSB
GND
GNDIO
VDD
I2C_SDA
I2C_SCL
C1
C10
100nF

U2
MPR121QR2
*IRQ
SCL
SDA
ADDR
VREG
VSS
REXT
ELE0
ELE1
ELE2
HTAB
ELE11
ELE10
ELE9
ELE8
ELE7
ELE6
ELE5
ELE4
ELE3
C2
C11
R1
75k
Touch Pads
J2

U3B
NRF5340-QKAA-R
Y2
32.768kHz
R9
R10
4k7
P0.00/XL1
P0.01/XL2
P0.02/NFC1
P0.03/NFC2
P0.04/AIN0
P0.05/AIN1
P0.06/AIN2
P0.07/AIN3
P0.08/TRACEDATA3/SCK
P0.09/TRACEDATA2/MOSI
P0.10/TRACEDATA1/MISO
P0.11/TRACEDATA0/CSN
P0.12/TRACECLK/DCX
P0.13/IO0
P0.14/IO1
P0.15/IO2
P0.16/IO3
P0.17/SCK
P0.18/CSN
P0.19
P0.20
P0.21
P0.22
P0.23
P0.24
P0.25/AIN4
P0.26/AIN5
P0.27/AIN6
P0.28/AIN7
P0.29
P0.30
P0.31
High-impedance input
SD_MODE
ISET
MIC_DATA
MIC_CLOCK

Speaker & Amplifier

12db gain connected to GND
15db gain connected with 100kohm
9db gain leave open

U5
MAX98357AEWL_T
SCK
SDOUT
N.C.
LRCLK
SD_MODE
BCLK
DIN
GAIN_SLOT
LRCLK
SD_MODE
VDD
OUTN
OUTP
GND
R7
680R
R33
LS2
Boneconduction
LS3
Boneconduction
LEFT CHANNEL SELECTED

ON - MCU SD pin input (High impedance)
OFF - MCU SD pin output (LOW)

12db gain connected to GND
15db gain connected with 100kohm
9db gain leave open

U6
MAX98357AEWL_T
R8
680R
R34
LS4
Boneconduction
LS5
Boneconduction
RIGHT CHANNEL SELECTED

Logic Level Shifter Programing

J6
High-V
J8
Low-V
J9
Low-V-TH
R14
R16
R22
R24
R18
R19
R15
R17
R23
R25
1K5
1K8
C42
C50
C49
C45
C51
30pF

Sheet: /
File: untitled.kicad_sch
Title:
Size: A3
Date:
Rev:
KiCad E.D.A. 9.0.7
Id: 1/1