

- Power on datalogger and MiFi router
- 2. Mount sensor on magnetic foot.
- 3. Point sensor onto moving object that should define uptime/unit counter
- 4. Adjust length of measure by turning sensor screw




- 2. Digital port 2 (D2)
- 3. Ethernet port
- 4. Power



WIFI through MiFi
Default
SSID: Optilink Pass: Optipeople

Number next to WIFI icon indicates that a device is connected to the router.

Within 10min it connects to the database as well.



portal.optipeople.dk

- 1. Create customer account
- 2. Create factory
- 3. Add device
- 4. Add machine
- 5. Configure machine
- 6. Configure shifts
- 7. Configure Waste

User Manual



