

OEM-HX-01 — Shell & Tube Heat Exchanger — Maintenance Manual

Plant: Shakti Petrochem Unit-2 | **Equipment Type:** Heat Exchanger | **Asset:** HX-102

Fouling & Cleaning

A rising outlet temperature at constant duty indicates tube-side fouling.

Recommended cleaning interval: 6 months, or when outlet temperature rises 8 degC above baseline.

Inspection

Inspect tube bundle for scaling and pitting at each turnaround.