

SOP-17 — Centrifugal Pump Maintenance

Plant: Shakti Petrochem Unit-2 | **Applies To:** Boiler Feed Pump | **Revision:** Rev 4 | **Last Reviewed:** 2024-01-10

Procedure Steps

1. Isolate and lock out the pump (LOTO) before any work.
2. For seal replacement, replace the cartridge seal as a unit.
3. Perform laser coupling alignment to 0.05 mm concentricity.
4. Record a post-repair vibration reading and attach to the work order before closeout.