

MTU_Value*Service* **Technical Documentation**

Diesel Engine

12 V 2000 G23, G43, G63, G83

16 V 2000 G23, G43, G63, G83

18 V 2000 G63, G83

**Air-cooled / coolant-cooled charge-air
cooling**

**Optimized fuel consumption / exhaust
emission**

Operating Instructions

M015560/04E



Printed in Germany

© 2008 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services. This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

Wichtig – Important – Importante

Bitte die Karte „Inbetriebnahmemeldung“ abtrennen und ausgefüllt an MTU Friedrichshafen GmbH zurücksenden.

Die Informationen der Inbetriebnahmemeldung sind Grundlage für den vertraglich vereinbarten Logistik-Support (Gewährleistung, Ersatzteile etc.).

Please complete and return the “Commissioning Note” card below to MTU Friedrichshafen GmbH.

The Commissioning Note information serves as a basis for the contractually agreed logistic support (warranty, spare parts, etc.).

Veillez séparer la carte “Signalisation de mise en service” et la renvoyer à la MTU Friedrichshafen GmbH.

Les informations contenues dans la signalisation de mise en service constituent la base pour l'assistance en exploitation contractuelle (garantie, rechanges, etc.).

Rogamos separar la tarjeta “Aviso de puesta en servicio” y la devuelvan rellena a MTU Friedrichshafen GmbH.

Las informaciones respecto al aviso de puesta en servicio constituyen la base para el soporte logístico contractual (garantía, piezas de repuesto, etc.).

Ritagliare “Avviso di messa in servizio” e rispedirlo debitamente compilato alla MTU Friedrichshafen GmbH.

Le informazioni ivi registrate sono la base per il supporto logistico contrattuale (garanzia, ricambi, ecc.).

É gentileza cortar o cartão “Participação da colocação em serviço”, preenché-lo e devolvê-lo a MTU Friedrichshafen.

Os dados referentes à colocação em serviço representam a base para o suporte logístico (garantia, peças sobressalentes, etc.) estabelecido contratualmente.



Postcard

MTU Friedrichshafen GmbH
Department MST
88040 Friedrichshafen
GERMANY

Bitte in Blockschrift ausfüllen!
Please use block capitals!
Prière de remplir en lettres capitales!
¡A rellenar en letras de imprenta!
Scrivere in stampatello!
Favor preencher com letras de forma!



Motomr.: Engine No.: N° du moteur: N° de motor: Motore N.: No. do motor:

Auftragsnr.: MTU works order No.: N° de commande: N° de pedido: N. commessa: No. do pedido:
--

**Inbetriebnahme-
meldung**

**Commissioning
Note**

**Notice de mise
en service**

**Aviso de puesta
en servicio**

**Avviso di messa
in servizio**

**Participação da
colocação em
serviço**

Motortyp: Engine model: Type du moteur: Tipo de motor: Motore tipo: Tipo do motor:

Inbetriebnahmedatum: Date put into operation: Mise en service le: Fecha de puesta en servicio: Messa in servizio il: Data da colocação em serviço:

Eingebaut in: Installation site: Lieu de montage: Lugar de montaje: Installato: Incorporado em:
--

Schiffstyp / Schiffshersteller: Vessel/type/class / Shipyard: Type du bateau / Constructeur: Tipo de buque / Constructor: Tipo di barca / Costruttore Tipo de embarcação/estaleiro naval:
--

Endabnehmer/Anschrift: End user's address: Adresse du client final: Dirección del cliente final: Indirizzo del cliente finale: Usuário final/endereço:

Bemerkung: Remarks: Remarques: Observaciones: Commento: Observações:

1	Safety	05
1.1	General conditions	05
1.2	Personnel and organizational requirements	06
1.3	Transport	07
1.4	Safety requirements when working on the engine	08
1.5	Auxiliary materials, fire prevention and environmental protection	11
1.6	Standards for warning notices in the publication	13
2	Product Overview	15
2.1	Engine Overview	15
2.1.1	Engine layout	15
2.2	Engine Side and Cylinder Designations	17
2.2.1	Engine side and cylinder designations	17
2.3	Main Engine Dimensions	18
2.3.1	Main engine dimensions	18
2.4	Firing Order	19
2.4.1	Firing order	19
2.5	Technical Data	20
2.5.1	12/16/18V 2000 engine data: Continuous operation, unrestricted 3A, air-cooled intercooler, optimized fuel consumption, optimized exhaust emission (EPA 40 CFR89 / Tier 1) *	20
2.5.2	12/16/18V 2000 engine data: Continuous operation, unrestricted 3A, coolant-cooled intercooler, optimized fuel consumption, optimized exhaust emission (EPA 40 CFR89 / Tier 1) *	28
2.5.3	12/16/18V 2000 engine data: Continuous operation, variable 3B, air-cooled intercooler, optimized fuel consumption	36
2.5.4	12/16/18V engine data: Continuous operation, variable 3B, air-cooled intercooler, optimized exhaust emission (EPA 40 CFR89 / Tier 1)	41
2.5.5	12/16/18V engine data: Continuous operation, variable 3B, air-cooled intercooler, optimized exhaust emission (TA-Luft)	45
2.5.6	12/16/18V 2000 engine data: Continuous operation, variable 3B, coolant-cooled intercooler, optimized fuel consumption	50
2.5.7	12/16/18V 2000 engine data: Continuous operation, variable 3B, coolant-cooled intercooler, optimized exhaust emission (EPA 40 CFR89 / Tier 1)	55
2.5.8	12/16/18V 2000 engine data: Continuous operation, variable 3B, coolant-cooled intercooler, optimized exhaust emission (TA-Luft)	59
2.5.9	12/16/18V 2000 engine data: Standby operation 3D, air-cooled intercooler, optimized fuel consumption	64
2.5.10	12/16/18V 2000 engine data: Standby operation 3D, air-cooled intercooler, optimized exhaust emission (EPA 40 CFR89 / Tier 1)	69
2.5.11	12/16/18V 2000 engine data: Standby operation 3D, coolant-cooled intercooler, optimized fuel consumption	74
2.5.12	12/16/18V 2000 engine data: Standby operation 3D, coolant-cooled intercooler, optimized exhaust emission (EPA 40 CFR89 / Tier 1)	79
3	Operation	85

3.1	Putting the engine into operation after extended out-of-service periods (>3 months)	85
3.2	Putting the engine into operation after scheduled out-of-service-period	86
3.3	Start engine in manual mode (testing mode)	87
3.4	Bypassing the safety system (Override)	88
3.5	Operational checks	89
3.6	Stop engine in manual mode (testing mode)	90
3.7	Emergency stop	91
3.8	After stopping the engine – engine remains ready for operation	92
3.9	After stopping the engine – putting the engine out of service	93
3.10	Plant – Cleaning	94
4	Maintenance	95
4.1	Maintenance Schedule, Application Group 3A	95
4.1.1	Preface	95
4.1.2	Maintenance schedule matrix	97
4.1.3	Maintenance tasks	100
4.2	Maintenance Schedule, Application Group 3B	102
4.2.1	Preface	102
4.2.2	Maintenance schedule matrix	104
4.2.3	Maintenance tasks	106
4.3	Maintenance Schedule, Application Group 3B (“TA-Luft”)	108
4.3.1	Preface	108
4.3.2	Maintenance schedule matrix	110
4.3.3	Maintenance tasks	112
4.4	Maintenance Schedule, Application Group 3D	114
4.4.1	Preface	114
4.4.2	Maintenance schedule matrix	116
4.4.3	Maintenance tasks	118
5	Troubleshooting	121
5.1	Troubleshooting	121
5.2	ECU alarms	124
6	Task Description	135
6.1	Engine	135
6.1.1	Engine – Barring manually	135
6.1.2	Engine – Barring with starting system	136
6.1.3	Engine test run	137
6.2	Cylinder Liner	138
6.2.1	Cylinder liner – Endoscopic examination	138
6.2.2	Instructions and comments on endoscopic and visual examination of cylinder liners	140
6.3	Crankcase Breather	142

6.3.1	Crankcase breather – Oil separator replacement, diaphragm check and replacement	142
6.3.2	Crankcase breather – Wire mesh cleaning	144
6.4	Valve Gear	146
6.4.1	Valve clearance – Check and adjustment	146
6.4.2	Cylinder-head cover – Removal and installation	149
6.5	Injection Pump / HP Pump	150
6.5.1	Injection pump replacement	150
6.5.2	Injection pump – Removal and installation	151
6.6	Fuel Injector	154
6.6.1	Injector – Replacement	154
6.6.2	Injector – Removal and installation	155
6.7	Fuel System	158
6.7.1	Fuel pressure relief valve – Replacement	158
6.7.2	HP fuel line and pressure pipe neck – Replacement	160
6.7.3	Fuel – Draining	162
6.7.4	Fuel system – Venting	163
6.8	Fuel Filter	165
6.8.1	Fuel filter – Replacement	165
6.8.2	Fuel prefilter cleaning	166
6.8.3	Fuel prefilter – differential pressure check and adjustment of gauge	167
6.8.4	Fuel prefilter – draining	168
6.8.5	Fuel prefilter – flushing	170
6.8.6	Fuel prefilter – filter element replacement	172
6.9	Intercooler	174
6.9.1	Intercooler – Checking condensate drains for coolant discharge and obstructions	174
6.10	Air Filter	175
6.10.1	Air filter replacement	175
6.10.2	Air filter removal and installation	176
6.11	Air Intake	177
6.11.1	Service indicator – Signal ring position check	177
6.12	Starting Equipment	178
6.12.1	Air starter – manual operation	178
6.12.2	Starter – Condition check	179
6.13	Lube-oil System, Lube-oil Circuit	180
6.13.1	Engine oil – Level check	180
6.13.2	Engine oil – Change	181
6.14	Oil Filtration/Cooling	182
6.14.1	Engine oil filter – Replacement	182
6.15	Coolant Circuit, general, High-temperature circuit	183
6.15.1	Engine coolant level – Check	183
6.15.2	Engine coolant – Change	184
6.15.3	Engine coolant – Draining	185
6.15.4	Engine coolant filling	186

	6.15.5	Coolant pump – Relief bore check	187
6.16		Low-temperature Circuit	188
	6.16.1	Charge-air coolant level check	188
	6.16.2	Charge-air coolant change	189
	6.16.3	Charge-air coolant – Draining	190
	6.16.4	Charge-air coolant filling	191
6.17		Generator	192
	6.17.1	Battery-charging generator drive – Drive-belt check and adjustment	192
	6.17.2	Battery-charging generator drive – Drive belt replacement	194
6.18		Fan Drive	195
	6.18.1	Fan drive – Drive-belt check and adjustment	195
	6.18.2	Ventilator drive – Drive belt replacement	198
6.19		General Wiring for Engine / Gearbox / Genset	199
	6.19.1	Engine wiring – Check	199
6.20		Accessories for Engine Governor (electronic) / Control System	200
	6.20.1	Engine governor and connectors – Cleaning	200
	6.20.2	Engine governor plug-in connections – Check	202
	6.20.3	Engine governor – Removal and installation	203
7		Special Tools	205
	7.1	Special tools	205
8		Appendix	219
	8.1	Manufacturer's documentation	219
	8.2	MTU contact person/service partner	220
	8.3	Abbreviations	221
	8.4	Index	228

1 Safety

1.1 General conditions

General

In addition to the instructions in this publication, the applicable country-specific legislation and other compulsory regulations regarding accident prevention must be observed. This engine is a state-of-the art product and conforms with all applicable specifications and regulations. Nevertheless, persons and property may be at risk in the event of:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Modifications or conversions
- Non-compliance with the Safety Instructions

Correct use

The engine is intended exclusively for the application specified in the contract or defined at the time of delivery. Any other use is considered improper use. The manufacturer will accept no liability for any resultant damage. The responsibility is borne by the user alone.

Correct use also includes observation of and compliance with the maintenance specifications.

Modifications or Conversions

Modifications made by the customer to the engine may affect safety.

MTU will accept no liability or warranty claims for any damage caused by unauthorized modifications or conversions.

Spare parts

Only genuine MTU spare parts must be used to replace components or assemblies. In the event of any damage caused by the use of other spare parts, no liability nor warranty claims vis-à-vis the engine manufacturer will be accepted.

1.2 Personnel and organizational requirements

Personnel

Work on the engine must only be carried out by properly qualified and instructed personnel.

The specified legal minimum age must be observed.

Responsibilities of the operating, maintenance and repair personnel must be specified.

Organization

This publication must be issued to all personnel involved in operation, maintenance, repair or transportation.

It must be kept at hand near the engine and accessible at any time to all personnel involved in operation, maintenance, repair or transportation.

The personnel must be instructed on engine operation and repair by means of this publication, and in particular the safety instructions must be explained.

This is especially important for personnel who work on the engine only on an occasional basis. Such personnel must be given instructions repeatedly.

Working clothes and protective equipment

Wear proper work clothing for all work.

Depending on the kind of work, use additional protective equipment, e.g. protective goggles, gloves, helmet, apron.

Work clothing must be tight fitting so that it does not catch on rotating or projecting components.

Do not wear jewelry (e.g. rings, chains etc.).