



Operating Instructions

Diesel engine
12V2000P12
16V2000P12

MS150025/03E



A Rolls-Royce
solution

Engine model	kW/cyl.	Application group
12V2000P12	50 kW/cyl.	4A, continuous operation
16V2000P12	50 kW/cyl.	4A, continuous operation

Table 1: Applicability

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.



WARNING: Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1	Preface		
1.1	Preface	7	
2	Safety		
2.1	Important provisions for all products	8	
2.2	Intended use of all products	10	
2.3	Personnel and organizational requirements	11	
2.4	Safety regulations for initial start-up and operation	12	
2.5	Safety regulations for assembly, maintenance, and repair work	14	
2.6	Fire and environmental protection, indirect materials	18	
2.7	Standards for warning notices in the text and highlighted information	21	
2.8	ATEX precautions (if applicable)	22	
3	Transport		
3.1	Transport	23	
4	General Information		
4.1	Engine side and cylinder designations	24	
4.2	Engine layout	25	
4.3	Use	27	
4.4	ECS-5 - Use of devices	34	
4.5	MDEC - Functions	37	
4.6	Peripheral Interface Modules (PIMs)	42	
4.7	Printed circuit board - SCB 3	44	
5	Technical Data		
5.1	12/16 V 2000 P12 engine data	47	
5.2	Firing order	50	
5.3	Engine - Main dimensions	51	
5.4	SAM - Technical data	52	
5.5	SCB 3 - Technical data	54	
6	Operation		
6.1	LOP - Control elements	55	
6.2	Preparations for putting into operation after extended out-of-service periods (>3 months)	57	
6.3	Preparations for putting into operation after scheduled out-of-service-period	58	
6.4	Starting the engine in manual mode (test run)	59	
6.5	Safety system - Override	60	
6.6	Operational checks	61	
6.7	Engine - Stopping in Manual mode (test run)	62	
6.8	Engine - Emergency stop	64	
6.9	After stopping the engine - Engine remains ready for operation	65	
6.10	After shutting down engine - Putting engine out of operation	66	
6.11	Plant - Cleaning	67	
7	Maintenance		
7.1	Maintenance task reference table [QL1]	69	
8	Troubleshooting		
8.1	Troubleshooting	70	
8.2	Fault display on printed circuit board SAM	73	
8.3	ECU alarms	82	
9	Task Description		
9.1	Engine	92	
9.1.1	Engine - Barring manually	92	
9.1.2	Barring engine with starting system	93	
9.1.3	Engine - Test run	94	
9.2	Cylinder Liner	95	
9.2.1	Cylinder liner - Endoscopic examination	95	
9.2.2	Cylinder liner - Instructions and comments on endoscopic and visual examination	97	
9.3	Crankcase Breather	99	
9.3.1	Crankcase breather - Wire mesh cleaning	99	
9.3.2	Crankcase breather - Oil separator replacement, diaphragm check and replacement	101	
9.4	Valve Drive	103	
9.4.1	Valve clearance - Check and adjustment	103	
9.4.2	Cylinder head cover - Removal and installation	105	
9.5	Injection Pump / HP Pump	106	
9.5.1	Injection pump - Replacement	106	
9.5.2	Injection pump - Removal and installation	107	
9.6	Injection Valve / Injector	110	
9.6.1	Injector - Replacement	110	
9.6.2	Injector - Removal and installation	111	
9.7	Fuel System	114	
9.7.1	Fuel pressure relief valve - Removal and installation	114	
9.7.2	Fuel - Draining	116	
9.7.3	Fuel system - Venting	117	

9.8 Fuel Filter	118	9.17 Belt Drive	155
9.8.1 Fuel filter - Replacement	118	9.17.1 Drive belt - Condition check	155
9.8.2 Fuel prefilter - Cleaning	120	9.18 Engine Mounting / Support	156
9.8.3 Fuel prefilter - Differential pressure gauge check and adjustment	121	9.18.1 Engine mounts - Resilient elements check	156
9.8.4 Fuel prefilter - Draining	122	9.19 Wiring (General) for Engine/Gearbox/Unit	157
9.8.5 Fuel prefilter - Flushing	124	9.19.1 Engine cabling - Check	157
9.8.6 Fuel prefilter - Filter element replacement	127	9.20 Accessories for (Electronic) Engine Governor / Control System	158
9.9 Charge-Air Cooling General, Left-Hand Side	129	9.20.1 Engine governor and connectors - Cleaning	158
9.9.1 Intercooler - Checking condensate drain for coolant discharge and obstructions	129	9.20.2 EMU and connectors - Cleaning	159
9.10 Air Filter	130	9.20.3 Engine Control Unit ECU 4, plug connections - Check	160
9.10.1 Air filter - Replacement	130	9.20.4 Engine Monitoring Unit - Plug connection check	161
9.11 Air Intake	131	9.20.5 Engine governor - Removal and installation	162
9.11.1 Service indicator - Signal ring position check	131	9.21 Emergency Instrumentation (Local Operating Panel)	163
9.12 Starting Equipment	132	9.21.1 LOP - Visual inspection	163
9.12.1 Starter - Condition check	132	9.21.2 LOP - Running test procedures	165
9.13 Lube Oil System, Lube Oil Circuit	133	10 Engine Governor Assignment and Circuitry	
9.13.1 Engine oil level - Check	133	10.1 Engine Governor	167
9.13.2 Engine oil - Change	134	10.1.1 Circuitry of engine control unit channels	167
9.14 Oil Filtration / Cooling	136	10.1.2 I/O assignment of MDEC control unit	176
9.14.1 Engine oil filter - Replacement	136	10.2 Connector Assignment	178
9.15 Coolant Circuit, General, High-Temperature Circuit	138	10.2.1 Connector pin assignment	178
9.15.1 Drain and venting points	138	11 Appendix A	
9.15.2 Engine coolant - Level check	142	11.1 Abbreviations	187
9.15.3 Engine coolant - Change	144	11.2 Contact person/Service partner	191
9.15.4 Engine coolant - Draining	145	12 Appendix B	
9.15.5 Engine coolant - Filling	146	12.1 Special Tools	192
9.15.6 Coolant pump - Relief bore check	148	12.2 Index	199
9.16 Low-Temperature Circuit	149		
9.16.1 Charge-air coolant - Filling	149		
9.16.2 Charge-air coolant - Draining	151		
9.16.3 Charge-air coolant - Change	152		
9.16.4 Charge-air coolant level - Check	153		

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer MTU.

Definition of MTU

MTU refers to Rolls-Royce Power Systems AG and MTU Friedrichshafen GmbH or an affiliated company pursuant to Section § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture).

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations and emissions label

Responsibility for compliance with emissions regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emissions characteristics of the product are prohibited by emissions regulations. Emissions-related components must only be serviced, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these specifications will invalidate the design type approval or certification issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emissions regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 10).

Emissions certification applicable to engines with EPA Nonroad Tier 4 emissions certification in accordance with 40 CFR 1039 and with EPA Locomotive emissions certification in accordance with 40 CFR 1033

Extract from the standard:

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.

Extract from the standard:

If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.

When fitting the second label, the requirements of 40 CFR 1068.105(c) must be followed and observed. This paragraph describes the process for requesting and fitting the label, the documentation obligations and storage obligations for the required documents.

TM-ID: 0000040530 - 016

Replacing components with emissions labels

On all engines from MTU fitted with emissions labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emissions labels:

- The relevant emissions labels must be affixed to the spare part.
- Emissions labels shall not be transferred from the replaced part to the spare part.
- The emissions labels must be removed from the replaced part and destroyed.

2.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.