



Operating Instructions

Diesel Engine
12V2000S92R
16V2000S92R
16V2000S92

MS150043/06E

Engine model	kW/cyl.	Application group
12V2000S92R	62.5 kW/cyl.	4C, short time operation
16V2000S92R	62.5 kW/cyl.	4C, short time operation
16V2000S92	69.9 kW/cyl.	4C, short time operation

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.



WARNING: Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1 Preface		7.6 Operational checks	53
1.1 Preface	7	7.7 Engine shutdown	54
2 Revision Overview		7.8 Emergency engine stop	55
2.1 Revision - Overview	8	7.9 After stopping the engine - Putting the engine out of operation	56
3 Safety		7.10 Plant - Cleaning	57
3.1 Important provisions for all products	9	8 Maintenance	
3.2 Intended use of all products	10	8.1 Maintenance task reference table [QL1]	59
3.3 Personnel and organizational requirements	11	9 Troubleshooting	
3.4 Safety regulations for commissioning and operation	12	9.1 Troubleshooting	60
3.5 Safety regulations for assembly, maintenance, and repair work	14	9.2 Fault messages from DDEC engine governor III/IV	63
3.6 Fire and environmental protection, indirect materials	18	10 Task Description	
3.7 Standards for warning messages in the text and highlighted information	21	10.1 Engine	82
4 Transport		10.1.1 Engine - Barring manually	82
4.1 Transportation	22	10.1.2 Engine - Turning on starting system	83
5 General Information		10.2 Cylinder Liner	84
5.1 Tightening specifications for screws, nuts and bolts	23	10.2.1 Cylinder liner - Endoscopic examination	84
5.2 Engine side and cylinder designations	37	10.2.2 Cylinder liner - Instructions and comments on endoscopic and visual examination	86
5.3 Engine layout	38	10.3 Crankcase Breather	88
5.4 Sensors - Overview	40	10.3.1 Crankcase breather - Oil separator replacement, diaphragm check and replacement	88
5.5 Data acquisition and data transmission	41	10.3.2 Crankcase breather - Wire mesh cleaning	90
6 Technical Data		10.4 Valve Drive	92
6.1 Product data 12V2000S92R, 16V2000S92R, 16V2000S92	42	10.4.1 Valve clearance - Check and adjustment	92
6.2 Firing order	46	10.4.2 Cylinder head cover - Removal and installation	94
6.3 Engine - Main dimensions	47	10.5 Injection Pump / HP Pump	95
7 Operation		10.5.1 Injection pump - Replacement	95
7.1 Preparations for putting into operation after extended out-of-service periods (>3 months)	48	10.5.2 Injection pump - Removal and installation	96
7.2 Preparations for putting into operation after scheduled out-of-service-period	49	10.6 Injection Valve / Injector	100
7.3 Engine - Starting	50	10.6.1 Injector - Replacement	100
7.4 Re-starting the engine following an automatic safety shutdown	51	10.6.2 Injector - Removal and installation	101
7.5 Safety system - Override	52	10.7 Fuel System	106
		10.7.1 HP fuel line and pressure pipe neck - Replacement	106
		10.7.2 Fuel - Draining	108
		10.7.3 Fuel system - Venting	109
		10.8 Fuel Filter	114
		10.8.1 Fuel filter - Replacement	114
		10.8.2 Fuel prefilter - Draining	115

10.9 Charge-Air Cooling	116	10.15.1 Charge-air coolant level - Check	131
10.9.1 Intercooler - Checking condensate drain for coolant leakage and obstruction	116	10.15.2 Charge-air coolant - Change	133
10.10 Air Filter	117	10.15.3 Charge-air coolant - Draining	134
10.10.1 Air filter - Replacement	117	10.15.4 Charge-air coolant - Filling	135
10.11 Starting Equipment	118	10.15.5 Charge-air coolant pump - Relief bore check	137
10.11.1 Starter - Condition check	118	10.16 Wiring (General) for Engine/Gearbox/Unit	138
10.12 Lube Oil System, Lube Oil Circuit	119	10.16.1 Engine cabling - Check	138
10.12.1 Engine oil level - Check	119	10.17 Accessories for (Electronic) Engine Governor / Control System	139
10.12.2 Engine oil - Change	120	10.17.1 Engine governor and connectors - Cleaning	139
10.13 Oil Filtration / Cooling	122	10.17.2 Engine governor plug connections - Check	140
10.13.1 Engine oil filter - Replacement	122	10.17.3 DDEC engine governor - Removal and installation	141
10.14 Coolant Circuit, General, High-Temperature Circuit	123	11 Appendix A	
10.14.1 Engine coolant - Level check	123	11.1 Contact person/Service partner	142
10.14.2 Engine coolant - Change	125	11.2 Abbreviations	143
10.14.3 Engine coolant - Draining	126	12 Appendix B	
10.14.4 Engine coolant - Filling	127	12.1 Standard Tools and Special Tools	146
10.14.5 Engine coolant pump - Relief bore check	129	12.2 Index	152
10.14.6 Engine coolant - Sample extraction and analysis	130		
10.15 Low-Temperature Circuit	131		

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Revision Overview

2.1 Revision – Overview

Revision overview – General

Chapter	MS150043/02	MS150043/03
2	Chapter “Safety”.	Chapter updated to the latest status.

Revision overview – Maintenance schedule

Task No.	MS50012/00	MS50012/00

Revision overview – Task description

Chapter	MS150043/02	MS150043/03
3.1	Chapter "Transportation"	Content updated.
9.5.2	Chapter "Injection pump – Removal and installation"	Graphic updated.
9.6.2	Chapter "Injector – Removal and installation"	Graphic updated.
9.12.1	Chapter “Engine oil level – Check”	Graphic updated.

3 Safety

3.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at: <http://www.mtu-solutions.com>

3.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.