



Operating Instructions

Diesel engine

12V2000P62, P82

16V2000P62, P82, P82L

Application group 3A

MS15008/03E

Engine model	kW/cyl.	Application group
12V2000P62	46.4 kW/cyl.	3A, continuous operation, unrestricted
12V2000P82	55.7 kW/cyl.	3A, continuous operation, unrestricted
16V2000P62	48.1 kW/cyl.	3A, continuous operation, unrestricted
16V2000P82	58.1 kW/cyl.	3A, continuous operation, unrestricted
16V2000P82L	61.2 kW/cyl.	3A, continuous operation, unrestricted

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.



WARNING: Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1	Preface		6.7	Engine - Stopping in manual mode (test run)	61
1.1	Preface	7	6.8	Engine - Emergency stop	63
2	Safety		6.9	After stopping the engine - Engine remains ready for operation	64
2.1	Important provisions for all products	8	6.10	After shutting down engine - Putting engine out of operation	65
2.2	Intended use of all products	9	7	Maintenance	
2.3	Personnel and organizational requirements	10	7.1	Maintenance task reference table [QL1]	66
2.4	Safety regulations for commissioning and operation	11	8	Troubleshooting	
2.5	Safety regulations for assembly, maintenance, and repair work	13	8.1	Troubleshooting	67
2.6	Fire and environmental protection, indirect materials	17	8.2	Fault display on printed circuit board SAM	70
2.7	Standards for warning messages in the text and highlighted information	20	8.3	ECU alarms	79
2.8	ATEX precautions (if applicable)	21	9	Task Description	
3	Transport		9.1	Engine	89
3.1	Transport	22	9.1.1	Engine - Barring manually	89
4	General Information		9.1.2	Barring engine with starting system	90
4.1	Engine side and cylinder designations	23	9.1.3	Engine - Test run	91
4.2	Engine layout	24	9.2	Cylinder Liner	92
4.3	Purpose	26	9.2.1	Cylinder liner - Endoscopic examination	92
4.4	ECS-5 - Purpose of the units	33	9.2.2	Cylinder liner - Instructions and comments on endoscopic and visual examination	94
4.5	MDEC - Functions	36	9.3	Crankcase Breather	96
4.6	Peripheral Interface Modules (PIMs)	41	9.3.1	Crankcase breather - Wire mesh cleaning	96
4.7	Printed circuit board - SCB 3	43	9.3.2	Crankcase breather - Oil separator filter element replacement, diaphragm check and replacement	97
5	Technical Data		9.4	Valve Drive	99
5.1	12/16V 2000 P62/82 engine data	46	9.4.1	Valve clearance - Check and adjustment	99
5.2	Final compression pressure	50	9.4.2	Cylinder head cover - Removal and installation	101
5.3	SAM - Technical data	51	9.5	Injection Pump / HP Pump	102
5.4	SCB 3 - Technical data	53	9.5.1	Injection pump - Replacement	102
6	Operation		9.5.2	Injection pump - Removal and installation	103
6.1	LOP - Control elements	54	9.6	Injection Valve / Injector	106
6.2	Preparations for putting into operation after extended out-of-service periods (>3 months)	56	9.6.1	Injector - Replacement	106
6.3	Preparations for putting into operation after scheduled out-of-service-period	57	9.6.2	Injector - Removal and installation	107
6.4	Starting the engine in manual mode (test run)	58	9.7	Fuel System	110
6.5	Emergency engine start (Override mode)	59	9.7.1	Fuel pressure relief valve - Removal and installation	110
6.6	Operational checks	60	9.7.2	Fuel - Draining	112
			9.7.3	Fuel system - Venting	113
			9.8	Fuel Filter	114

9.8.1	Fuel filter - Replacement	114	9.17	Belt Drive	151
9.8.2	Fuel prefilter - Cleaning	116	9.17.1	Drive belt - Condition check	151
9.8.3	Fuel prefilter - Differential pressure gauge check and adjustment	117	9.18	Wiring (General) for Engine/Gearbox/Unit	152
9.8.4	Fuel prefilter - Draining	118	9.18.1	Engine cabling - Check	152
9.8.5	Fuel prefilter - Flushing	120	9.18.2	Sensors and actuators	153
9.8.6	Fuel prefilter - Filter element replacement	123	9.19	Accessories for (Electronic) Engine Governor / Control System	157
9.9	Charge-Air Cooling General, Left-Hand Side	125	9.19.1	Engine governor and connectors - Cleaning	157
9.9.1	Intercooler - Checking condensate drain for coolant discharge and obstructions	125	9.19.2	Engine Monitoring Unit and connectors - Cleaning	158
9.10	Air Filter	126	9.19.3	Engine Control Unit ECU 4, plug connections - Check	159
9.10.1	Air filter - Replacement	126	9.19.4	Engine Monitoring Unit - Plug connection check	160
9.11	Air Intake	127	9.19.5	Engine governor - Removal and installation	161
9.11.1	Service indicator - Signal ring position check	127	9.20	Emergency Instrumentation (Local Operating Panel)	162
9.12	Starting Equipment	128	9.20.1	LOP - Visual inspection	162
9.12.1	Air starter - Manual operation	128	9.20.2	LOP - Running test procedures	164
9.12.2	Starter - Condition check	129	10	Engine Governor Assignment and Circuitry	
9.13	Lube Oil System, Lube Oil Circuit	130	10.1	Engine Governor	166
9.13.1	Engine oil - Change	130	10.1.1	Circuitry of Engine Control Unit channels	166
9.13.2	Engine oil level - Check	132	10.1.2	I/O assignment of MDEC control unit	175
9.14	Oil Filtration / Cooling	133	10.2	Connector Assignment	177
9.14.1	Engine oil filter - Replacement	133	10.2.1	Connector pin assignment	177
9.15	Coolant Circuit, General, High-Temperature Circuit	134	11	Appendix A	
9.15.1	Drain and venting points	134	11.1	Abbreviations	186
9.15.2	Engine coolant - Filling	138	11.2	Contact person/Service partner	190
9.15.3	Engine coolant - Draining	140	12	Appendix B	
9.15.4	Engine coolant - Change	141	12.1	Standard Tools and Special Tools	191
9.15.5	Engine coolant - Level check	142	12.2	Index	198
9.15.6	Coolant pump - Relief bore check	144			
9.16	Low-Temperature Circuit	145			
9.16.1	Charge-air coolant - Change	145			
9.16.2	Charge-air coolant - Filling	146			
9.16.3	Charge-air coolant - Draining	148			
9.16.4	Charge-air coolant level - Check	149			

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>

2.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

2.3 Personnel and organizational requirements

Organizational measures of the user/manufactururer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.