



# Operating Instructions

Diesel engine

12V2000P62, P82

16V2000P62, P82, P82L

Application group 3A

MS15010/04E

| Engine model | kW/cyl.      | Application group                            |
|--------------|--------------|----------------------------------------------|
| 12V2000P62   | 46.4 kW/cyl. | 3A, continuous operation, unrestricted, ICXN |
| 12V2000P82   | 55.7 kW/cyl. | 3A, continuous operation, unrestricted, ICXN |
| 16V2000P62   | 48.1 kW/cyl. | 3A, continuous operation, unrestricted, ICXN |
| 16V2000P82   | 58.1 kW/cyl. | 3A, continuous operation, unrestricted, ICXN |

*Table 1: Applicability*

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

## California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.



**WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to [www.P65warnings.ca.gov/diesel](http://www.P65warnings.ca.gov/diesel).

(→ [www.P65warnings.ca.gov/diesel](http://www.P65warnings.ca.gov/diesel) )



# Table of Contents

|       |                                                                                           |    |       |                                                                                                |     |
|-------|-------------------------------------------------------------------------------------------|----|-------|------------------------------------------------------------------------------------------------|-----|
| 1     | Preface                                                                                   |    | 5.5   | Emergency engine start (Override mode)                                                         | 58  |
| 1.1   | Preface                                                                                   | 7  | 5.6   | Operational checks                                                                             | 59  |
| 2     | Safety                                                                                    |    | 5.7   | Engine - Stopping in manual mode (test run)                                                    | 60  |
| 2.1   | Important provisions for all products                                                     | 8  | 5.8   | Engine - Emergency stop                                                                        | 62  |
| 2.2   | Intended use of all products                                                              | 9  | 5.9   | After stopping the engine - Engine remains ready for operation                                 | 63  |
| 2.3   | Personnel and organizational requirements                                                 | 10 | 5.10  | After shutting down engine - Putting engine out of operation                                   | 64  |
| 2.4   | Transport                                                                                 | 11 | 6     | Maintenance                                                                                    |     |
| 2.5   | Safety regulations for assembly, maintenance, and repair work                             | 12 | 6.1   | Maintenance task reference table [QL1]                                                         | 65  |
| 2.6   | Fire and environmental protection, indirect materials                                     | 16 | 7     | Troubleshooting                                                                                |     |
| 2.7   | Standards for warning messages in the text and highlighted information                    | 19 | 7.1   | Troubleshooting                                                                                | 66  |
| 2.8   | ATEX precautions (if applicable)                                                          | 20 | 7.2   | Fault display on printed circuit board SAM                                                     | 69  |
| 3     | General Information                                                                       |    | 7.3   | ECU alarms                                                                                     | 78  |
| 3.1   | Data acquisition and data transmission                                                    | 21 | 8     | Task Description                                                                               |     |
| 4     | Product Summary                                                                           |    | 8.1   | Engine                                                                                         | 88  |
| 4.1   | Plant Overview                                                                            | 22 | 8.1.1 | Engine - Barring manually                                                                      | 88  |
| 4.1.1 | Purpose                                                                                   | 22 | 8.1.2 | Barring engine with starting system                                                            | 89  |
| 4.1.2 | ECS-5 - Purpose of the units                                                              | 29 | 8.1.3 | Engine - Test run                                                                              | 90  |
| 4.1.3 | MDEC - Functions                                                                          | 32 | 8.2   | Cylinder Liner                                                                                 | 91  |
| 4.1.4 | Peripheral Interface Modules (PIMs)                                                       | 37 | 8.2.1 | Cylinder liner - Endoscopic examination                                                        | 91  |
| 4.1.5 | Printed circuit board - SCB 3                                                             | 39 | 8.2.2 | Cylinder liner - Instructions and comments on endoscopic and visual examination                | 93  |
| 4.2   | Engine Layout                                                                             | 42 | 8.3   | Crankcase Breather                                                                             | 95  |
| 4.2.1 | Engine layout                                                                             | 42 | 8.3.1 | Crankcase breather - Wire mesh cleaning                                                        | 95  |
| 4.3   | Engine Side and Cylinder Designations                                                     | 44 | 8.3.2 | Crankcase breather - Oil separator filter element replacement, diaphragm check and replacement | 96  |
| 4.3.1 | Engine side and cylinder designations                                                     | 44 | 8.4   | Valve Drive                                                                                    | 98  |
| 4.4   | Final Compression Pressure                                                                | 45 | 8.4.1 | Valve clearance - Check and adjustment                                                         | 98  |
| 4.4.1 | Final compression pressure                                                                | 45 | 8.4.2 | Cylinder head cover - Removal and installation                                                 | 100 |
| 4.5   | Technical Data                                                                            | 46 | 8.5   | Injection Pump / HP Pump                                                                       | 101 |
| 4.5.1 | ENGINE DATA 12/16V 2000P62/82                                                             | 46 | 8.5.1 | Injection pump - Replacement                                                                   | 101 |
| 4.5.2 | SAM - Technical data                                                                      | 50 | 8.5.2 | Injection pump - Removal and installation                                                      | 102 |
| 4.5.3 | SCB 3 - Technical data                                                                    | 52 | 8.6   | Injection Valve / Injector                                                                     | 105 |
| 5     | Operation                                                                                 |    | 8.6.1 | Injector - Replacement                                                                         | 105 |
| 5.1   | LOP - Control elements                                                                    | 53 | 8.6.2 | Injector - Removal and installation                                                            | 106 |
| 5.2   | Preparations for putting into operation after extended out-of-service periods (>3 months) | 55 | 8.7   | Fuel System                                                                                    | 109 |
| 5.3   | Preparations for putting into operation after scheduled out-of-service-period             | 56 | 8.7.1 | Fuel pressure relief valve - Removal and installation                                          | 109 |
| 5.4   | Starting the engine in manual mode (test run)                                             | 57 | 8.7.2 | Fuel - Draining                                                                                | 111 |
|       |                                                                                           |    | 8.7.3 | Fuel system - Venting                                                                          | 112 |

|                                                                                      |     |                                                                    |     |
|--------------------------------------------------------------------------------------|-----|--------------------------------------------------------------------|-----|
| 8.8 Fuel Filter                                                                      | 113 | 8.17 Belt Drive                                                    | 150 |
| 8.8.1 Fuel filter - Replacement                                                      | 113 | 8.17.1 Drive belt - Condition check                                | 150 |
| 8.8.2 Fuel prefilter - Cleaning                                                      | 115 | 8.18 Wiring (General) for Engine/Gearbox/Unit                      | 151 |
| 8.8.3 Fuel prefilter - Differential pressure gauge check and adjustment              | 116 | 8.18.1 Engine cabling - Check                                      | 151 |
| 8.8.4 Fuel prefilter - Draining                                                      | 117 | 8.18.2 Sensors and actuators                                       | 152 |
| 8.8.5 Fuel prefilter - Flushing                                                      | 119 | 8.19 Accessories for (Electronic) Engine Governor / Control System | 156 |
| 8.8.6 Fuel prefilter - Filter element replacement                                    | 122 | 8.19.1 Engine governor and connectors - Cleaning                   | 156 |
| 8.9 Charge-Air Cooling General, Left-Hand Side                                       | 124 | 8.19.2 Engine Monitoring Unit and connectors - Cleaning            | 157 |
| 8.9.1 Intercooler - Checking condensate drain for coolant discharge and obstructions | 124 | 8.19.3 Engine Control Unit ECU 4, plug connections - Check         | 158 |
| 8.10 Air Filter                                                                      | 125 | 8.19.4 Engine Monitoring Unit - Plug connection check              | 159 |
| 8.10.1 Air filter - Replacement                                                      | 125 | 8.19.5 Engine governor - Removal and installation                  | 160 |
| 8.11 Air Intake                                                                      | 126 | 8.20 Emergency Instrumentation (Local Operating Panel)             | 161 |
| 8.11.1 Service indicator - Signal ring position check                                | 126 | 8.20.1 LOP - Visual inspection                                     | 161 |
| 8.12 Starting Equipment                                                              | 127 | 8.20.2 LOP - Running test procedures                               | 163 |
| 8.12.1 Air starter - Manual operation                                                | 127 |                                                                    |     |
| 8.12.2 Starter - Condition check                                                     | 128 |                                                                    |     |
| 8.13 Lube Oil System, Lube Oil Circuit                                               | 129 | 9 Engine Governor Assignment and Circuitry                         |     |
| 8.13.1 Engine oil - Change                                                           | 129 | 9.1 Engine Governor                                                | 165 |
| 8.13.2 Engine oil level - Check                                                      | 131 | 9.1.1 Circuitry of Engine Control Unit channels                    | 165 |
| 8.14 Oil Filtration / Cooling                                                        | 132 | 9.1.2 I/O assignment of MDEC control unit                          | 174 |
| 8.14.1 Engine oil filter - Replacement                                               | 132 | 9.2 Connector Assignment                                           | 176 |
| 8.15 Coolant Circuit, General, High-Temperature Circuit                              | 133 | 9.2.1 Connector pin assignment                                     | 176 |
| 8.15.1 Drain and venting points                                                      | 133 |                                                                    |     |
| 8.15.2 Engine coolant - Filling                                                      | 137 | 10 Appendix A                                                      |     |
| 8.15.3 Engine coolant - Draining                                                     | 139 | 10.1 Abbreviations                                                 | 185 |
| 8.15.4 Engine coolant - Change                                                       | 140 | 10.2 Contact person/Service partner                                | 189 |
| 8.15.5 Engine coolant - Level check                                                  | 141 |                                                                    |     |
| 8.15.6 Coolant pump - Relief bore check                                              | 143 | 11 Appendix B                                                      |     |
| 8.16 Low-Temperature Circuit                                                         | 144 | 11.1 Standard Tools and Special Tools                              | 190 |
| 8.16.1 Charge-air coolant - Change                                                   | 144 | 11.2 Consumables                                                   | 197 |
| 8.16.2 Charge-air coolant - Filling                                                  | 145 | 11.3 Index                                                         | 199 |
| 8.16.3 Charge-air coolant - Draining                                                 | 147 |                                                                    |     |
| 8.16.4 Charge-air coolant level - Check                                              | 148 |                                                                    |     |

# 1 Preface

## 1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

## 2 Safety

### 2.1 Important provisions for all products

#### General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

#### Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

#### Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>



## 2.2 Intended use of all products

### Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

### Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

## 2.3 Personnel and organizational requirements

### Organizational measures of the user/manufactururer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

### Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

### Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.