



Operating Instructions

Diesel Engine
12 V 2000 Gx6F

MS150111/04E

Engine model	kW/cyl.	Application group
12V2000G56F	55.4 kW/cyl.	3B, continuous service, variable load, ICXN
12V2000G66F	59.1 kW/cyl.	3B, continuous service, variable load, ICXN

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.



WARNING: Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1 Preface		6.11 After stopping the engine - Putting the engine out of operation	43
1.1 Preface	7	6.12 Fuel treatment system - Shutdown	44
2 Safety		6.13 Plant - Cleaning	45
2.1 Important provisions for all products	8	7 Maintenance	
2.2 Important requirements for Power Generation application products	9	7.1 Maintenance task reference table [QL1]	47
2.3 Intended use of all products	11	8 Troubleshooting	
2.4 Personnel and organizational requirements	12	8.1 Troubleshooting	48
2.5 Safety regulations for commissioning and operation	13	8.2 Control cabinet of fuel treatment system - Troubleshooting	51
2.6 Safety regulations for assembly, maintenance, and repair work	15	9 Task Description	
2.7 Fire and environmental protection, indirect materials	19	9.1 Engine	52
2.8 Standards for warning messages in the text and highlighted information	22	9.1.1 Engine - Barring manually	52
3 Transport		9.1.2 Engine - Barring with starting system	53
3.1 Transport	23	9.2 Crankcase Breather	54
4 General Information		9.2.1 Crankcase breather - Oil mist separator replacement	54
4.1 Engine side and cylinder designations	24	9.3 Valve Drive	55
4.2 Engine overview	25	9.3.1 Valve clearance - Check and adjustment	55
5 Technical Data		9.3.2 Cylinder head cover - Removal and installation	57
5.1 Engine data 12 V 2000 G56/66F	26	9.4 Injection Valve / Injector	58
5.2 Firing order	29	9.4.1 Injector - Replacement	58
5.3 Engine - Main dimensions	30	9.4.2 Injector - Removal and installation	59
6 Operation		9.4.3 Injector functions	64
6.1 Preparations for putting into operation after extended out-of-service periods (>3 months)	31	9.5 Fuel System	65
6.2 Preparations for putting into operation after scheduled out-of-service-period	32	9.5.1 HP fuel line and pressure pipe neck - Replacement	65
6.3 Tasks after extended out-of-service periods (>3 weeks)	33	9.5.2 Fuel system - Venting	68
6.4 Fuel treatment system - Checks prior to putting into operation	34	9.5.3 Fuel - Draining	70
6.5 Fuel treatment system - Initial start-up	35	9.6 Fuel Filter	71
6.6 Engine - Starting	38	9.6.1 Fuel filter - Replacement	71
6.7 Fuel treatment system - Switching on	39	9.6.2 Fuel prefilter - Differential pressure gauge check and adjustment	72
6.8 Operational monitoring	40	9.6.3 Fuel prefilter - Draining	73
6.9 Engine shutdown	41	9.6.4 Fuel prefilter - Flushing	74
6.10 Emergency engine stop	42	9.6.5 Fuel prefilter - Filter element replacement	77
		9.7 Air Filter	79
		9.7.1 Air filter - Replacement	79
		9.7.2 Air filter - Removal and installation	80
		9.8 Air Intake	81
		9.8.1 Contamination indicator - Signal ring position check	81

9.9 Exhaust Gas Recirculation	82	9.15 Battery-Charging Generator	115
9.9.1 Exhaust gas recirculation flaps - Overview	82	9.15.1 Battery-charging generator drive - Drive belt replacement	115
9.9.2 Exhaust gas recirculation - Flap function check	83	9.16 Fuel Supply System	116
9.10 Lube Oil System, Lube Oil Circuit	84	9.16.1 Water drain valve - Check	116
9.10.1 Engine oil level - Check	84	9.16.2 Differential pressure gauge - Check	117
9.10.2 Engine oil - Change	85	9.16.3 Water level probe (3-in-1 rod electrode) - Check	118
9.11 Oil Filtration / Cooling	87	9.16.4 Pump capacity - Check	119
9.11.1 Engine oil filter - Replacement	87	9.16.5 Coalescer filter element - Replacement	120
9.11.2 Centrifugal oil filter - Cleaning and filter-sleeve replacement	88	9.17 Engine Governor	122
9.12 Coolant Circuit, General, High-Temperature Circuit	90	9.17.1 Engine governor - Overview	122
9.12.1 Drain and vent points	90	9.17.2 Engine governor - Removal and installation	123
9.12.2 Engine coolant - Level check	95	9.17.3 Engine governor plug connections - Check	124
9.12.3 Engine coolant - Change	96	9.18 Wiring (General) for Engine/Gearbox/Unit	125
9.12.4 Engine coolant - Draining	97	9.18.1 Engine cabling - Check	125
9.12.5 Engine coolant - Filling	98	9.18.2 Lambda, NOx and humidity sensors - Overview	126
9.12.6 Engine coolant pump - Relief bore check	100	9.18.3 Lambda sensor - Replacement	127
9.12.7 Engine coolant - Sample extraction and analysis	101	9.18.4 NOx sensor - Replacement	129
9.13 Low-Temperature Circuit	102	9.18.5 Humidity sensor - Replacement	131
9.13.1 Intercooler - Venting and draining	102	9.19 Accessories for (Electronic) Engine Governor / Control System	133
9.13.2 Intercooler - Checking condensate drain for coolant discharge and obstructions	103	9.19.1 Engine governor and connectors - Cleaning	133
9.13.3 Charge-air coolant level - Check	104	10 Appendix A	
9.13.4 Charge-air coolant - Change	106	10.1 Abbreviations	134
9.13.5 Charge-air coolant - Filling	107	10.2 Contact person/Service partner	136
9.13.6 Charge-air coolant - Draining	109	11 Appendix B	
9.13.7 Charge-air coolant pump - Relief bore check	110	11.1 Standard Tools and Special Tools	137
9.14 Belt Drive	111	11.2 Index	147
9.14.1 Drive belt - Condition check	111		
9.14.2 Drive belt - Tension check	112		
9.14.3 Drive belt - Tension adjustment	113		
9.14.4 Drive belt - Replacement	114		

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>

2.2 Important requirements for Power Generation application products

Project-specific operational environment

During integration and use of the diesel engine, all currently valid and relevant standards and guidelines on safety and specified operation must be implemented and observed. This applies to persons responsible for:

- The installation of the engine
- The design of the engine-generator set
- The installation of the engine-generator set

The relevant standards are, in particular:

- DIN EN 1679-1
- EN ISO 8528-13

Residual hazards

In the event of a defect, the diesel engine can unexpectedly have insufficient or no drive power at all. We therefore recommend a redundant design of the engine-generator set system in safety-critical applications.

Protection against hot surfaces

Combustion engines and their auxiliary components have hot surfaces (e.g. exhaust system, exhaust turbochargers, exhaust aftertreatment system, engine oil system, cooling system), which can cause injury to persons who approach or touch them (danger of burns).

- In operation
- During the cooling-down phase after operation

The plant integrator and operator must assess, based on spatial or other plant conditions, whether the danger potential usually associated with the state of technology is exceeded, e.g.:

- Particularly narrow maintenance spaces
- Particularly exposed position of hot surfaces

In such cases, the plant integrator or operator must equip the plant with the necessary and suitable safety devices to reliably exclude the possibility of personal injury, e.g.:

- Heat shields
- Insulation

The operator must ensure that the plant is not operated without these protective devices. Operating and maintenance personnel must be informed about the danger of hot surfaces and the prohibition of operation without the protective devices.

Noise

Noise protection measures that comply with statutory requirements must be implemented by the plant integrator and operator.

Chemical resistance

Only use hoses, pipes, fittings, etc. that can tolerate the fluids and lubricants in accordance with the Fluids and Lubricants Specifications. Only use options that are resistant to the fluids and lubricants in accordance with the Fluids and Lubricants Specifications.

Electrical devices

The IP protection class of the electrical devices required by the manufacturer must be observed.

Hoses

For vibration decoupling, where possible only use hoses or rubber sleeves. Install devices in low-vibration areas and not on the engine. Hoses must be installed such that they do not chafe and are not under tension.

Incorrect synchronization

Load application with incorrect synchronization (generator connection with phase offset) can cause considerably high torque pulses. The plant integrator must design the control system such that the possibility of a load application with incorrect synchronization is excluded.

Emergency stop

The diesel engine has inputs for Stop and Emergency stop. The emergency-stop function must be executable in the whole plant independently of the operation stop. This is the only way to ensure that a safe shutdown of fuel injection takes place on a diverse redundant path and thus results in engine standstill. Through an appropriate design of the engine-generator set or whole plant, the operator of the engine must guarantee that safe, non-reversible stopping of the engine is as fast as possible, including all of its dangerous system components, when the emergency-stop actuating element is activated. In particular, it must always be guaranteed that machine shutdown can not be prevented or delayed once the command for shutdown has been issued. The engine shutdown command must always have priority over the start command.

If machines or machine components are designed to interact, they must be designed and built such that all devices can shut down. This relates to:

- Emergency-stop command devices for the machine itself (engine, engine-generator set)
- All connected devices insofar as their continued operation could result in a hazard

Important

Engines with exhaust aftertreatment: When the emergency stop is actuated on engine with an exhaust aftertreatment system, note that the emergency-stop function also interrupts the reducing agent supply. This can result in overheating of the reducing agent dosing units. For details and further information, see Operating Instructions.