

Technical Documentation

Diesel Engine

12 V 2000 G44-TB

12 V 2000 G84-TB

16 V 2000 G44-TB

16 V 2000 G84-TB

Application Group 3D

Operating Instructions

MS15014/01E



Printed in Germany

© 2008 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services. This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

Wichtig – Important – Importante

Bitte die Karte „Inbetriebnahmemeldung“ abtrennen und ausgefüllt an MTU Friedrichshafen GmbH zurücksenden.

Die Informationen der Inbetriebnahmemeldung sind Grundlage für den vertraglich vereinbarten Logistik-Support (Gewährleistung, Ersatzteile etc.).

Please complete and return the “Commissioning Note” card below to MTU Friedrichshafen GmbH.

The Commissioning Note information serves as a basis for the contractually agreed logistic support (warranty, spare parts, etc.).

Veillez séparer la carte “Signalisation de mise en service” et la renvoyer à la MTU Friedrichshafen GmbH.

Les informations contenues dans la signalisation de mise en service constituent la base pour l'assistance en exploitation contractuelle (garantie, rechanges, etc.).

Rogamos separar la tarjeta “Aviso de puesta en servicio” y la devuelvan rellena a MTU Friedrichshafen GmbH.

Las informaciones respecto al aviso de puesta en servicio constituyen la base para el soporte logístico contractual (garantía, piezas de repuesto, etc.).

Ritagliare “Avviso di messa in servizio” e rispedirlo debitamente compilato alla MTU Friedrichshafen GmbH.

Le informazioni ivi registrate sono la base per il supporto logistico contrattuale (garanzia, ricambi, ecc.).

É gentileza cortar o cartão “Participação da colocação em serviço”, preenché-lo e devolvê-lo a MTU Friedrichshafen.

Os dados referentes à colocação em serviço representam a base para o suporte logístico (garantia, peças sobressalentes, etc.) estabelecido contratualmente.



Postcard

MTU Friedrichshafen GmbH
Department MST
88040 Friedrichshafen
GERMANY

Bitte in Blockschrift ausfüllen!
Please use block capitals!
Prière de remplir en lettres capitales!
¡A rellenar en letras de imprenta!
Scrivere in stampatello!
Favor preencher com letras de forma!



Motomr.: Engine No.: N° du moteur: N° de motor: Motore N.: No. do motor:

Auftragsnr.: MTU works order No.: N° de commande: N° de pedido: N. commessa: No. do pedido:
--

**Inbetriebnahme-
meldung**

**Commissioning
Note**

**Notice de mise
en service**

**Aviso de puesta
en servicio**

**Avviso di messa
in servizio**

**Participação da
colocação em
serviço**

Motortyp: Engine model: Type du moteur: Tipo de motor: Motore tipo: Tipo do motor:

Inbetriebnahmedatum: Date put into operation: Mise en service le: Fecha de puesta en servicio: Messa in servizio il: Data da colocação em serviço:

Eingebaut in: Installation site: Lieu de montage: Lugar de montaje: Installato: Incorporado em:
--

Schiffstyp / Schiffshersteller: Vessel/type/class / Shipyard: Type du bateau / Constructeur: Tipo de buque / Constructor: Tipo di barca / Costruttore Tipo de embarcação/estaleiro naval:
--

Endabnehmer/Anschrift: End user's address: Adresse du client final: Dirección del cliente final: Indirizzo del cliente finale: Usuário final/endereço:

Bemerkung: Remarks: Remarques: Observaciones: Commento: Observações:

1	Safety	05
1.1	General conditions	05
1.2	Personnel and organizational requirements	06
1.3	Transport	07
1.4	Safety requirements when working on the engine	08
1.5	Auxiliary materials, fire prevention and environmental protection	11
1.6	Standards for warning notices in the publication	13
2	Product Summary	15
2.1	Engine Overview	15
2.1.1	Engine layout	15
2.2	Engine Side and Cylinder Designations	17
2.2.1	Engine side and cylinder designations	17
2.3	Main Engine Dimensions	18
2.3.1	Engine – Main dimensions	18
2.4	Firing Sequence	19
2.4.1	Firing order	19
2.5	Technical Data	20
2.5.1	12/16/V 2000 Gx4 engine data	20
3	Operation	25
3.1	Putting the engine into operation after extended out-of-service periods (>3 months)	25
3.2	Putting the engine into operation after scheduled out-of-service-period	26
3.3	Start engine in manual mode (testing mode)	27
3.4	Bypassing the safety system (Override)	28
3.5	Operational checks	29
3.6	Stop engine in manual mode (testing mode)	30
3.7	Emergency stop	31
3.8	After stopping the engine – engine remains ready for operation	32
3.9	After stopping the engine – putting the engine out of service	33
3.10	Plant – Cleaning	34
4	Maintenance	35
4.1	Preface	35
4.2	Maintenance schedule matrix	36
4.3	Maintenance tasks	38
5	Troubleshooting	41
5.1	Troubleshooting	41

5.2	Fault indication on SAM display – Genset applications	44
6	Task Description	69
6.1	Engine	69
6.1.1	Engine – Barring manually	69
6.1.2	Engine - Barring with starting system	70
6.1.3	Engine test run	71
6.2	Cylinder Liner	72
6.2.1	Cylinder liner – Endoscopic examination	72
6.2.2	Instructions and comments on endoscopic and visual examination of cylinder liners	74
6.3	Crankcase Ventilation	76
6.3.1	Crankcase breather – Oil separator replacement, diaphragm check and replacement	76
6.3.2	Crankcase breather – Wire mesh cleaning	78
6.4	Valve Drive	80
6.4.1	Valve clearance – Check and adjustment	80
6.4.2	Cylinder-head cover – Removal and installation	83
6.5	Injection Pump / HP Pump	84
6.5.1	Injection pump replacement	84
6.5.2	Injection pump – Removal and installation	85
6.6	Injector	88
6.6.1	Injector – Replacement	88
6.6.2	Injector – Removal and installation	89
6.7	Fuel System	92
6.7.1	Fuel pressure maintaining valve – Removal and installation	92
6.7.2	HP fuel line and pressure pipe neck – Replacement	93
6.7.3	Fuel – Draining	95
6.7.4	Fuel system – Venting	96
6.8	Fuel Filter	98
6.8.1	Fuel filter – Replacement	98
6.8.2	Fuel prefilter cleaning	99
6.8.3	Fuel prefilter – differential pressure check and adjustment of gauge	100
6.8.4	Fuel prefilter – draining	101
6.8.5	Fuel prefilter – flushing	103
6.8.6	Fuel prefilter – filter element replacement	105
6.9	Charge-air Cooling	107
6.9.1	Intercooler – Checking condensate drains for coolant discharge and obstructions	107
6.10	Air Filter	108
6.10.1	Air filter – Replacement	108
6.10.2	Air filter – Removal and installation	109
6.11	Air Intake	110
6.11.1	Service indicator – Signal ring position check	110
6.12	Starting Equipment	111
6.12.1	Air starter – manual operation	111

6.13	Lube-oil System, Lube-oil Circuit	112
6.13.1	Engine oil – Level check	112
6.13.2	Engine oil – Change	113
6.14	Oil Filtration / Cooling	114
6.14.1	Engine oil filter – Replacement	114
6.15	Coolant Circuit, General, HT Circuit	115
6.15.1	Engine coolant – Level check	115
6.15.2	Engine coolant – Change	116
6.15.3	Engine coolant – Draining	117
6.15.4	Engine coolant filling	118
6.15.5	Coolant pump – Relief bore check	119
6.16	LT Circuit	120
6.16.1	Charge-air coolant level check	120
6.16.2	Charge-air coolant change	121
6.16.3	Charge-air coolant – Draining	122
6.16.4	Charge-air coolant filling	123
6.17	Generator	124
6.17.1	Battery-charging generator drive – Drive-belt check and adjustment	124
6.17.2	Battery-charging generator drive – Drive belt replacement	126
6.18	Ventilator Drive	127
6.18.1	Ventilator drive – Drive-belt check and adjustment	127
6.18.2	Ventilator drive – Drive belt replacement	129
6.19	General Wiring for Engine / Gearbox / Genset	130
6.19.1	Engine wiring – Check	130
6.19.2	Sensors and actuators	131
6.20	Accessories for Engine Governor (Electronic) / Control System	132
6.20.1	Engine governor and connectors – Cleaning	132
6.20.2	Engine governor plug-in connections – Check	133
6.20.3	Engine governor – Removal and installation	134
7	Special Tools	135
7.1	Special tools	135
8	Appendix	147
8.1	Manufacturer's documentation	147
8.2	MTU-contact person/service partner	148
8.3	Abbreviations	149
8.4	Index	153

1 Safety

1.1 General conditions

General

In addition to the instructions in this publication, the applicable country-specific legislation and other compulsory regulations regarding accident prevention must be observed. This engine is a state-of-the art product and conforms with all applicable specifications and regulations. Nevertheless, persons and property may be at risk in the event of:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Modifications or conversions
- Non-compliance with the Safety Instructions

Correct use

The engine is intended exclusively for the application specified in the contract or defined at the time of delivery. Any other use is considered improper use. The manufacturer will accept no liability for any resultant damage. The responsibility is borne by the user alone.

Correct use also includes observation of and compliance with the maintenance specifications.

Modifications or Conversions

Modifications made by the customer to the engine may affect safety.

MTU will accept no liability or warranty claims for any damage caused by unauthorized modifications or conversions.

Spare parts

Only genuine MTU spare parts must be used to replace components or assemblies. In the event of any damage caused by the use of other spare parts, no liability nor warranty claims vis-à-vis the engine manufacturer will be accepted.

1.2 Personnel and organizational requirements

Personnel

Work on the engine must only be carried out by properly qualified and instructed personnel.

The specified legal minimum age must be observed.

Responsibilities of the operating, maintenance and repair personnel must be specified.

Organization

This publication must be issued to all personnel involved in operation, maintenance, repair or transportation.

It must be kept at hand near the engine and accessible at any time to all personnel involved in operation, maintenance, repair or transportation.

The personnel must be instructed on engine operation and repair by means of this publication, and in particular the safety instructions must be explained.

This is especially important for personnel who work on the engine only on an occasional basis. Such personnel must be given instructions repeatedly.

Working clothes and protective equipment

Wear proper work clothing for all work.

Depending on the kind of work, use additional protective equipment, e.g. protective goggles, gloves, helmet, apron.

Work clothing must be tight fitting so that it does not catch on rotating or projecting components.

Do not wear jewelry (e.g. rings, chains etc.).