



Operating Instructions

Diesel engine

12V2000G65, G65-TB

16V2000G65, G65-TB

18V2000G65, G65-TB

Application group 3A

MS15018/05E

Engine model	kW/cyl.	Application group
12V2000G65	42.9 kW/cyl.	3A, heavy duty, unrestricted, ICXN
12V2000G65-TB	42.9 kW/cyl.	3A, heavy duty, unrestricted, ICXN
16V2000G65	40.9 kW/cyl.	3A, heavy duty, unrestricted, ICXN
16V2000G65-TB	40.9 kW/cyl.	3A, heavy duty, unrestricted, ICXN
18V2000G65	40.0 kW/cyl.	3A, heavy duty, unrestricted, ICXN
18V2000G65-TB	40.0 kW/cyl.	3A, heavy duty, unrestricted, ICXN

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.



WARNING: Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1	Preface		6.6	Operational checks	45
1.1	Preface	7	6.7	Engine - Stopping in manual mode (test run)	46
2	Safety		6.8	Engine - Emergency stop	48
2.1	Important provisions for all products	8	6.9	After stopping the engine - Engine remains ready for operation	49
2.2	Important requirements for Power Generation application products	9	6.10	After shutting down engine - Putting engine out of operation	50
2.3	Intended use of all products	11	7	Maintenance	
2.4	Personnel and organizational requirements	12	7.1	Maintenance task reference table [QL1]	51
2.5	Safety regulations for commissioning and operation	13	8	Troubleshooting	
2.6	Safety regulations for assembly, maintenance, and repair work	15	8.1	Fault indication on SAM display - Genset applications	52
2.7	Fire and environmental protection, indirect materials	19	8.2	Troubleshooting	76
2.8	Standards for warning notices in the text and highlighted information	22	9	Task Description	
3	Transport		9.1	Engine	79
3.1	Transport	23	9.1.1	Engine - Barring manually	79
3.2	Lifting specifications	24	9.1.2	Engine - Barring with starting system	80
4	General Information		9.1.3	Engine - Test run	81
4.1	Engine side and cylinder designations	25	9.2	Cylinder Liner	82
4.2	Engine overview	26	9.2.1	Cylinder liner - Endoscopic examination	82
4.3	Sensors and actuators - Overview	28	9.2.2	Cylinder liner - Instructions and comments on endoscopic and visual examination	84
5	Technical Data		9.3	Crankcase Breather	86
5.1	12/16/18V2000G65 engine data, fuel optimized	30	9.3.1	Crankcase breather - Wire mesh cleaning	86
5.2	12/16/18V2000G65-TB engine data, fuel optimized	34	9.3.2	Crankcase breather - Oil separator replacement, diaphragm check and replacement	87
5.3	Firing order	38	9.4	Valve Drive	89
5.4	Engine - Main dimensions	39	9.4.1	Valve clearance - Check and adjustment	89
6	Operation		9.4.2	Cylinder head cover - Removal and installation	92
6.1	Preparations for putting into operation after extended out-of-service periods (>3 months)	40	9.5	Injection Pump / HP Pump	93
6.2	Preparations for putting into operation after scheduled out-of-service-period	41	9.5.1	Injection pump - Replacement	93
6.3	Starting the engine in manual mode (test run)	42	9.5.2	Injection pump - Removal and installation	94
6.4	Re-starting the engine following an automatic safety shutdown	43	9.6	Injection Valve / Injector	97
6.5	Safety system - Override	44	9.6.1	Injector - Replacement	97
			9.6.2	Injector - Removal and installation	98
			9.7	Fuel System	104
			9.7.1	HP fuel line - Pressure pipe neck replacement	104
			9.7.2	Fuel - Draining	107
			9.7.3	Fuel pressure relief valve - Removal and installation	109
			9.7.4	Fuel system - Venting	110

9.8 Fuel Filter	113	9.16.2 Charge-air coolant - Draining	141
9.8.1 Fuel filter - Replacement	113	9.16.3 Charge-air coolant - Change	143
9.8.2 Fuel prefilter - Differential pressure gauge check and adjustment	114	9.16.4 Charge-air coolant level - Check	144
9.8.3 Fuel prefilter - Draining	115	9.17 Coolant System	146
9.8.4 Fuel prefilter - Flushing	117	9.17.1 Cooler - Checking cooler elements externally for dirt	146
9.8.5 Fuel prefilter - Cleaning	120	9.17.2 Cooler - Cleaning cooler elements	147
9.8.6 Fuel prefilter - Filter element replacement	121	9.18 Battery-Charging Generator	148
9.9 Charge-Air Cooling General, Left-Hand Side	123	9.18.1 Battery-charging generator drive - Drive-belt check and adjustment	148
9.9.1 Intercooler - Checking condensate drain for coolant discharge and obstructions	123	9.18.2 Battery-charging generator drive - Drive belt replacement	150
9.10 Air Filter	124	9.19 Fan Drive	151
9.10.1 Air filter - Replacement	124	9.19.1 Fan drive - Drive-belt check and adjustment	151
9.10.2 Air filter - Removal and installation	125	9.19.2 Fan drive - Drive belt replacement	154
9.11 Air Intake	126	9.20 Wiring (General) for Engine/Gearbox/Unit	155
9.11.1 Service indicator - Signal ring position check	126	9.20.1 Engine cabling - Check	155
9.12 Starting Equipment	127	9.21 Accessories for (Electronic) Engine Governor / Control System	156
9.12.1 Air starter - Manual operation	127	9.21.1 Engine governor and connectors - Cleaning	156
9.13 Lube Oil System, Lube Oil Circuit	128	9.21.2 Engine governor plug connections - Check	157
9.13.1 Engine oil level - Check	128	9.21.3 Engine governor ECU 7 - Removal and installation	158
9.13.2 Engine oil - Change	129		
9.14 Oil Filtration / Cooling	131	10 Appendix A	
9.14.1 Engine oil filter - Replacement	131	10.1 Abbreviations	159
9.15 Coolant Circuit, General, High-Temperature Circuit	132	10.2 Contact person/Service partner	163
9.15.1 Engine coolant - Level check	132		
9.15.2 Engine coolant - Change	134	11 Appendix B	
9.15.3 Engine coolant - Draining	135	11.1 Standard Tools and Special Tools	164
9.15.4 Engine coolant - Filling	136	11.2 Index	171
9.15.5 Coolant pump - Relief bore check	138		
9.16 Low-Temperature Circuit	139		
9.16.1 Charge-air coolant - Filling	139		

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>

2.2 Important requirements for Power Generation application products

Project-specific operational environment

During integration and use of the diesel engine, all currently valid and relevant standards and guidelines on safety and specified operation must be implemented and observed. This applies to persons responsible for:

- The installation of the engine
- The design of the engine-generator set
- The installation of the engine-generator set

The relevant standards are, in particular:

- DIN EN 1679-1
- EN ISO 8528-13

Residual hazards

In the event of a defect, the diesel engine can unexpectedly have insufficient or no drive power at all. We therefore recommend a redundant design of the engine-generator set system in safety-critical applications.

Protection against hot surfaces

Combustion engines and their auxiliary components have hot surfaces (e.g. exhaust system, exhaust turbochargers, exhaust aftertreatment system, engine oil system, cooling system), which can cause injury to persons who approach or touch them (danger of burns).

- In operation
- During the cooling-down phase after operation

The plant integrator and operator must assess, based on spatial or other plant conditions, whether the danger potential usually associated with the state of technology is exceeded, e.g.:

- Particularly narrow maintenance spaces
- Particularly exposed position of hot surfaces

In such cases, the plant integrator or operator must equip the plant with the necessary and suitable safety devices to reliably exclude the possibility of personal injury, e.g.:

- Heat shields
- Insulation

The operator must ensure that the plant is not operated without these protective devices. Operating and maintenance personnel must be informed about the danger of hot surfaces and the prohibition of operation without the protective devices.

Noise

Noise protection measures that comply with statutory requirements must be implemented by the plant integrator and operator.

Chemical resistance

Only use hoses, pipes, fittings, etc. that can tolerate the fluids and lubricants in accordance with the Fluids and Lubricants Specifications. Only use options that are resistant to the fluids and lubricants in accordance with the Fluids and Lubricants Specifications.

Electrical devices

The IP protection class of the electrical devices required by the manufacturer must be observed.

Hoses

For vibration decoupling, where possible only use hoses or rubber sleeves. Install devices in low-vibration areas and not on the engine. Hoses must be installed such that they do not chafe and are not under tension.

Incorrect synchronization

Load application with incorrect synchronization (generator connection with phase offset) can cause considerably high torque pulses. The plant integrator must design the control system such that the possibility of a load application with incorrect synchronization is excluded.

Emergency stop

The diesel engine has inputs for Stop and Emergency stop. The emergency-stop function must be executable in the whole plant independently of the operation stop. This is the only way to ensure that a safe shutdown of fuel injection takes place on a diverse redundant path and thus results in engine standstill. Through an appropriate design of the engine-generator set or whole plant, the operator of the engine must guarantee that safe, non-reversible stopping of the engine is as fast as possible, including all of its dangerous system components, when the emergency-stop actuating element is activated. In particular, it must always be guaranteed that machine shutdown can not be prevented or delayed once the command for shutdown has been issued. The engine shutdown command must always have priority over the start command.

If machines or machine components are designed to interact, they must be designed and built such that all devices can shut down. This relates to:

- Emergency-stop command devices for the machine itself (engine, engine-generator set)
- All connected devices insofar as their continued operation could result in a hazard

Important

Engines with exhaust aftertreatment: When the emergency stop is actuated on engine with an exhaust aftertreatment system, note that the emergency-stop function also interrupts the reducing agent supply. This can result in overheating of the reducing agent dosing units. For details and further information, see Operating Instructions.