



Operating Instructions

Diesel engine

12V2000Gx5, Gx5 TB

16V2000Gx5, Gx5 TB

18V2000Gx5, Gx5 TB

Application group 3B

MS15019/07E

Engine model	kW/cyl.	Application group *
12V2000G25	48.3 kW/cyl.	3B
12V2000G25-TB	48.3 kW/cyl.	3B
12V2000G45	59.2 kW/cyl.	3B
12V2000G45-TB	59.2 kW/cyl.	3B
12V2000G65	57.9 kW/cyl.	3B
12V2000G65-TB	57.9 kW/cyl.	3B
12V2000G85	67.5 kW/cyl.	3B
12V2000G85-TB	67.5 kW/cyl.	3B
16V2000G25	50.6 kW/cyl.	3B
16V2000G25-TB	50.6 kW/cyl.	3B
16V2000G45	57.2 kW/cyl.	3B
16V2000G45-TB	57.2 kW/cyl.	3B
16V2000G65	55.6 kW/cyl.	3B
16V2000G65-TB	55.6 kW/cyl.	3B
16V2000G85	63.1 kW/cyl.	3B
16V2000G85-TB	63.1 kW/cyl.	3B
18V2000G65	55.6 kW/cyl.	3B
18V2000G65-TB	55.6 kW/cyl.	3B
18V2000G85	66.2 kW/cyl.	3B
18V2000G85-TB	66.2 kW/cyl.	3B
* 3B Continuous operation, variable load, ICXN		

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.



WARNING: Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1	Preface		
1.1	Preface	7	
2	Safety		
2.1	Important provisions for all products	8	
2.2	Important requirements for Power Generation application products	9	
2.3	Intended use of all products	11	
2.4	Personnel and organizational requirements	12	
2.5	Safety regulations for commissioning and operation	13	
2.6	Safety regulations for assembly, maintenance, and repair work	15	
2.7	Fire and environmental protection, indirect materials	19	
2.8	Standards for warning notices in the text and highlighted information	22	
3	Transport		
3.1	Transport	23	
3.2	Lifting specifications	24	
4	General Information		
4.1	Engine side and cylinder designations	25	
4.2	Engine overview	26	
4.3	Sensors and actuators - Overview	28	
5	Technical Data		
5.1	12/16/18V2000Gx5 engine data, fuel optimized	30	
5.2	12/16/18V2000Gx5-TB engine data, fuel optimized	35	
5.3	12V2000Gx5, engine data, emissions optimized	40	
5.4	16/18V2000Gx5 engine data, emissions optimized	44	
5.5	12/16/18V2000Gx5-TB engine data, emissions optimized	50	
5.6	Firing order	55	
5.7	Engine - Main dimensions	56	
6	Operation		
6.1	Preparations for putting into operation after extended out-of-service periods (>3 months)	57	
6.2	Preparations for putting into operation after scheduled out-of-service-period	58	
6.3	Starting the engine in manual mode (test run)	59	
6.4	Re-starting the engine following an automatic safety shutdown	60	
6.5	Safety system - Override	61	
6.6	Operational checks	62	
6.7	Engine - Stopping in manual mode (test run)	63	
6.8	Engine - Emergency stop	65	
6.9	After stopping the engine - Engine remains ready for operation	66	
6.10	After shutting down engine - Putting engine out of operation	67	
7	Maintenance		
7.1	Maintenance task reference table [QL1]	68	
8	Troubleshooting		
8.1	Fault indication on SAM display - Genset applications	69	
8.2	Troubleshooting	93	
9	Task Description		
9.1	Engine	96	
9.1.1	Engine - Barring manually	96	
9.1.2	Engine - Barring with starting system	97	
9.1.3	Engine - Test run	98	
9.2	Cylinder Liner	99	
9.2.1	Cylinder liner - Endoscopic examination	99	
9.2.2	Cylinder liner - Instructions and comments on endoscopic and visual examination	101	
9.3	Crankcase Breather	103	
9.3.1	Crankcase breather - Oil separator replacement, diaphragm check and replacement	103	
9.3.2	Crankcase breather - Wire mesh cleaning	105	
9.4	Valve Drive	106	
9.4.1	Valve clearance - Check and adjustment	106	
9.4.2	Cylinder head cover - Removal and installation	109	
9.5	Injection Pump / HP Pump	110	
9.5.1	Injection pump - Replacement	110	
9.5.2	Injection pump - Removal and installation	111	
9.6	Injection Valve / Injector	114	
9.6.1	Injector - Replacement	114	

9.6.2	Injector - Removal and installation	115	9.15.2	Engine coolant - Change	151
9.7	Fuel System	121	9.15.3	Engine coolant - Draining	152
9.7.1	HP fuel line - Pressure pipe neck replacement	121	9.15.4	Engine coolant - Filling	153
9.7.2	Fuel - Draining	124	9.15.5	Coolant pump - Relief bore check	155
9.7.3	Fuel pressure relief valve - Removal and installation	126	9.16	Low-Temperature Circuit	156
9.7.4	Fuel system - Venting	127	9.16.1	Charge-air coolant - Filling	156
9.8	Fuel Filter	130	9.16.2	Charge-air coolant - Draining	158
9.8.1	Fuel filter - Replacement	130	9.16.3	Charge-air coolant - Change	160
9.8.2	Fuel prefilter - Differential pressure gauge check and adjustment	131	9.16.4	Charge-air coolant level - Check	161
9.8.3	Fuel prefilter - Draining	132	9.17	Battery-Charging Generator	163
9.8.4	Fuel prefilter - Flushing	134	9.17.1	Battery-charging generator drive - Drive-belt check and adjustment	163
9.8.5	Fuel prefilter - Cleaning	137	9.17.2	Battery-charging generator drive - Drive belt replacement	165
9.8.6	Fuel prefilter - Filter element replacement	138	9.18	Fan Drive	166
9.9	Charge-Air Cooling General, Left-Hand Side	140	9.18.1	Fan drive - Drive-belt check and adjustment	166
9.9.1	Intercooler - Checking condensate drain for coolant discharge and obstructions	140	9.18.2	Fan drive - Drive belt replacement	169
9.10	Air Filter	141	9.19	Wiring (General) for Engine/Gearbox/Unit	170
9.10.1	Air filter - Replacement	141	9.19.1	Engine cabling - Check	170
9.10.2	Air filter - Removal and installation	142	9.20	Accessories for (Electronic) Engine Governor / Control System	171
9.11	Air Intake	143	9.20.1	Engine governor and connectors - Cleaning	171
9.11.1	Service indicator - Signal ring position check	143	9.20.2	Engine governor plug connections - Check	172
9.12	Starting Equipment	144	9.20.3	Engine governor ECU 7 - Removal and installation	173
9.12.1	Air starter - Manual operation	144	10	Appendix A	
9.13	Lube Oil System, Lube Oil Circuit	145	10.1	Abbreviations	174
9.13.1	Engine oil level - Check	145	10.2	Contact person/Service partner	177
9.13.2	Engine oil - Change	146	11	Appendix B	
9.14	Oil Filtration / Cooling	148	11.1	Standard Tools and Special Tools	178
9.14.1	Engine oil filter - Replacement	148	11.2	Index	185
9.15	Coolant Circuit, General, High-Temperature Circuit	149			
9.15.1	Engine coolant - Level check	149			

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>

2.2 Important requirements for Power Generation application products

Project-specific operational environment

During integration and use of the diesel engine, all currently valid and relevant standards and guidelines on safety and specified operation must be implemented and observed. This applies to persons responsible for:

- The installation of the engine
- The design of the engine-generator set
- The installation of the engine-generator set

The relevant standards are, in particular:

- DIN EN 1679-1
- EN ISO 8528-13

Residual hazards

In the event of a defect, the diesel engine can unexpectedly have insufficient or no drive power at all. We therefore recommend a redundant design of the engine-generator set system in safety-critical applications.

Protection against hot surfaces

Combustion engines and their auxiliary components have hot surfaces (e.g. exhaust system, exhaust turbochargers, exhaust aftertreatment system, engine oil system, cooling system), which can cause injury to persons who approach or touch them (danger of burns).

- In operation
- During the cooling-down phase after operation

The plant integrator and operator must assess, based on spatial or other plant conditions, whether the danger potential usually associated with the state of technology is exceeded, e.g.:

- Particularly narrow maintenance spaces
- Particularly exposed position of hot surfaces

In such cases, the plant integrator or operator must equip the plant with the necessary and suitable safety devices to reliably exclude the possibility of personal injury, e.g.:

- Heat shields
- Insulation

The operator must ensure that the plant is not operated without these protective devices. Operating and maintenance personnel must be informed about the danger of hot surfaces and the prohibition of operation without the protective devices.

Noise

Noise protection measures that comply with statutory requirements must be implemented by the plant integrator and operator.

Chemical resistance

Only use hoses, pipes, fittings, etc. that can tolerate the fluids and lubricants in accordance with the Fluids and Lubricants Specifications. Only use options that are resistant to the fluids and lubricants in accordance with the Fluids and Lubricants Specifications.

Electrical devices

The IP protection class of the electrical devices required by the manufacturer must be observed.

Hoses

For vibration decoupling, where possible only use hoses or rubber sleeves. Install devices in low-vibration areas and not on the engine. Hoses must be installed such that they do not chafe and are not under tension.

Incorrect synchronization

Load application with incorrect synchronization (generator connection with phase offset) can cause considerably high torque pulses. The plant integrator must design the control system such that the possibility of a load application with incorrect synchronization is excluded.

Emergency stop

The diesel engine has inputs for Stop and Emergency stop. The emergency-stop function must be executable in the whole plant independently of the operation stop. This is the only way to ensure that a safe shutdown of fuel injection takes place on a diverse redundant path and thus results in engine standstill. Through an appropriate design of the engine-generator set or whole plant, the operator of the engine must guarantee that safe, non-reversible stopping of the engine is as fast as possible, including all of its dangerous system components, when the emergency-stop actuating element is activated. In particular, it must always be guaranteed that machine shutdown can not be prevented or delayed once the command for shutdown has been issued. The engine shutdown command must always have priority over the start command.

If machines or machine components are designed to interact, they must be designed and built such that all devices can shut down. This relates to:

- Emergency-stop command devices for the machine itself (engine, engine-generator set)
- All connected devices insofar as their continued operation could result in a hazard

Important

Engines with exhaust aftertreatment: When the emergency stop is actuated on engine with an exhaust aftertreatment system, note that the emergency-stop function also interrupts the reducing agent supply. This can result in overheating of the reducing agent dosing units. For details and further information, see Operating Instructions.