



Operating Instructions

Diesel engine

16V2000G26S

16V2000G76S

16V2000G86S

Stationary Emergency only

Application group 3B, 3D, 3F, 3G

MS15054/07E



A Rolls-Royce
solution

Engine model	kW/cyl.	Application group
16V2000G26S	62.4 kW/cyl.	3B, Continuous operation, variable load, ICXN 3F, Mains backup mode, unlimited, ICXN 3G, Prime power, time-limited, ICXN
16V2000G76S	68.6 kW/cyl.	3D, Emergency Standby power, IFN
16V2000G86S	85.7 kW/cyl.	3D, Emergency Standby power, IFN

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to §15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.



WARNING: Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1	Preface	
1.1	Preface	8
2	Safety	
2.1	Important provisions for all products	9
2.2	Important requirements for Power Generation application products	10
2.3	Intended use of all products	12
2.4	Personnel and organizational requirements	13
2.5	Safety regulations for commissioning and operation	14
2.6	Safety regulations for assembly, maintenance, and repair work	16
2.7	Fire and environmental protection, indirect materials	20
2.8	Standards for warning messages in the text and highlighted information	23
3	Transport	
3.1	Transport	24
4	General Information	
4.1	Engine side and cylinder designations	25
4.2	Engine overview	26
4.3	Sensors and actuators – Overview	27
4.4	Data acquisition and data transmission	31
5	Technical Data	
5.1	Product data 16V2000Gx6S, 3D, emergency standby power, IFN, fuel optimized	32
5.2	Product data 16V2000Gx6S, 3B, continuous operation, variable load, ICXN, fuel-consumption optimized	36
5.3	Product data 12V/16V2000Gx6S, 3F, mains backup mode, unlimited, ICXN, optimized fuel consumption	39
5.4	Product data 16V2000Gx6S, 3G, prime power, time-limited, ICXN, fuel-consumption optimized	42
5.5	Product data 16V2000Gx6S, 3G, prime power, time-limited, ICXN, EPA Nonroad T2 (40CFR89)	45
5.6	Product data 16V2000Gx6S, 3B, continuous operation, variable load, ICXN, EPA Nonroad T2 (40CFR89)	48
5.7	Product data 16V2000Gx6S, 3D, emergency standby power, IFN, EPA Nonroad T2 (40CFR89) and EPA Stationary EMERG T2 (40CFR60)	51
5.8	Product data 16V2000Gx6S, 3E, emergency service, ICXN, EPA Stationary EMERG T2 (40CFR60)	55
5.9	Product data 12V/16V2000Gx6S, 3F, mains backup mode, unlimited, ICXN, EPA Nonroad T2 (40CFR89) and EPA Stationary EMERG T2 (40CFR60)	58
5.10	Firing order	62
5.11	Engine – Main dimensions	63
6	Operation	
6.1	Preparations for putting into operation after extended out-of-service periods (>3 months)	64
6.2	Preparations for putting into operation after scheduled out-of-service-period	65
6.3	Engine – Starting	66
6.4	Re-starting the engine following an automatic safety shutdown	67
6.5	Operational checks	68
6.6	Emission label – Check	69
6.7	Engine shutdown	70
6.8	Emergency engine shutdown	71
6.9	After shutting down the engine	72
6.10	Plant – Cleaning	73
7	Maintenance	
7.1	Maintenance task reference table [QL1]	75
8	Troubleshooting	
8.1	Troubleshooting	77
8.2	Engine Control Unit – ECU9 fault messages	80
9	Task Description	
9.1	Engine	108
9.1.1	Engine – Test run	108
9.1.2	Engine – Barring manually	109
9.1.3	Engine – Barring with starting system	110
9.2	Cylinder Liner	111
9.2.1	Cylinder liner – Instructions and comments on endoscopic and visual examination	111

9.2.2	Cylinder liner – Endoscopic examination	113	9.12	Lube Oil System, Lube Oil Circuit	167
9.3	Crankcase Breather	115	9.12.1	Engine oil level – Check	167
9.3.1	Crankcase breather – Oil mist separator replacement	115	9.12.2	Engine oil – Change	168
9.4	Fan Drive	116	9.13	Oil Filtration / Cooling	170
9.4.1	Drive belt – Condition check	116	9.13.1	Engine oil filter – Replacement	170
9.4.2	Drive belt – Tension check	117	9.14	Coolant Circuit, General, High-Temperature Circuit	171
9.4.3	Drive belt – Tension adjustment	119	9.14.1	Engine coolant – Level check	171
9.4.4	Drive belt – Replacement	120	9.14.2	Engine coolant – Change	173
9.5	Valve Drive	121	9.14.3	Engine coolant – Draining	174
9.5.1	Valve clearance – Check and adjustment	121	9.14.4	Engine coolant – Filling	175
9.5.2	Cylinder head cover – Cylinder head cover	124	9.14.5	Engine coolant pump – Relief bore check	177
9.6	Injector	126	9.14.6	Engine coolant – Sample extraction and analysis	178
9.6.1	Injector – Replacement	126	9.14.7	Coolant expansion tank – Valve cover replacement	179
9.6.2	Injector – Removal and installation	127	9.15	Low-Temperature Circuit	181
9.6.3	Injector functions	132	9.15.1	Charge-air coolant – Filling	181
9.7	Fuel System	133	9.15.2	Charge-air coolant – Draining	183
9.7.1	HP fuel line and pressure pipe neck – Replacement	133	9.15.3	Charge-air coolant – Change	184
9.7.2	Fuel system – Venting	136	9.15.4	Charge-air coolant level – Check	185
9.7.3	Fuel – Draining	137	9.15.5	Charge-air coolant pump – Relief bore check	187
9.7.4	Fuel cooler – External contamination and leak-tightness check	138	9.15.6	Intercooler – Checking condensate drain for coolant discharge and obstructions	188
9.7.5	Fuel cooler – Cleaning	139	9.16	Battery-Charging Generator	189
9.8	Fuel Filter	141	9.16.1	Drive belt – Condition check	189
9.8.1	Fuel filter – Replacement	141	9.16.2	Drive belt – Tension check	190
9.8.2	Fuel prefilter – Draining	142	9.16.3	Drive belt – Tension adjustment	192
9.8.3	Fuel prefilter (non-switchable) – Draining	143	9.16.4	Drive belt – Replacement	193
9.8.4	Fuel prefilter (switchable) – Draining	146	9.17	Preheater	194
9.8.5	Fuel prefilter – Pressure ratios	149	9.17.1	Preheater – Overhaul	194
9.8.6	Fuel prefilter (switchable) – Low pressure indicator check	150	9.17.2	Preheater – Function and leak check	195
9.8.7	Fuel prefilter (non-switchable) – Filter element replacement	151	9.17.3	Preheater – Heating element and housing check	196
9.8.8	Fuel prefilter (switchable) – Filter element replacement	153	9.17.4	Preheater – Heating element and housing check	199
9.8.9	Fuel prefilter – Venting	156	9.17.5	Preheater – Heating element and housing check	202
9.9	Air Filter	158	9.17.6	Preheater – Solenoid switch replacement	205
9.9.1	Air filter – Replacement	158	9.17.7	Preheater – Solenoid switch replacement	207
9.9.2	Air filter – Removal and installation	159	9.17.8	Preheater – Solenoid switch replacement	209
9.10	Air Intake	160	9.17.9	Preheater thermostats – Replacement	211
9.10.1	Service indicator – Signal ring position check	160	9.17.10	Preheater thermostats – Replacement	214
9.11	Starting Equipment	161	9.17.11	Preheater thermostats – Replacement	217
9.11.1	Electric starter – Overview	161	9.18	Engine Mounting / Support	220
9.11.2	Starter – Removal	162	9.18.1	Engine mounting – Checking securing screws for firm seating	220
9.11.3	Starter – Installation	163	9.18.2	Engine mounting – Checking condition of resilient mounts	221
9.11.4	Pneumatic starter – Overview	164	9.19	Generator	222
9.11.5	Starter – Removal	165			
9.11.6	Starter – Installation	166			

9.19.1	Generator mounting – Checking condition of resilient mounts	222	9.22	Accessories for (Electronic) Engine Governor / Control System	228
9.19.2	Generator mounting – Checking firm seating of securing screws	223	9.22.1	Engine governor and connectors – Cleaning	228
9.20	Engine Governor	224	10	Appendix A	
9.20.1	Engine Control Unit – Overview	224	10.1	Abbreviations	229
9.20.2	Engine Control Unit – Removal and installation	225	10.2	Contact person / Service partner	231
9.20.3	Engine governor plug connections – Check	226	11	Appendix B	
9.21	Wiring (General) for Engine/Gearbox/Unit	227	11.1	Standard Tools and Special Tools	232
9.21.1	Engine cabling – Check	227	11.2	Index	242

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at: <http://www.mtu-solutions.com>

2.2 Important requirements for Power Generation application products

Project-specific operational environment

During integration and use of the diesel engine, all currently valid and relevant standards and guidelines on safety and specified operation must be implemented and observed. This applies to persons responsible for:

- The installation of the engine
- The design of the engine-generator set
- The installation of the engine-generator set

The relevant standards are, in particular:

- DIN EN 1679-1
- EN ISO 8528-13

Residual hazards

In the event of a defect, the diesel engine can unexpectedly have insufficient or no drive power at all. We therefore recommend a redundant design of the engine-generator set system in safety-critical applications.

Protection against hot surfaces

Combustion engines and their auxiliary components have hot surfaces (e.g. exhaust system, exhaust turbochargers, exhaust aftertreatment system, engine oil system, cooling system), which can cause injury to persons who approach or touch them (danger of burns).

- In operation
- During the cooling-down phase after operation

The plant integrator and operator must assess, based on spatial or other plant conditions, whether the danger potential usually associated with the state of technology is exceeded, e.g.:

- Particularly narrow maintenance spaces
- Particularly exposed position of hot surfaces

In such cases, the plant integrator or operator must equip the plant with the necessary and suitable safety devices to reliably exclude the possibility of personal injury, e.g.:

- Heat shields
- Insulation

The operator must ensure that the plant is not operated without these protective devices. Operating and maintenance personnel must be informed about the danger of hot surfaces and the prohibition of operation without the protective devices.

Noise

Noise protection measures that comply with statutory requirements must be implemented by the plant integrator and operator.

Chemical resistance

Only use hoses, pipes, fittings, etc. that can tolerate the fluids and lubricants in accordance with the Fluids and Lubricants Specifications. Only use options that are resistant to the fluids and lubricants in accordance with the Fluids and Lubricants Specifications.

Electrical devices

The IP protection class of the electrical devices required by the manufacturer must be observed.

Hoses

For vibration decoupling, where possible only use hoses or rubber sleeves. Install devices in low-vibration areas and not on the engine. Hoses must be installed such that they do not chafe and are not under tension.