



Operating Instructions

Diesel engine
12V2000Gx6x
16V2000Gx6x
18V2000Gx6x

MS15059/04E

Engine model	kW/cyl.	Application group
12V2000G76F	61 kW/cyl.	3D, Emergency Standby power, IFN
12V2000G86F	73,9 kW/cyl.	3D, Emergency Standby power, IFN
16V2000G76F	61,2 kW/cyl.	3D, Emergency Standby power, IFN
16V2000G86F	68,8 kW/cyl.	3D, Emergency Standby power, IFN
18V2000G76F	68,6 kW/cyl.	3D, Emergency Standby power, IFN

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to §15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.



WARNING: Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1 Preface		6.7 Emergency engine shutdown	47
1.1 Preface	7	6.8 After shutting down the engine	48
		6.9 Plant – Cleaning	49
2 Safety		7 Maintenance	
2.1 Important provisions for all products	8	7.1 Maintenance task reference table [QL1]	51
2.2 Important requirements for Power Generation application products	9	8 Troubleshooting	
2.3 Intended use of all products	11	8.1 Troubleshooting	53
2.4 Personnel and organizational requirements	12	8.2 Engine Control Unit – ECU9 fault messages	56
2.5 Safety regulations for commissioning and operation	13	9 Task Description	
2.6 Safety regulations for assembly, maintenance, and repair work	15	9.1 Engine	84
2.7 Fire and environmental protection, indirect materials	19	9.1.1 Engine – Barring manually	84
2.8 Standards for warning messages in the text and highlighted information	22	9.1.2 Engine – Barring with starting system	86
		9.1.3 Engine – Test run	87
3 Transport		9.2 Cylinder Liner	88
3.1 Transport	23	9.2.1 Cylinder liner – Instructions and comments on endoscopic and visual examination	88
		9.2.2 Cylinder liner – Endoscopic examination	90
4 General Information		9.3 Crankcase Breather	92
4.1 Engine side and cylinder designations	24	9.3.1 Crankcase breather – Oil mist separator replacement	92
4.2 Engine – Overview	25	9.4 Valve Drive	93
4.3 Data acquisition and data transmission	31	9.4.1 Valve clearance – Check and adjustment	93
		9.4.2 Cylinder head cover – Cylinder head cover	96
5 Technical Data		9.5 Injection Valve / Injector	98
5.1 Product data 12V2000G76F, 16V2000G76F, 18V2000G76F	32	9.5.1 Injector – Replacement	98
5.2 Product data 12V2000G86F, 16V2000G86F	36	9.5.2 Injector – Removal and installation	99
5.3 Firing order	39	9.5.3 Injector functions	104
5.4 Engine – Main dimensions	40	9.6 Fuel System	105
		9.6.1 HP fuel line and pressure pipe neck – Replacement	105
6 Operation		9.6.2 Fuel system – Venting	108
6.1 Preparations for putting into operation after extended out-of-service periods (>3 months)	41	9.6.3 Fuel – Draining	109
6.2 Preparations for startup after scheduled out-of-service-period	42	9.7 Fuel Filter	110
6.3 Engine – Starting	43	9.7.1 Fuel filter – Replacement	110
6.4 Re-starting the engine following an automatic safety shutdown	44	9.7.2 Fuel prefilter (switchable) – Low pressure indicator check	111
6.5 Operational monitoring	45	9.7.3 Fuel prefilter – Pressure ratios	112
6.6 Engine shutdown	46	9.7.4 Fuel prefilter (non-switchable) – Draining	113
		9.7.5 Fuel prefilter (switchable) – Draining	116
		9.7.6 Fuel prefilter (non-switchable) – Filter element replacement	119

9.7.7 Fuel prefilter (switchable) – Filter element replacement	121	9.15.4 Drive belt – Replacement	163
9.7.8 Fuel prefilter – Venting	124	9.16 Battery-Charging Generator	164
9.8 Air Filter	126	9.16.1 Drive belt – Condition check	164
9.8.1 Air filter – Replacement	126	9.16.2 Drive belt – Tension check	165
9.8.2 Air filter – Removal and installation	127	9.16.3 Drive belt – Tension adjustment	167
9.9 Air Intake	128	9.16.4 Drive belt – Replacement	168
9.9.1 Service indicator – Signal ring position check	128	9.17 Engine Mounting / Support	169
9.10 Starting Equipment	129	9.17.1 Engine mount – Measuring height of rubber element	169
9.10.1 Electric starter – Overview	129	9.17.2 Engine mounting – Checking condition of resilient mounts	170
9.10.2 Starter – Removal	130	9.17.3 Engine mounting – Checking securing screws for firm seating	171
9.10.3 Starter – Installation	131	9.18 Fuel Supply System	172
9.10.4 Pneumatic starter – Overview	133	9.18.1 Pump capacity – Check	172
9.10.5 Starter – Removal	134	9.19 Engine Governor	173
9.10.6 Starter – Installation	135	9.19.1 Engine Control Unit – Overview	173
9.11 Lube Oil System, Lube Oil Circuit	136	9.19.2 Engine Control Unit – Removal and installation	174
9.11.1 Engine oil level – Check	136	9.19.3 Engine governor plug connections – Check	175
9.11.2 Engine oil – Change	137	9.20 Generator Mounting	176
9.12 Oil Filtration / Cooling	139	9.20.1 Generator mounting – Securing screw firm seating check	176
9.12.1 Engine oil filter – Replacement	139	9.20.2 Resilient mounts of generator mounting – Check	177
9.13 Coolant Circuit, General, High-Temperature Circuit	140	9.20.3 Generator mount – Measuring height of rubber element	178
9.13.1 Engine coolant – Level check	140	9.21 Wiring (General) for Engine/Gearbox/Unit	179
9.13.2 Engine coolant – Change	142	9.21.1 Engine cabling – Check	179
9.13.3 Engine coolant – Draining	143	9.22 Accessories for (Electronic) Engine Governor / Control System	180
9.13.4 Engine coolant – Filling	144	9.22.1 Engine control unit – Reading out fault memory	180
9.13.5 Engine coolant pump – Relief bore check	146	10 Appendix A	
9.13.6 Preheater – Function and leak check	147	10.1 Abbreviations	181
9.13.7 Preheater thermostats – Replacement	148	10.2 Contact person / Service partner	183
9.13.8 Coolant expansion tank – Valve cover replacement	151	11 Appendix B	
9.14 Cooling System	153	11.1 Standard Tools and Special Tools	184
9.14.1 Coolant cooler – External contamination and leak-tightness check	153	11.2 Index	194
9.14.2 Coolant cooler – Cleaning	154		
9.14.3 Fuel cooler – External contamination and leak-tightness check	156		
9.14.4 Fuel cooler – Cleaning	157		
9.15 Belt Drive	159		
9.15.1 Drive belt – Condition check	159		
9.15.2 Drive belt – Tension check	160		
9.15.3 Drive belt – Tension adjustment	162		

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>

2.2 Important requirements for Power Generation application products

Project-specific operational environment

During integration and use of the diesel engine, all currently valid and relevant standards and guidelines on safety and specified operation must be implemented and observed. This applies to persons responsible for:

- The installation of the engine
- The design of the engine-generator set
- The installation of the engine-generator set

The relevant standards are, in particular:

- DIN EN 1679-1
- EN ISO 8528-13

Residual hazards

In the event of a defect, the diesel engine can unexpectedly have insufficient or no drive power at all. We therefore recommend a redundant design of the engine-generator set system in safety-critical applications.

Protection against hot surfaces

Combustion engines and their auxiliary components have hot surfaces (e.g. exhaust system, exhaust turbochargers, exhaust aftertreatment system, engine oil system, cooling system), which can cause injury to persons who approach or touch them (danger of burns).

- In operation
- During the cooling-down phase after operation

The plant integrator and operator must assess, based on spatial or other plant conditions, whether the danger potential usually associated with the state of technology is exceeded, e.g.:

- Particularly narrow maintenance spaces
- Particularly exposed position of hot surfaces

In such cases, the plant integrator or operator must equip the plant with the necessary and suitable safety devices to reliably exclude the possibility of personal injury, e.g.:

- Heat shields
- Insulation

The operator must ensure that the plant is not operated without these protective devices. Operating and maintenance personnel must be informed about the danger of hot surfaces and the prohibition of operation without the protective devices.

Noise

Noise protection measures that comply with statutory requirements must be implemented by the plant integrator and operator.

Chemical resistance

Only use hoses, pipes, fittings, etc. that can tolerate the fluids and lubricants in accordance with the Fluids and Lubricants Specifications. Only use options that are resistant to the fluids and lubricants in accordance with the Fluids and Lubricants Specifications.

Electrical devices

The IP protection class of the electrical devices required by the manufacturer must be observed.

Hoses

For vibration decoupling, where possible only use hoses or rubber sleeves. Install devices in low-vibration areas and not on the engine. Hoses must be installed such that they do not chafe and are not under tension.

Incorrect synchronization

Load application with incorrect synchronization (generator connection with phase offset) can cause considerably high torque pulses. The plant integrator must design the control system such that the possibility of a load application with incorrect synchronization is excluded.

Emergency stop

The diesel engine has inputs for Stop and Emergency stop. The emergency-stop function must be executable in the whole plant independently of the operation stop. This is the only way to ensure that a safe shutdown of fuel injection takes place on a diverse redundant path and thus results in engine standstill. Through an appropriate design of the engine-generator set or whole plant, the operator of the engine must guarantee that safe, non-reversible stopping of the engine is as fast as possible, including all of its dangerous system components, when the emergency-stop actuating element is activated. In particular, it must always be guaranteed that machine shutdown can not be prevented or delayed once the command for shutdown has been issued. The engine shutdown command must always have priority over the start command.

If machines or machine components are designed to interact, they must be designed and built such that all devices can shut down. This relates to:

- Emergency-stop command devices for the machine itself (engine, engine-generator set)
- All connected devices insofar as their continued operation could result in a hazard

Important

Engines with exhaust aftertreatment: When the emergency stop is actuated on engine with an exhaust aftertreatment system, note that the emergency-stop function also interrupts the reducing agent supply. This can result in overheating of the reducing agent dosing units. For details and further information, see Operating Instructions.