

Operating Instructions

Diesel engine
12V4000G60
12V4000G80

M015236/11E



Power. Passion. Partnership.

Engine model	Power rating	Application group
12V4000G60	91.25 kW/cyl.	3A, continuous operation, unrestricted
12V4000G80	93.33 kW/cyl.	3A, continuous operation, unrestricted

Table 1: Applicability

Table of Contents

1 Safety		6 Maintenance	
1.1 Important provisions for all products	5	6.1 Maintenance task reference table [QL1]	40
1.2 Correct use of all products	6		
1.3 Personnel and organizational requirements	7	7 Troubleshooting	
1.4 Safety regulations for initial start-up and operation	8	7.1 Troubleshooting	41
1.5 Safety regulations for maintenance and repair work	10	7.2 Fault messages on engine governor	44
1.6 Fire prevention and environmental protection, fluids and lubricants, indirect materials	14		
1.7 Standards for safety notices in the text	16	8 Task Description	
2 Transport		8.1 Engine	55
2.1 Transportation	17	8.1.1 Engine - Barring manually	55
2.2 Lifting requirements	18	8.1.2 Engine - Cranking on starting system	57
2.3 Crankshaft transport locking device	19	8.1.3 Engine - Test run	58
3 General Information		8.2 Cylinder Liner	59
3.1 Engine side and cylinder designations	22	8.2.1 Cylinder liner - Endoscopic examination	59
3.2 Engine - Overview	23	8.2.2 Cylinder liner - Instructions and comments on endoscopic and visual examination	61
4 Technical Data		8.3 Crankcase Breather	63
4.1 Product data 12V4000G60, 12V4000G80, continuous operation, unlimited 3A	25	8.3.1 Crankcase breather - Oil separator check	63
4.2 Firing order	29	8.3.2 Crankcase breather - Filter element replacement	64
4.3 Engine - Main dimensions	30	8.4 Valve Drive	65
5 Operation		8.4.1 Valve gear - Lubrication	65
5.1 Putting the engine-generator set into operation after extended out-of-service-periods - Preparation	31	8.4.2 Valve clearance - Check and adjustment	66
5.2 Putting engine into operation after scheduled out-of-service-period - Preparation	32	8.4.3 Cylinder head cover - Removal and installation	72
5.3 Engine - Starting in manual mode (test run)	33	8.5 Injection Pump / HP Pump	73
5.4 Starting the engine in emergency situations (override mode)	34	8.5.1 HP fuel pump - Relief bore check	73
5.5 Operational checks	35	8.6 Injector	74
5.6 Engine - Stopping in manual mode (test run)	36	8.6.1 Injector - Replacement	74
5.7 Engine - Emergency stop	37	8.6.2 Injector - Removal and installation	75
5.8 After stopping the engine - Putting the engine out of operation	38	8.7 Fuel System	80
5.9 Plant - Cleaning	39	8.7.1 Fuel system - Filling	80
		8.8 Fuel Filter	81
		8.8.1 Fuel filter - Replacement	81
		8.8.2 Fuel prefilter - Draining	82
		8.8.3 Fuel prefilter - Differential pressure gage check and adjustment	84
		8.8.4 Fuel prefilter - Filter element replacement	85
		8.8.5 Fuel prefilter - Flushing	87
		8.8.6 Fuel prefilter - Cleaning	89
		8.9 Exhaust Turbocharger	90
		8.9.1 Exhaust turbocharger - Replacement	90
		8.9.2 Exhaust turbocharger - Removal	91
		8.9.3 Exhaust turbocharger - Installation	92
		8.10 Charge-Air Cooling	93

8.10.1	Charge-air cooler - Check water drain for coolant leakage and obstruction	93	8.17.3	Charge-air coolant - Draining	118
8.11	Air Filter	94	8.17.4	Charge-air coolant - Filling	120
8.11.1	Air filter - Replacement	94	8.17.5	Charge-air coolant - Sample extraction and analysis	124
8.11.2	Air filter - Removal and installation	95	8.17.6	Charge-air coolant pump - Relief bore check	126
8.12	Air Intake	96	8.18	Belt Drive	127
8.12.1	Service indicator - Signal ring position check	96	8.18.1	Drive belt - Condition check	127
8.13	Starting Equipment	97	8.19	Battery-Charging Generator	128
8.13.1	Starter - Condition check	97	8.19.1	Battery-charging generator drive - Drive belt tension adjustment	128
8.14	Lube Oil System, Lube Oil Circuit	98	8.19.2	Battery-charging generator drive - Drive belt condition check	129
8.14.1	Engine oil level - Check	98	8.19.3	Battery-charging generator drive - Drive belt replacement	130
8.14.2	Engine oil - Change	99	8.20	Wiring (General) for Engine/Gearbox/Unit	131
8.14.3	Engine oil - Sample extraction and analysis	101	8.20.1	Engine cabling - Check	131
8.15	Oil Filtration / Cooling	102	8.21	Accessories for (Electronic) Engine Governor / Control System	132
8.15.1	Engine oil filter - Replacement	102	8.21.1	Engine Control Unit and connectors - Cleaning	132
8.15.2	Centrifugal oil filter - Cleaning and filter sleeve replacement	103	8.21.2	Engine Control Unit - Plug connection check	133
8.16	Coolant Circuit, General, High-Temperature Circuit	105	9	Appendix A	
8.16.1	Engine coolant - Level check	105	9.1	Abbreviations	134
8.16.2	Engine coolant - Change	107	9.2	MTU Contact/Service Partners	137
8.16.3	Engine coolant - Draining	108	10	Appendix B	
8.16.4	Engine coolant - Filling	109	10.1	Special Tools	138
8.16.5	Engine coolant - Sample extraction and analysis	113	10.2	Index	145
8.16.6	Engine coolant pump - Relief bore check	115			
8.17	Low-Temperature Circuit	116			
8.17.1	Charge-air coolant - Level check	116			
8.17.2	Charge-air coolant - Change	117			

1 Safety

1.1 Important provisions for all products

General information

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number and must match with the information on the title page of this manual.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. When operating the machine in the EU: The second nameplate must be affixed in a prominent position as described in the accompanying specifications.

Emission regulations and emission labels

Responsibility for compliance with emission regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emission characteristics of the product are prohibited by emission regulations. Emission control units/systems may only be maintained, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these regulations will invalidate the design type approval issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emission regulations. The maintenance schedules of the manufacturer must be observed over the entire life cycle of the product.

Replacing components with emission labels

On all MTU engines fitted with emission labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emission labels:

- The relevant emission labels must be affixed to the spare part.
- Emission labels shall not be transferred from the replaced part to the spare part.
- The emission labels must be removed from the replaced part and destroyed.

1.2 Correct use of all products

Correct use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair
- By contracting only workshops authorized by the manufacturer to carry out repair and overhaul

The product must not be operated in explosive atmospheres, unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found on the websites:

- For drive systems: <http://www.mtu-online.com>
- For power generation: <http://www.mtuonsiteenergy.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

1.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. These personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the descriptions of the individual activities.

1.4 Safety regulations for initial start-up and operation

Safety regulations for initial start-up

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before putting the product into service. All necessary approvals must be granted by the relevant authorities and all requirements for initial startup must be fulfilled.

Whenever the product is subsequently taken into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All safety equipment is in place.
- No persons wearing pacemakers or any other technical body aids are present.
- The service room is adequately ventilated.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil. These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust system is leak-tight and that the gases are vented to atmosphere.
- The product must be free of any damage, this applies in particular to lines and cabling.
- Protect battery terminals, generator terminals or cables against accidental contact.
- Check that all connections have been correctly allocated e.g. +/- polarity, direction.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be permanently observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

The following steps must be taken if a malfunction of the system is recognized or reported by the system:

- inform supervisor(s) in charge,
- analyze the message,
- respond by taking any necessary emergency action, e.g. emergency stop.

Operation

Do not remain in the operating room when the product is running unless absolutely necessary. Keep your stay as short as possible.

Keep a safe distance away from the product if possible. Do not touch the product unless expressly instructed to do so following a written procedure.

Do not inhale the exhaust gases of the product.

The following requirements must be fulfilled before the product is started:

- Wear ear protectors.
- Mop up any leaked or spilt fluids and lubricants immediately or soak up with a suitable binding agent.

Operation of electrical equipment

When electrical equipment is in operation, certain components of these appliances are electrically live.

Follow the applicable operating and safety instructions when operating the devices and heed warnings at all times.

1.5 Safety regulations for maintenance and repair work

Safety regulations when preparing to perform maintenance and repair work

Have maintenance or repair work carried out by qualified and authorized personnel only.

Allow the product to cool down to less than 50 °C (risk of explosion for oil vapors, fluids and lubricants, risk of burning).

Relieve pressure in fluid and lubricant systems and compressed-air lines which are to be opened. Use suitable containers of adequate capacity to catch fluids and lubricants.

When changing the oil or working on the fuel system, ensure that the service room is adequately ventilated.

Never carry out maintenance and repair work with the product in operation, unless:

- It is expressly permitted to do so following a written procedure.
- The product is running in the low load range and only for as long as absolutely necessary.

Lock-out the product to preclude undesired starting, e.g.

- Start interlock
- Key switch
- With hydraulic starting system: shut off supply line.

Attach "Do not operate" sign in the operating area or to control equipment.

Disconnect the battery cables or actuate the battery isolating switch, if fitted. Lock circuit breakers.

Close the main valve on the compressed-air system and vent the compressed-air line when pneumatic starters are fitted.

Disconnect the control equipment from the product.

Use the recommended special tools or suitable equivalents when instructed to do so.

Elastomer components (e.g. engine mounts, damping elements, couplings and V-belts) must not be painted. Only install them after painting the engine or mask them prior to painting.

The following applies to starters with copper-beryllium alloy pinions:

- Wear a respirator mask (filter class P3). Do not blow out the interior of the flywheel housing or the starter with compressed air. Clean the flywheel housing inside with a class H dust extraction device.
- Observe the safety data sheet.

Safety regulations when performing maintenance and repair work

Take special care when removing ventilation or plug screws from the product.

Release residual pressure before removing or replacing a component in the supply line. To depressurize pressurized lines, shut off the lines first, then release the residual pressure.

Use only proper and calibrated tools. Observe the specified tightening torques during assembly or disassembly.

Carry out work only on assemblies or plants which are properly secured.

Use appropriate lifting equipment for all components. Use all specified attachment points and observe the center of gravity.

Never work on engines or components when they are held in place by lifting equipment.

Make sure components or assemblies are placed on stable surfaces. Adopt suitable measures to avoid that components/tools fall down.

Never use the product as a climbing aid.

When working high on the equipment, always use suitable ladders and work platforms. Special instructions for outdoor areas: There must be no risk of slipping e.g. due to icing.

Keep fuel injection lines and connections clean.